




# ATLANTA 1829 Radio-Controlled Alarm Clock Instruction Manual

[Home](#) » [ATLANTA](#) » ATLANTA 1829 Radio-Controlled Alarm Clock Instruction Manual 

Radio-Controlled Analog Alarm Clock



Instruction Manual



1. BATTERY 2. SET ALARM 3. ALARM ON OFF 4. SNOOZE LIGHT 5. M. SET	6. REC 7. RESET 8. BATTERY 9. ALARM OUTPUT
---	---

## **Contents**

- 1 BATTERY INSERTION/REPLACEMENT**
- 2 SETTING THE CLOCK AUTOMATICALLY**
- 3 ALARM FUNCTIONS SET ALARM TIME**
- 4 SWITCH ON ALARM**
- 5 INTERRUPT ALARM (SNOOZE)**
- 6 AUTOMATIC SWITCH-OFF**
- 7 SWITCH OFF ALARM**
- 8 ILLUMINATION**
- 9 TO SET THE TIME MANUALLY**
- 10 RECEIVING THE RADIO CONTROL SIGNAL**
- 11 Documents / Resources**
- 12 Related Posts**

## **BATTERY INSERTION/REPLACEMENT**

To install and replace the battery, please follow these steps:

1. Pull down the battery (1), (8) compartments (at the back of the case).
2. Insert two new batteries (AA type, 1.5V, LR6), observing correct polarity as indicated in the battery compartment..
3. Put the lid (1), (8) back again.

## **SETTING THE CLOCK AUTOMATICALLY**

Once the batteries are installed properly, the clock automatically sets itself to 12 O'clock and then receives the signal. Once it has received the DCF signal and processed it accordingly (which takes 3 to a maximum of 12 minutes), the clock automatically displays the correct time. We recommend that you do not put up or hang up the clock anywhere during this process. If the clock still has not set itself after 12 minutes, reception is faulty or not possible at the chosen location. Repeat setting at a different location by pressing the RESET button (7).

## **ALARM FUNCTIONS SET ALARM TIME**

Turn the set-alarm knob (2) in the direction of the arrow in order to set the alarm time. Never turn the set-alarm knob in the opposite direction since this could damage the works.

## **SWITCH ON ALARM**

Push the alarm ON/OFF switch (3) upwards. At the set alarm time, the alarm sounds for maximum 2 minutes if the alarm ON/OFF switch (3) is still upwards (i.e. at the ON position) or the top (4) button is not pressed.

## **INTERRUPT ALARM (SNOOZE)**

Press the snooze button on the top (4) of the alarm clock, the light turns on for 5 seconds. The alarm stops for 5 minutes and then sounds again. The snooze function can be repeated 3-7 times.

## AUTOMATIC SWITCH-OFF

If the alarm is not interrupted or switched off, it stops automatically after approx. 2 minutes. It is reactivated 12 hours later at the same time.

## SWITCH OFF ALARM

When the alarm is activated, push the alarm ON/OFF switch (3) downwards, and the alarm stops.

## ILLUMINATION

To be able to read the face of your alarm clock even when it is dark, briefly press the button (4) on the top of the alarm clock. The illumination function is activated for 5 seconds.

## TO SET THE TIME MANUALLY


Press and hold the M.SET (5) button for 3 seconds to set the time: Press the M.SET button (5) for 1 second to advance 1 minute Press the M.SET button (5) for more than 1 second to auto-advance the minute hand. If the M.SET button (5) is not pressed for 8 seconds, the clock is set.

## RECEIVING THE RADIO CONTROL SIGNAL

The radio-controlled clock will automatically receive the radio signal 12 times every day. It will take 3-12 minutes to receive the radio signal. During force DCF reception by pressing the REC button (6) for 3 seconds, the clock will go to 12 O'clock and start receiving the radio signal for 3-12 minutes. Once it has received the DCF signal and processed it accordingly, the clock automatically displays the correct time. If the clock still has not set itself after 12 minutes, reception is faulty and it will resume the time before the force reception.

This item complies with all the required European

## Documents / Resources

	<a href="#">ATLANTA 1829 Radio-Controlled Alarm Clock</a> [pdf] Instruction Manual 1829, 1825, Radio-Controlled Alarm Clock
---	--