

Autonics PS08 Inductive Proximity Sensor Instruction Manual

Home » Autonics » Autonics PS08 Inductive Proximity Sensor Instruction Manual



Autonics

DRW160733AC **INDUCTIVE PROXIMITY SENSOR PS SERIES INSTRUCTION MANUAL**





Thank you very much for selecting Autonics products. For your safety, please read the following before using.

Contents


- 1 Safety Considerations
- 2 Ordering Information
- 3 Control Output Diagram and Load Operation
- **4 Specifications**
- **5 Dimensions**
- 6 Mutual-Interference and Infl uence By Surrounding

Metals

- 7 Setting Distance
- 8 Caution during Use
- 9 Major Products
- 10 Documents / Resources
 - 10.1 References

Safety Considerations

- * Please observe all safety considerations for safe and proper product operation to avoid hazards.
- * A symbol represents caution due to special circumstances in which hazards may occur.



Caution Failure to follow these instructions may result in personal injury or product damage.

Marning

- 1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
 - Failure to follow this instruction may result in fire, personal injury, or economic loss.
- 2. Do not disassemble or modify the unit.
 - Failure to follow this instruction may result in fi re.
- 3. Do not connect, repair, or inspect the unit while connected to a power source.
 - Failure to follow this instruction may result in fi re.
- 4. Check 'Connections' before wiring.
 - Failure to follow this instruction may result in fi re.




1. Use the unit within the rated specifi cations.

Failure to follow this instruction may result in fi re or product damage.


- 2. Use dry cloth to clean the unit, and do not use water or organic solvent.
 - Failure to follow this instruction may result in electric shock or fi re.
- 3. Do not use the unit in the place where fl ammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
 - Failure to follow this instruction may result in fi re or explosion.
- 4. Do not supply power without load.

Failure to follow this instruction may result in fire or product damage.

Ordering Information



Control Output Diagram and Load Operation



- *1: For PS08 model, there is no zener diode.
- * The above specifi cations are subject to change and some models may be discontinued without notice.
- * Be sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage).

Specifications

		PS08-2.5DN 5DNU	PS08-2.	PS12-4DN	PS12-4		
Model		PS08-2.5DP	PS08-2.	DNU	F312-4		
		5DPU	D000 0	PS12-4DP DPU	PS12-4	PS50-30DN PS50-30DN2	
		PS08-2.5DN2 5DN2U	PS08-2.	PS12-4DN2	PS12-4	PS50-30DP PS50-30DP2	
		PS08-2.5DP2 5DP2U	PS08-2.	DN2U	1012 +		
Sensing distance		2.5mm		4mm		30mm	
Hysteresis		Max. 20% of sensing distance		Max. 10% of sensing distance			
Standard sensing targ et		8x8x1mm (Iron)		12x12x1mm (Iron)		90x90x1mm (Iron)	
Setting distance		0 to 1.7mm		0 to 2.8mm		0 to 21mm	
Power supply (Operating voltage)		12-24VDC= (10-30VDC=)					
Current consumption		Max. 10mA					
Response frequency'		1,000Hz		1500Hz		150Hz	
Residual voltage		Max. 1.5V					
Affection by Temp.		Max. ±10% for sensing distance at ambient temperature 20°C					
Control output		Max. 100mA Max. 200mA					
Insulation resistance		Min. 50M0 (at 500VDC megger)					
Dielectric strength		1,500VAC 50/60Hz for 1 minute					
Vibration		1mm amplitude at frequency of 10 to 55Hz in each of X, Y, Z directions for 2 hours					
Shock		500m/s ² (approx. 50G) in X, Y, Z directions for 3 times					
Indicator		Operation indicator: Red LED					
Envir on -	Ambient temp erature	-25 to 70°C, Storage: -30 to 80°C					
ment	Ambient humi dity	35 to 95%RH, Storage: 35 to 95%RH					
Protection circuit		Reverse polarity protection, Surge protection circuit, Overcurrent protection					
Protection structure		IP67 (IEC standard)					
Cable x2		02.5mm, 3-wire, li	m	04mm, 3-wire, 2	m	05mm, 3-wire, 2m	
		AWG28, Core dia 8mm, Number of Insulator diameter	cores: 19,	AWG22, Core diameter: 0.08mm, Number of cores: 60, I nsulator diameter: 01.25mm			

Material	Case: Polycarbonate Gener al cable (gray): Polyvinyl chl oride (PVC)	Case: Heat-resistant ABS General cable (gray): Polyvi nyl chloride (PVC)	Case: Polybutylene terep hthalate General cable (gr ay): Polyvinyl chloride (PVC)		
Approval	C €				
Weight ^{x3}	Approx. 30g (approx. 16g)	Approx. 77g (approx. 62g)	Approx. 265g (approx. 22 0g)		


^{*1:} The response frequency is the average value. The standard sensing target is used and the width is set as 2 times of the standard sensing target, 1/2 of the sensing distance for the distance.

It may result in fi re due to the broken wire. When extending wire, use AWG22 cable or over within 200m.

- *3: The weight includes packaging. The weight in parentheses in for unit only.
- *Environment resistance is rated at no freezing or condensation.

Dimensions

^{*2:} Do not pull the Ø4mm cable with a tensile strength of 30N or over and the Ø5mm cable with a tensile strength of 50N or over.




Mutual-Interference and Infl uence By Surrounding Metals

• Mutual-interference

When plural proximity sensors are mounted in a close row, malfunction of sensor may be caused due to mutual interference.

Therefore, be sure to provide a minimum distance between the two sensors, as below charts.


(unit: mm)




· Influence by surrounding metals

When sensors are mounted on metallic panel, it must be prevented sensors from being affected by any metallic object except target.

Therefore, be sure to provide a minimum distance as a right picture.



Setting Distance



• Sensing distance can be changed by the shape, size or material of the target.

Therefore please check the sensing distance like (a), then pass the target within range of setting distance(Sa).

Setting distance(Sa)= Sensing distance(Sn) × 70% E.g.)PS50-30DN
 Setting distance(Sa)= 30mm × 0.7 = 21mm

Caution during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- 2. 12-24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- 3. Use the product, after 0.8 sec of supplying power.
- 4. Wire as short as possible and keep away from high voltage lines or power lines, to prevent surge and inductive noise.

Do not use near the equipment which generates strong magnetic force or high frequency noise (transceiver, etc.).

In case installing the product near the equipment which generates strong surge (motor, welding machine, etc.), use diode or varistor to remove surge.

- 5. This unit may be used in the following environments.
 - ① Indoors (in the environment condition rated in 'Specifi cations')
 - 2 Altitude max. 2,000m
 - 3 Pollution degree 2
 - 4 Installation category II

Major Products

- Photoelectric Sensors
- · Fiber Optic Sensors
- Door Sensors
- Door Side Sensors
- · Area Sensors
- · Proximity Sensors
- Pressure Sensors
- Rotary Encoders
- Connectors/Sockets
- Switching Mode Power Supplies
- · Control Switches/Lamps/Buzzers
- I/O Terminal Blocks & Cables
- Stepper Motors/Drivers/Motion Controllers
- · Graphic/Logic Panels
- · Field Network Devices
- Laser Marking System (Fiber, Co₂, Nd: YAG)
- · Laser Welding/Cutting System
- Temperature Controllers
- Temperature/Humidity Transducers
- SSRs/Power Controllers
- Counters
- Timers

- · Panel Meters
- Tachometers/Pulse (Rate) Meters
- · Display Units
- Sensor Controllers

Autonics

Corporation

http://www.autonics.com

HEADQUARTERS:

18, Bansong-ro 513 beon-gil, Haeundae-gu, Busan, South Korea, 48002

TEL: 82-51-519-3232 E-mail: sales@autonics.com DRW160733AC

Documents / Resources



<u>Autonics PS08 Inductive Proximity Sensor</u> [pdf] Instruction Manual PS08, PS12, PS50, PS08 Inductive Proximity Sensor, Inductive Proximity Sensor, Proximity Sensor, Sensor

References

- A autonics.com
- MH Search Manual-Hub.com

Manuals+,