



Axis Communications Door/Window Sensor T8342 Manual

[Home](#) » [AXIS COMMUNICATIONS](#) » **Axis Communications Door/Window Sensor T8342 Manual** 

Contents

- [1 Axis Communications](#)
- [2 Door/Window Sensor](#)
 - [2.1 SKU: T8342](#)
 - [2.2 Quickstart](#)
 - [2.3 Important safety information](#)
 - [2.4 What is Z-Wave?](#)
 - [2.5 Product Description](#)
 - [2.6 Prepare for Installation / Reset](#)
 - [2.6.1 Reset to factory default](#)
 - [2.7 Inclusion/Exclusion](#)
 - [2.7.1 Inclusion](#)
 - [2.7.2 Exclusion](#)
 - [2.8 Communication to a Sleeping device \(Wakeup\)](#)
 - [2.9 Quick trouble shooting](#)
 - [2.10 Association – one device controls an other device](#)
 - [2.10.1 Association Groups:](#)
 - [2.11 Technical Data](#)
 - [2.12 Supported Command Classes](#)
 - [2.13 Controlled Command Classes](#)
 - [2.14 Explanation of Z-Wave specific terms](#)
 - [2.15 Related Posts](#)

Axis Communications

Door/Window Sensor

SKU: T8342



Quickstart

This is a
secure
Alarm Sensor
for
U.S. / Canada / Mexico.

Please make sure the internal battery is fully charged.

To add this device to your network execute the following action:

1. Put the Z-Wave Controller into inclusion mode
2. Press the tamper switch 3 times within 1.5 seconds to put the unit into inclusion mode.

Please refer to the [Manufacturers Manual](#) for more information.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

AXIS T8342 Door/Window Sensor is an easy to install, wireless sensor which enables triggering of a series of events such as notification messages, illumination and much more. With its support for wireless input/output connectivity, the door/window sensor can communicate wirelessly with AXIS M5065 PTZ Network camera or other connected Z-Wave Plus controllers, creating a small security solution with less cabling. Thanks to its integrated wireless I/O connectivity, AXIS T8342 enables flexible installation as the sensor can easily be mounted on a door, window, or cabinet according to your needs.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly

from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

This procedure should only be used when the controller is inoperable.1. Press the tamper switch 3 times within 1.5 seconds to put the unit into exclusion mode.2. Within 1 second of step 1, press the tamper switch again and hold for 5 seconds.3. Node ID is excluded. The device reverts to factory default state.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

1. Put the Z-Wave Controller into inclusion mode2. Press the tamper switch 3 times within 1.5 seconds to put the unit into inclusion mode.

Exclusion

1. Put the Z-Wave Controller into exclusion mode.2. Press the tamper switch 3 times within 1.5 seconds to put the unit into exclusion mode.

Communication to a Sleeping device (Wakeup)

This device is battery operated and turned into deep sleep state most of the time to save battery life time. Communication with the device is limited. In order to communicate with the device, a static controller **C** is needed in the network. This controller will maintain a mailbox for the battery operated devices and store commands that can not be received during deep sleep state. Without such a controller, communication may become impossible and/or the battery life time is significantly decreased.

This device will wakeup regularly and announce the wakeup state by sending out a so called Wakeup Notification. The controller can then empty the mailbox. Therefore, the device needs to be configured with the desired wakeup interval and the node ID of the controller. If the device was included by a static controller this controller will usually perform all necessary configurations. The wakeup interval is a tradeoff between maximal battery life time and the desired responses of the device. To wakeup the device please perform the following action:

After the detector has been included into a Z-wave network it will go to sleep, but it will send a wake-up notification command to the controller periodically at a preset period. The motion detector will stay awake for at least 10 seconds and then go back to sleep to conserve battery life. The time interval between wake up notification commands can be set in the wake up command class based on the range values below: Minimum wake up interval 600s (10 minutes) Maximum wake up interval 86400s (1 day) Default wake up interval 14400s (4 hours) Wake up interval step seconds 600s (10 minutes)

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group NumberMaximum NodesDescription

1	1	Association with 1 node.
2	4	Association with 4 nodes.

Technical Data

Hardware Platform	SD3502
Device Type	Notification Sensor
Network Operation	Reporting Sleeping Slave
Firmware Version	HW: 1 FW: 1.01:00.01
Z-Wave Version	6.71.01
Certification ID	ZC10-17115881
Z-Wave Product Id	0x0364.0x0003.0x0001
Supported Notification Types	Access Control
Color	White
Firmware Updatable	Updatable by Consumer via Internet
Security V2	S2_UNAUTHENTICATED ,S2_AUTHENTICATED
Frequency	XXfrequency
Maximum transmission power	XXantenna

Supported Command Classes

- Association Grp Info

- Association V2
- Battery
- Device Reset Locally
- Firmware Update Md V4
- Manufacturer Specific V2
- Notification V4
- Powerlevel
- Security
- Security 2
- Supervision
- Transport Service V2
- Version V2
- Wake Up V2
- Zwaveplus Info V2

Controlled Command Classes

- Basic

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.