



## Bell 2GIG Personal Panic Device Instructions

[Home](#) » [Bell](#) » Bell 2GIG Personal Panic Device Instructions 



Battery replacement instructions for your Bell Smart Home equipment.

Enclosed you will find the replacement battery for your Bell Smart Home Personal Panic Device. Please refer to the list below to identify the personal panic device belonging to you that requires a battery replacement, then follow the step-by-step instructions on how to replace it.

### Contents

- [1 Battery Disposal](#)
- [2 Instructions](#)
- [3 Interlogix Personal Panic Device](#)
- [4 2GIG Personal Panic Device](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

### Battery Disposal

We encourage you to dispose of your old battery in an environmentally friendly way. For more information about the designated battery types and recycling depot locations, please visit [www.call2recycle.ca](http://www.call2recycle.ca).

### Instructions

Please start by disarming your system.

## Interlogix Personal Panic Device

Battery Type: 1 x CR1632



1. Remove the two screws on the back of the Personal Panic Device, observing how the wristband components are attached.
2. Carefully separate the cover and base.
3. Remove the electronic subassembly (blue circuit board) from the base.
4. Remove the battery from the electronic subassembly.
5. Install the new battery.
6. Place the electronic subassembly back into the base.
7. Put the cover back and replace the screws.
8. Contact Technical Support to confirm the battery replacement was successful and the device is in proper working order. Contact numbers are located at the end of this document.

## 2GIG Personal Panic Device

Battery Type: 1 x CR1632



1. Remove the top cover by inserting a small flat-head screwdriver into the slot (located on the bottom right corner) and twist gently.
2. Remove the circuit board from the plastic case, and then remove the battery from the circuit board.
3. Insert the replacement battery with the (+) sign facing out.
4. Replace the circuit board in the plastic case, and then replace the top cover.
5. Contact Technical Support to confirm the battery replacement was successful and the device is in proper working order. Contact numbers are located at the end of this document.


For any additional questions about your Bell Smart Home equipment, visit [bell.ca/smart-home](https://bell.ca/smart-home).

Or call our Technical Support team using the following numbers: Ontario and Québec: **1 877 267-2004**. Manitoba: **1 866 949-0078**.

New Brunswick, Nova Scotia, Newfoundland and Labrador, and PEI: **1 844 474-2023**.

CR1632  
108087425

## Documents / Resources

	<p><b>Bell 2GIG Personal Panic Device</b> [pdf] Instructions</p> <p>2GIG, Personal Panic Device</p>
--	---

References

- [Bell Maison intelligente | Sécurité résidentielle et domotique | Bell change selected close](#)
- [Bell Smart Home | Security System and Home Automation | Bell Canada change selected close](#)
- [Call2Recycle® | Canada](#)