



## Bell Smart Home device or sensor battery replacement Instructions

[Home](#) » [Bell](#) » Bell Smart Home device or sensor battery replacement Instructions 



**Battery replacement instructions for your Bell Smart Home equipment.**

Enclosed you will find the replacement batteries for your Bell Smart Home device or sensor. Please refer to the list below to identify the device or sensor belonging to you that requires a battery replacement, then follow the step-by-step instructions on how to replace them.

### Contents

- [1 Battery Disposal](#)
- [2 Instructions](#)
- [3 Flood Detector](#)
- [4 Smoke Detector](#)
- [5 Wireless Keypad](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

### Battery Disposal

We encourage you to dispose of your old batteries in an environmentally friendly way. For more information about the designated battery types and recycling depot locations, please visit [call2recycle.ca](https://call2recycle.ca).

### Instructions

Please start by disarming your system.

## Flood Detector

Battery Type: 4 x AAA

1. Remove the two front-facing screws from the rear of the sensor with a Phillips screwdriver to separate the two halves of the sensor.
2. Observe the battery polarity.
3. Remove the old batteries.
4. Install the new batteries.
5. Reattach the two halves of the sensor, and re-install the screws.
6. Contact Technical Support to confirm the battery replacement was successful and the sensor is in proper working order. Contact numbers are located at the end of this document.



## Smoke Detector

Battery Type: 3 x AAA

1. Remove the detector from its mounting base by twisting the detector counter-clockwise, and then pulling the detector away from the mounting base. You may hear beeping from your alarm system; this is normal.
2. Observe the battery polarity.
3. Remove the old batteries and wait 30 seconds.
4. Install the new batteries.
5. Re-install the detector on its mounting base, by turning the detector clockwise to lock it into place.
6. Contact Technical Support to confirm the battery replacement was successful and the sensor is in proper working order. Contact numbers are located at the end of this document.



## Wireless Keypad




Battery Type: 3 x AAA

1. Remove the cover by loosening the screw located at the bottom of the keypad with a Phillips screwdriver.
2. Observe the battery polarity.
3. Remove the old batteries.
4. Install the new batteries.
5. Replace the cover and tighten the screw.
6. Contact Technical Support to confirm the battery replacement was successful and the sensor is in proper working order. Contact numbers are located at the end of this document.



For any additional questions about your Bell Smart Home equipment, visit [bell.ca/smart-home](https://bell.ca/smart-home). Or call our Technical Support team using the following numbers: 1 866 949-0078. New Brunswick, Nova Scotia, Newfoundland and Labrador, and PEI: 1 844 474-2023.

Documents / Resources

	<a href="#">Bell Bell Smart Home device or sensor battery replacement</a> [pdf] Instructions Bell, Smart, Home equipment, battery, replacement
	<a href="#">Bell Bell Smart Home device or sensor Battery replacement</a> [pdf] Instructions Bell, Smart Home, device, sensor
	<a href="#">Bell Bell Smart Home device or sensor battery replacement</a> [pdf] Instructions Bell, Smart Home, device, sensor, battery, replacement, CR2032

References

- [Bell Maison intelligente | Sécurité résidentielle et domotique | Bell change selected close](#)
- [Bell Smart Home | Security System and Home Automation | Bell Canada change selected close](#)

- [📞 Call2Recycle® | Canada](#)
- [📞 Call2Recycle® | Canada](#)

Manuals+.