

BLACK DECKER BL1220SGC Power Crusher Multi Function Blender



BLACK DECKER BL1220SGC Power Crusher Multi Function Blender User Manual

[Home](#) » [Black Decker](#) » **BLACK DECKER BL1220SGC Power Crusher Multi Function Blender User Manual** 

Contents

- 1 [BLACK DECKER BL1220SGC Power Crusher Multi Function Blender](#)
- 2 [IMPORTANT SAFEGUARDS.](#)
- 3 [SAVE THESE INSTRUCTIONS.](#)
- 4 [POWERCrush](#)
- 5 [USING YOUR BLENDER](#)
- 6 [BLENDING TIPS AND TRICKS](#)
- 7 [SPEED CHART](#)
- 8 [CARE AND CLEANING](#)
- 9 [RECIPES](#)
- 10 [QUICK AND EASY SALSA](#)
- 11 [Documents / Resources](#)
 - 11.1 [References](#)
- 12 [Related Posts](#)



BLACK DECKER BL1220SGC Power Crusher Multi Function Blender



Thank you for your purchase! Gracias por su compra!Merci de votre achat!

Should you have any questions or concerns with your new product, please call our Customer Service Line at 1-800-465-6070 (US and Canada). Please do not return to the store.

Si usted tiene alguna inquietud o pregunta con su producto, por favor llame a nuestra línea de servicio al cliente una atención inmediata 1-800-465-6070 (EE.UU./Canadá) 01-800-714-2503

Please Read and Save this Use and Care Book.

IMPORTANT SAFEGUARDS.

When using electrical appliances, always follow basic safety precautions to reduce the risk of fire, electric shock, and/or injury, including the following:

- Read all instructions.
- To protect against risk of electrical shock, do not put blender base, cord or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Turn the appliance OFF, then unplug from the outlet when not in use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
- Avoid contacting moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or is dropped or damaged in any manner. Contact the consumer service number listed in this manual.
- This appliance has important markings on the plug blade. The attachment plug or entire cordset (if plug is molded onto cord) is not suitable for replacement. If damaged, the appliance must be replaced.
- The use of attachments, including canning jars, not recommended or sold by the appliance manufacturer may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let the plug or cord hang over the edge of table or counter.
- Do not place on or near a hot gas or electric burner or in a heated oven.

- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
- Blades are sharp. Handle carefully.
- To reduce the risk of injury, never place blade assembly on base without the jar properly attached.
- Always operate blender with cover in place.
- Do not blend hot liquids.
- Do not use appliance for other than intended use.
- To avoid overheating, degraded performance, or inoperability, do not use the appliance beyond the recommended operating time.
- Avoid overloading the blender. Overloading may cause the motor to overheat. If the blender starts to overheat, stop use and allow the motor to cool down.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS.

This product is for household use only.

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

TAMPER-RESISTANT SCREW

Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

ELECTRICAL CORD

1. A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
2. Extension cords are available and may be used if care is exercised in their use.
3. If an extension cord is used,
 - The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance,
 - If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

Note: If the power cord is damaged, please contact the warranty department listed in these instructions.

GETTING TO KNOW YOUR

POWERCRUSH

MULTI-FUNCTION BLENDER

1.



Dual-opening lid

- 2. Pour spout
- 3. Ingredient slot
- 4. Blending jar
- 5. Handle
- 6. Blade assembly
- 7. Jar base
- 8. Base
- 9. OFF button
- 10. Speed buttons
- 11. Pulse buttons

Product may vary slightly from what is illustrated.

HOW TO USE

This product is for household use only.

GETTING STARTED

- Remove all packing material, any stickers from the product, and the plastic band around the plug.

- Remove and save literature.
- Please visit www.prodprotect.com/blackanddecker to register your warranty.
- Wash all removable parts as instructed in CARE AND CLEANING section of this manual.


BLENDER JAR ASSEMBLY

1. Turn blending jar upside down and place flat on counter top or work surface.
2. Place the blade assembly in bottom opening of the jar with blades down (A).



Caution: Blades are sharp. Handle carefully.

3. Place jar base onto jar and rotate clockwise until it is tight.
4. Turn assembled jar right side up.
5. Place dual-opening lid on blending jar.
Note: Make sure the pour spout and ingredient slot are closed.
6. Unwrap power cord from storage area under the base.
7. Place jar assembly on base (B).



8. Blender is now ready for use.

USING YOUR BLENDER

Important: Appliance should always have lid in place when in use.

Caution: Do not place blender jar onto base when motor is running.

1. Make sure appliance is OFF.
2. Place foods to be blended into jar. For best results place ingredients in jar in the following order: liquids, powders, soft foods, hard foods, ice.

Note: You must always add a liquid before blending.

Note: Avoid overloading the blender. If mixture is too thick, add more liquid.

Overloading may cause the motor to overheat. If blender overheats, stop use and allow motor to cool down.

3. Place lid on jar. Make sure the pour spout and ingredient slot are closed.
4. Plug power cord into outlet.

Note: When in use, do not leave blender unattended. When using hard foods, such as ice or cheese, keep one


hand on the lid to keep blender in place.

5. Select the speed that best suits your desired task.

(See SPEED CHART)

6. When blending thick mixtures, such as smoothies and milkshakes, press the Hi Pulse button for several seconds, then release. Repeat until food has desired consistency (C).

Note: Use PULSE for no more than five seconds at a time, allowing the blender to rest briefly between each pulse. Do not use PULSE for more than 2 minutes total. This helps break up the ice and distribute the ingredients.



7. Important: Do not remove the lid while the blender is running.
8. When finished, press the OFF button. Make sure blades have completely stopped before attempting to remove the blending jar from the base.
9. To remove the jar, grasp the handle and lift up.
10. Open pour spout to serve.

Note: Always unplug the appliance when not in use.

BLENDING TIPS AND TRICKS

- Cut food into pieces no larger than 3/4" for use in the blender.
- When preparing foods that have several different kinds of ingredients, always add liquid ingredients first.
- When ingredients splatter onto the sides of the jar or the mixture is very thick, press the OFF button to turn appliance off. Remove the lid and use a rubber spatula to scrape down the sides of the jar and to redistribute the food, pushing food toward the blades. Replace the lid and continue blending.
- When making bread crumbs make sure blender jar is completely dry.
- When using PULSE function; use short bursts for no more than five seconds at a time. Allow the blades to stop rotating between pulses. Do not use PULSE for more than 2 minutes total.
- Use the Hi Pulse button when preparing beverages that include ice cubes or anything frozen; this helps to produce a smoother texture.
- It is helpful to begin the blending process on the lowest speed and then increase to a higher speed, if necessary.
- To stop blending at any time, press the OFF button.

- When blending hot ingredients, open the ingredient slot. Cover lid with a cloth to avoid splattering and only use the lowest speed. Do not blend more than 2 1/2 to 3 cups at a time.
- Do not store foods in the blending jar.
- Do not overfill the blender (the blender is more efficient with less rather than more).
- Do not run blender for longer than 1 1/2 minutes at a time. Scrape down sides of blending jar, if necessary, and continue blending.
- Do not use if blending jar is chipped or cracked.
- It is not recommended to use your blender to beat egg whites, mix dough, mash potatoes, or grind meats.

DO NOT PLACE ANY OF THE FOLLOWING IN THE BLENDER:

- Large pieces of frozen foods
- Tough foods such as raw turnips, sweet potatoes and potatoes
- Bones
- Hard salami, pepperoni
- Boiling liquids (cool for 5 minutes before placing in blending jar)

USING THE PERSONAL BLENDER JAR

Caution: Do not blend hot liquids in the personal jar.

1. Place the personal blender jar on a flat surface with the open end facing up. Fill the jar with ingredients. Do not fill ingredients past the "20 oz." marking.

Note: For best results, add ingredients in the following order:

- Liquids
- Ice
- Hard Foods
- Soft Foods
- Powders

2. Place blade assembly in the jar opening with blades down.
3. Place jar base onto jar and rotate clockwise until it is tight. It is important to tighten to prevent leaking during blending.
4. Turn personal jar upside down and place on the blender base.
5. Select the appropriate speed or use PULSE to blend to desired consistency.
6. Once blending has finished, remove the personal jar by lifting off the base. Turn the jar over and place it on a flat surface.

Note: Always make sure blades have stopped moving before removing jar.

Important: If the jar gets stuck on the blending base or begins to loosen from the jar base, follow these steps:

- Unplug the unit
- Turn the jar clockwise to tighten jar onto the jar base

7. Remove the jar base from the personal jar by turning counterclockwise.

Then carefully remove blade assembly

8. Place the personal jar drinking lid on the personal jar and enjoy your delicious drinks on-the-go.

Caution: Blades are sharp. Handle carefully.

Note: The maximum rating is based on the blender jar attachment. The power input of the optional personal jar is less than the allowable deviation.

SPEED CHART

SPEED	FUNCTION	USAGE
LOW	Shake, Blend, Easy clean	Blend milkshakes and malts Blend salsas, prepare sauces, and remove lumps from gravies Blend drop of soap with hot water to clean blender quickly
HI	Smoothie, Icy drink, Puree	Prepare smoothies Liquefy frozen drinks Puree fruits and vegetables
LOW PULSE	Crumb, Chop, Dice	Make cookie, cereal and bread crumbs Chop fruits and vegetables Chop cooked meats
HI PULSE	Ice Crush	Crush ice and frozen food

CARE AND CLEANING

This product contains no user serviceable parts. Refer service to qualified service personnel.

CLEANING

1. Before cleaning, turn off and unplug the appliance.
2. Lift the blending jar by the handle off the base.
3. Remove jar base by turning it counterclockwise until loose.
4. Remove the blade assembly.
Caution: Blades are sharp. Handle carefully.
5. Remove lid.
6. Wash removable parts by hand or in the dishwasher. Place the jar on the bottom rack and the rest of the parts on the top rack only.

HELPFUL TIPS

- For quick cleanup, combine 1 cup hot water and a drop of liquid dish soap in the blending jar.
- Cover and blend on Easy Clean for about 30 seconds.
- Discard liquid and rinse thoroughly.

Important:

- Do not place the jar parts in boiling liquids.

- Do not immerse the base in liquid. Wipe the base with a damp cloth and dry thoroughly.
- Remove stubborn spots by rubbing with a damp cloth and nonabrasive cleaner.

Note: Do not use rough scouring pads or cleansers on parts or finish.

RECIPES

CLASSIC SMOOTHIE

This easy-to-blend classic smoothie is a great way to refresh at any time of day!

Ingredients

- 2 cups apple juice
- 2 medium bananas, halved
- 2 cups whole strawberries, frozen

Directions

Place all ingredients in blender jar in order shown. Cover and blend on SMOOTHIE (HI) for 30 seconds, or until smooth.

Makes about 3 cups.

Tip: Substitute orange juice for apple juice.

QUICK AND EASY SALSA

This fast and easy restaurant-style salsa is a great substitute for fresh Pico de Gallo when tomatoes are no longer in season. Serve it with your favorite chips or as a topping for tacos.

Ingredients

- 2 (10 oz.) cans diced tomatoes with green chilies
- 1/2 small onion, quartered
- 1 small jalapeno pepper, seeded, deveined
- 1 clove garlic, peeled and smashed
- 1/2 cup cilantro, loosely packed
- 1 Tbsp. lime juice
- 1 tsp. sugar
- 1/2 tsp. cumin
- 1/2 tsp. salt

Directions

Place ingredients in blender jar, in order shown. Cover and pulse on Chop (LOW PULSE) for 30 seconds or to desired consistency. For a small batch, cut recipe in half.

- Sello del Distribuidor:
- Fecha de compra:
- Modelo:


BL1200 Series – 120Vac 60 Hz 3.7A max.

Note: The maximum rating is based on the blending jar attachment, which draws the greatest load (power or current). Other recommended attachments may draw significantly less power or current

BLACK+DECKER® and the BLACK+DECKER® logos are trademarks of The Black & Decker Corporation, used under license by Empower Brands, LLC, a subsidiary of Spectrum Brands, Inc. for its manufacturing and sale of this product. All rights reserved. All other marks are trademarks of Empower Brands, LLC.

© 2023 Empower Brands, LLC. All rights reserved /
Todos los derechos reservados / Tous droits réservés.
Empower Brands, LLC, Middleton, WI 53562
Made in China.
Fabricado en China.
Fabriqué en Chine.

Documents / Resources

	<p>BLACK DECKER BL1220SGC Power Crusher Multi Function Blender [pdf] User Manual BL1220SGC Power Crusher Multi Function Blender, BL1220SGC, Power Crusher Multi Function Blender, Crusher Multi Function Blender, Multi Function Blender, Function Blender</p>
--	--

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.