



BLAUPUNKT BP480PP 480p Mini Projector Instruction Manual

[Home](#) » [Blaupunkt](#) » BLAUPUNKT BP480PP 480p Mini Projector Instruction Manual 

BLAUPUNKT BP480PP 480p Mini Projector
Instruction Manual



Instruction Manual

480p Mini Projector - BP480PP



Enjoy it.

Contents

- 1 GENERAL SAFETY
- 2 PRODUCT OVERVIEW
- 3 REMOTE CONTROL
- 4 FIRST TIME SETUP
- 5 INSTALLATION
- 6 HOME DASHBOARD
- 7 SETTING – PICTURE
- 8 SETTING – SOUND
- 9 SETTING – OPTION
- 10 SETTING-TIME
- 11 SPECIFICATIONS
- 12 Documents / Resources
- 13 Related Posts

GENERAL SAFETY

Read this manual thoroughly before you start using the Projector.

Store this manual, the completed warranty card, your receipt and the product packaging.

The safety precautions instructions reduces the risk of fire, electric shock and injury when correctly complied to.

Please follow all instructions and take notice of all warnings.

IMPORTANT INFORMATION

- Only using furniture that can safely support the Products.
- Ensure the Product is not overhanging the edge of the supporting furniture.
- Do not place the product on a high furniture without securing both the furniture and the product to a stable support.
- Do not place the product on cloth or other conductive materials.
- Warn children of the dangers of climbing on furniture to reach the projector or its controls and to call for an adult to assist.

IMPORTANT INFORMATION

- Do not expose this appliance to rain or moisture as it may result in fire or an electric shock hazard
- Do not tamper or change or modify the product in any way.
- Only use Accessories outlined and recommended by the manufacturer.
- Please do not expose the product to splashing or water contact
- Please do not place any object on top of the product including objects filled with liquids such as vases.

Installation

Please follow instruction when installing this product in accordance with the instruction manual. This product must be positioned in a sufficiently stable location, it can be potentially hazardous due to falling and can cause injury, particularly to children if it positioned incorrectly.

- Before installing this Projector set, make sure your outlet voltage corresponds to the voltage stated on the product rating label
- Do not use a damaged power cord, plug or loose outlet. Doing so may cause an electric shock.
- Do not plug several devices into the same outlet. Doing so may cause the outlet to overheat and start a fire. Make sure the outlet is readily accessible during operation of the equipment.
- Do not bend, twist or kink the power adaptor excessively.
- Do not allow anything to rest on or roll over the power adaptor.
Doing so may cause a fire or an electric shock.
- Do not run the power adaptor near heat-producing appliances such as radiators, stoves or irons. The excessive heat could melt the insulation and expose live wires, resulting in fire or electric shock.
- Unplug this Projector during lightning storms or when unused for long periods of time.
Not doing so may result in fire or electric shock.
- Do not cover the ventilation openings of the product with items such as newspapers, tablecloths, curtains etc or insert objects into the slots available on the products.
As this could result in the product temperature rising and could cause a fire.
- If you notice any unusual odors or smoke around the unit, immediately disconnect the unit from the outlet and contact the service center. Failure to do so may result in fire or electric shock.
- When not using the unit for long periods of time or when you are moving the unit please ensure to disconnect the power cord from the wall socket.
- Please beware that Dust could accumulate over time on the unit and cause it to generate heat and or deteriorate insulation, which in turn may result in an electrical fire.
- The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or young children of any age, They must be supervised product by a person responsible for their safety.
- Batteries from the remote control must be only removed by an adult, the adult must ensure to keep them out of reach of infants and children. Seek medical attention immediately if a child has swallowed a battery.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- To maintain the product do not use any chemical or cleaning agent or wet cloth, please only ensure to utilize a dry cloth to wipe it down from marks or dust and only after unplugging the product from the power socket.
- Please ensure to contact our call center for any repair or service required for the products.

! CAUTION !

DO NOT look directly into Project LENS. This can cause damage to a persons or children's eyes. Take all nessecary precautions to make sure that no one looks into the LENS while turned on.

MAKE SURE this project is out of reach of children or baby so that they do not stand and look into the project LENS.

DO NOT cover the vents, the vents are needed to let out hot air. Placing objects near or covering the vents can cause the product to overheat and permanantly damage the projector.

Please make sure upon positioning this product, the place is:



- Not wet or damp and Well ventilated
- Away from direct sunlight or heaters.
- Away from splashes or food.
- Protected from excessive dust or grease.
- Do not install this equipment in a confined space such as a bookcase or similar unit.
- Do not install the Projector set near heat sources such as radiators, stoves or other audio visual equipment that produce heat.
- Do not place containers with liquids, if liquid falls inside the products it may result in short-circuit, fire or electric shock.
- Do not place small metallic objects on top of the unit. Metal object falls inside the product it may result in short-circuit, fire or electric shock.
- Do not use or store flammable or combustible materials near the unit. Doing so may result in fire or explosion. Do not place any naked flame sources, such as lit candles, cigarettes or incense sticks on top of the Projector set.
- Install the unit at a reasonable distance from the wall to ensure sufficient ventilation.




HIGH-DEFINITION MULTIMEDIA INTERFACE

“HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.”

PRODUCT OVERVIEW





1. POWER ON/OFF
2. USB Port
3. HDMI Port
4. IR window
5. DC IN Plug
6. Micro SD Port
7. AV IN Port
8. Headphone Port

REMOTE CONTROL

Your projector comes with a Remote Control to access and control your projector from a distance. (Batteries not included).

Power
Press to power ON.
Press twice to power OFF.

◀◀ Previous / Next ▶▶
Press to skip between chapters or tracks.

■ Stop
Press to stop playback.


Flip
Press to flip display image 180°.

▶|| Play/Pause
Press to play or pause an individual chapter or track.

Arrows/OK
Press to navigate and confirm selections in Settings and other menus.

Menu
Press to access projector Settings.

Go To/Number Keypad
Press to enter specific chapter or track numbers. Use Play button to begin playing.



Mute
Press to mute volume.


◀◀ Back / Fwd ▶▶
Press to search through an individual chapter or track.

VOL+ / VOL-
Press to adjust audio level.

Source
Press to select media source (AV, PC, HDMI, MEDIA).

Exit
Press to exit menus.

Zoom
Press to zoom display image in or out.




Using the Remote Control

- Do not mix old and new batteries in the remote
- Do not use different types of battery
- If you do not intend to use the unit for a long time, please remove batteries from the remote to avoid accident.
- Keep batteries away from children and pets.
- Never throw batteries into a fire.
- Do not drop, or impact the remote control as it void warranty immediately.
- The remote control operate at a range of 5 to 6M effectively
- Do not expose the remote control sensor to a bright light.


FIRST TIME SETUP

Make sure to place the projector on a flat and stable surface that is level. So that the projector projects the video/image onto the wall nice and straight.

1. Fix the handle on the unit.




2. Plug in the power adaptor into back of unit (DC IN) and then plug in Adaptor end into wall power socket.



INSTALLATION

DISTANCE BETWEEN PROJECTOR AND SCREEN

Projection Distance	1m	2m	3m
Projection Size	30 inch	68 inch	98 inch
Light, brightness, etc. will affect the projection distance, this data is for reference only.			
Projection Position			
It is recommended to place the projector in front of the center of the screen.			




VIEWING OPTIONS

The projector can be used to project onto a wall or screen, mounted from the ceiling or on a table. When


projecting from a rear position, a special screen will be needed (not included) to display the image. Be sure to aim the remote at the sensor on the front or rear of the projector.




Front Table



Rear Ceiling



Front Ceiling




Rear Ceiling


When installing the projector in the ceiling, please purchase a projector mount recommended by an installation professional and follow the instructions that come with the mount.

Before installing the projector in the ceiling, please check to make sure the ceiling structure can support the weight of the projector and the mount. If in doubt please ask the advise from an installation professional.

NOTE: Projector Mount and Screw(s) are not included.




FIXED HANGER HOLE




ADJUSTING FOCUS

As shown in picture, adjust the lens focus wheel until you get a clear picture.



Swipe to adjust focus

HOME DASHBOARD




This dashboard above appears when you finish turning on your projector.
From here you can select your file types to view depending the device you want to project or other media devices and menu options.

SETTING – PICTURE

To Access the setting **PICTURE** menu:

1. Press the **MENU** button on the Remote Control.
2. With the directional keys, Press the **RIGHT** → arrow button to enter **PICTURE** settings.
3. To navigate back to PICTURE/SOUND/OPTION, with nothing selected, Press **MENU** button.



PICTURE MODE: Standard, Mild, Dynamic, User (contrast, brightness, sharpness, color).


COLOUR TEMP: Adjust between Medium, Cool, Warm.

NOISE REDUCTION: Off, Low, Middle, High.

SETTING – SOUND

To Access the setting **PICTURE** menu:

1. Press the **MENU** button on the Remote Control.
2. With the directional keys, Press the **DOWN** ↓ button, when on **AUDIO**, Press the **RIGHT** → arrow button to enter **SOUND** settings.
3. To navigate back to PICTURE/SOUND/OPTION, with nothing selected, Press **MENU** button.



OSD LANGUAGE: Adjust between Languages English (default)

ASPECT RATIO: Adjust video aspect ratio

PROJECTION MODE: Front, F/Ceiling, Rear, Rear/ceiling

RESET: Press Yes to reset your projector settings and device.

INFO: Display information about the projector

SETTING – OPTION

To Access the setting **OPTION** menu:

1. Press the **MENU** button on the Remote Control.
2. With the directional keys, Press the **DOWN** ↓ button, when on **OPTION**, Press the **RIGHT** → arrow button to enter **OPTION** settings.
3. To navigate back to PICTURE/SOUND/OPTION, with nothing selected, Press **MENU** button.




OSD LANGUAGE: Adjust between Languages: English (default)

RESTORE FACTORY: Press Yes to reset your projector settings and device.

PANEL FLIP ROATATE: Press to flip th screen between Rotate: 0, 1, 2, 3...

SETTING-TIME



Clock: Select clock to Day,Month,Year,Hour and Minutes.

Off Time: Select turn off time to Off, Once, Every day, Hour and Minutes.

On time: Select turn off time to Off, Once, Every day, Hour and Minutes.

Sleep Timer: Select sleep time to Off,10min,20min,30min,60min,90min, 120min.

Auto Sleep: Select auto sleep function to Off,1hour,2hours,4hours,8hours.

SPECIFICATIONS

Resolution	800 x 480 Native Resolution (supports up to 1080p Full HD)	
Projection Size	Up to 98" (inches)	
Lumens	40 ANSI	
Aspect Ratio	16:9, 4:3, AUTO	
Multimedia Playback Format under USB Mode	Movie: AVI / FLV / RMVB / MKV / MP4 / 3GP / MOV / MPG / MPEG / TS / TP / VOB	
	Music: MP3 / WMA / OGG / AAC / FLAC	
	Photo: JPG / PNG / BMP	
Ratings	12VDC 3A	
USB	5V $\overline{\text{---}}$ max. 500mA	
Dimensions	142 (w) × 116 (d) × 99 (h) mm	
Weight	Net: 0.61 kg	
	Gross: 1.1 kg	
Accessories	1 x Instruction Manual	1 x Remote Control
	1 x Power Adaptor	1 x Warranty Card

NOTE: This document is for reference only, the operation interface is subject to software.



CUSTOMER HELPLINE:

info@ayonz.com

DISTRIBUTED BY:

Ayonz Pty Ltd

Documents / Resources

