

**blink**  
home Outdoor  
4 and Sync  
Module 2



## blinkfor home Outdoor 4 and Sync Module 2 Instructions

[Home](#) » [blinkfor home](#) » blinkfor home Outdoor 4 and Sync Module 2 Instructions 

### Contents

- 1 [blink for home Outdoor 4 and Sync Module 2](#)
- 2 [PRODUCT SPECIFICATIONS](#)
- 3 [IMPORTANT PRODUCT INFORMATION](#)
- 4 [Other Safety Considerations](#)
- 5 [Protection Against Water](#)
- 6 [RECYCLING YOUR DEVICE PROPERLY](#)
- 7 [LIMITED WARRANTY](#)
- 8 [Documents / Resources](#)
  - 8.1 [References](#)

**blink**

**blink for home Outdoor 4 and Sync Module 2**



## PRODUCT SPECIFICATIONS

### Outdoor 4

- Model number: BCM05500U
- Electrical rating: 5V 1A
- Battery type: 2 x AA lithium
- Battery voltage: 1.5V
- Operating Temperature Range: -20° C to 45° C

### Sync Module 2

- Model number: BSM05401U
- Electrical rating: 5V 1A
- Battery type: 2 x AA lithium
- Battery voltage: 1.5V
- Operating Temperature Range: 0°C to 35°C

## IMPORTANT PRODUCT INFORMATION

### [Triangle with !] SAFETY INFORMATION

READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THIS SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Your Sync Module 2 is shipped with an AC adaptor A1027-050100U-AU1. Your device should only be powered

using the AC adaptor included with the device. If the adaptor or cable appears damaged, discontinue use immediately. Install your power adaptor into an easily accessible socket outlet located near the equipment that will be plugged into or powered by the adaptor.

Do not expose your Sync Module 2 or adaptor to liquids. If your Sync Module 2 or adaptor gets wet, carefully unplug all cables without getting your hands wet and wait for the Sync Module 2 and adaptor to dry completely before plugging them in again. Do not attempt to dry your Sync Module 2 or adaptor with an external heat source, such as a microwave oven or a hairdryer. If the device or adaptor appears damaged, discontinue use immediately. Use only accessories supplied with the device to power your device. Install your power adaptor into an easily accessible socket outlet located near the equipment that will be plugged into or powered by the adaptor.

### **[TRIANGLE WITH !] BATTERY SAFETY**

The Lithium batteries accompanying this Outdoor 4 cannot be recharged. Do not open, disassemble, bend, deform, puncture, or shred the battery. Do not modify, attempt to insert foreign objects into the battery, or immerse or expose to water or other liquids. Do not expose the battery to fire, explosion, high temperature, or another hazard. Fires involving lithium batteries can usually be controlled with flooding with water, except in confined spaces where a smothering agent should be used.

If dropped and you suspect damage, take steps to prevent any ingestion or direct contact with fluids and any other materials from the battery with skin or clothes. If a battery leaks, remove all batteries and recycle or dispose of them according to the battery manufacturer's recommendations. If fluid or other material from the battery comes into contact with skin or clothes, flush skin or clothes with water immediately. An open battery should never be exposed to water, as fire or explosion may result from exposure to water.

Insert the batteries in the proper direction as indicated by positive (+) and negative (-) markings in the battery compartment. Always replace with non-rechargeable AA 1.5V Lithium batteries (lithium metal batteries) like those provided with and specified for this product. Do not mix used and new batteries or batteries of different types (for example, Lithium and alkaline batteries). Always remove old, weak, or worn-out batteries promptly and recycle or dispose of them by applicable laws and regulations.

### **Other Safety Considerations**

Your Outdoor 4 can withstand outdoor use and contact with water under certain conditions. However, your device is not intended for underwater use and may experience temporary effects from exposure to water. Do not intentionally immerse your device in water. Do not spill any food, oil, lotion, or other abrasive substances on your device. Do not expose your device to pressurized water, high-velocity water, or extremely humid conditions (such as a steam room). Do not expose your device or batteries to salt water or other conductive liquids. To protect against electric shock, do not place a cord, plug, or device in water or other liquids.

If your device gets wet from immersion in water or high-pressure water, carefully disconnect all cables without getting your hands wet and wait for them to dry completely before powering it on again. Do not attempt to dry your device or batteries (if applicable) with an external heat source, such as a microwave oven or a hair dryer. To avoid the risk of electric shock, do not touch your device or batteries or any wires connected to your device during a lightning storm while your device is powered. If your device or batteries appear to be damaged, discontinue use immediately. Protect your device from direct sunlight.

Use only accessories supplied with your device, or specifically marketed for use with your device, to power your device. The use of third-party accessories may impact your device's performance. In limited circumstances, the use of third-party accessories may void your device's limited warranty. In addition, the use of incompatible third-party accessories may cause damage to your device or the third-party accessory. Read all safety instructions for any accessories before using your device. Don't expose your device to steam, extreme heat, or cold. Use your device in a location where temperatures remain within the device's operating temperature range outlined in this guide. Your device may get warm during normal use.

**WARNING:** Small parts contained in your device and its accessories may present a choking hazard to small

children.

**CAUTION:** When mounting this Outdoor 4 in elevated locations, use precautions to ensure that the device does not fall and harm bystanders.

## Protection Against Water

Your Blink Outdoor 4 has been tested to withstand brief accidental immersion in water under certain conditions. To reduce the risk of damage to your device, follow these instructions:

- Do not intentionally immerse your device in water or expose it to seawater, salt water, chlorinated water, or other liquids (such as beverages).
- Do not spill any food, oil, lotion, or abrasive substances on your device.
- Do not expose your device to pressurized water, high-velocity water, or extremely humid conditions (such as a steam room).
- If your device is dropped or otherwise damaged, the waterproofing of the device may be compromised.
- For more information concerning care instructions and the waterproofing of your device, please see [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

## RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your devices with your local laws and regulations. For information about recycling your device, go to [www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

## Additional Safety and Compliance Information

For additional safety, compliance, recycling, and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app or on the Blink website at <https://blinkforhome.com/safety-and-compliance>.

## TERMS AND POLICIES

Before using the Blink device ("Device"), please read the terms and policies for the Device located in your Blink Home Monitor App in About Blink > Legal Notices (collectively, the "Agreement"). By using your Device, you agree to be bound by the Agreement. In the same sections, you can find the Privacy Notice which is not part of the Agreement. BY PURCHASING OR USING THE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS OF THE AGREEMENT.

## LIMITED WARRANTY

If you purchased your Blink devices or accessories (the "Device") from Amazon.com.au or authorized resellers located in Australia or New Zealand, the warranty for the Device is provided by Amazon Commercial Services Pty Ltd, Level 37, Citigroup Tower, 2 Park Street Sydney, NSW 2000. The Provider of this warranty is sometimes referred to herein as "we".

When you purchase a new or Certified Refurbished Device (which, for clarity, excludes Devices sold as "Used" & Used Devices sold as Warehouse Deals), we warrant the Device against defects in materials and workmanship under ordinary consumer use for one year from the date of original retail purchase. During this warranty period, if a defect arises in the Device, and you follow the instructions for returning the Device, we will at our option, to the extent permitted by law, either (i) repair the Device using either new or refurbished parts, (ii) replace the Device with a new or refurbished Device that is equivalent to the Device to be replaced, or (iii) refund to you all or part of the purchase price of the Device.

This limited warranty applies, to the extent permitted by law, to any repair, replacement part, or replacement device for the remainder of the original warranty period or ninety days, whichever period is longer. All replaced parts and Devices for which a refund is given shall become our property. This limited warranty applies only to hardware components of the Device that are not subject to (a) accident, misuse, neglect, fire, alteration, or (b) damage from any third-party repair, third-party parts, or other external causes.

**Instructions.** For specific instructions about how to obtain warranty service for your Device, please contact Blink Support using the contact information provided below in 'Contact Information.' In general, you will need to deliver your Device in either its original packaging or in equally protective packaging to the address specified by Customer Service. Before you deliver your Device for warranty service, it is your responsibility to remove any removable storage media and back up any data, software, or other materials you may have stored or preserved on your Device. Such storage media, data, software, or other materials may be destroyed, lost, or reformatted during service, and we will not be responsible for any such damage or loss.

**Limitations.** TO THE EXTENT PERMITTED BY LAW, THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE INSTEAD OF ALL OTHER WARRANTIES AND REMEDIES, AND WE SPECIFICALLY DISCLAIM ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND AGAINST HIDDEN OR LATENT DEFECTS. IF WE CAN NOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY AND TO REPAIR OR REPLACEMENT SERVICE. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG A STATUTORY OR IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.


WE ARE NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY. IN SOME JURISDICTIONS THE FOREGOING LIMITATION DOES NOT APPLY TO DEATH OR PERSONAL INJURY CLAIMS, OR ANY STATUTORY LIABILITY FOR INTENTIONAL AND GROSSLY NEGLIGENT ACTS AND/OR OMISSIONS, THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.

This limited warranty gives you specific rights. You may have additional rights under applicable law, and this limited warranty does not affect such rights. Contact Information. For help with your Device, please contact Blink Supporting Australia (Toll-Free) 1800 595 447 or New Zealand (Toll Free) 800 780 635.

**FOR AUSTRALIAN CONSUMERS:** Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure, provided repair facilities and parts for the goods are available. Subject to any rights that you may have under the Australian Consumer Law, you may be required to bear the expense of claiming under this limited warranty, including the cost of returning the Device.

**FOR NEW ZEALAND CONSUMERS:** Our goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. You are entitled to a repair, replacement, or refund if the goods we provide to you are not of acceptable quality, are not fit for a particular purpose made known by you the consumer, or represented by us, or do not correspond with what is advertised by us. We do not undertake that repair facilities and parts will be available for our goods. You are also entitled to reject the goods and receive a refund or replacement from us if the failure of the goods to comply with guarantees in the Consumer Guarantees Act cannot be remedied, or if the failure is substantial. In addition, you may be entitled to compensation for reasonably foreseeable loss or damage. The above terms do not apply to goods purchased for commercial use.

## **Documents / Resources**

	<p><b><a href="#">blinkfor home Outdoor 4 and Sync Module 2</a> [pdf] Instructions</b> Outdoor 4, Sync Module 2, Outdoor 4 and Sync Module 2, and Sync Module 2, Sync Module 2, Module 2</p>
--	--

References

- [a Shop online for Electronics, Apparel, Toys, Books, DVDs & more](#)
- [a Amazon Digital Services and Device Support - Amazon Customer Service](#)
- [b Blink Support Contact Information — Blink Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.