

## brother MFC-J5340DW Ink Jet Multi Function Printer User Guide

Home » Brother » brother MFC-J5340DW Ink Jet Multi Function Printer User Guide





#### **Contents**


- 1 brother MFC-J5340DW Ink Jet Multi Function Printer
- 2 Unpack the machine and check the components
- 3 Load plain Letter/A4 paper
- 4 Connect the power cord
- 5 Install the starter ink cartridges
- 6 Set the date and time
- 7 Check the print quality
- 8 Adjust the print alignment (recommended)
- 9 Machine settings
- 10 Connect the telephone line cord
- 11 Select your language
- 12 Select the correct Receive Mode
- 13 Set your Station ID
- 14 Connect your computer or mobile device to your machine
  - 14.1 Follow the on-screen instructions and prompts.
- 15 Manual wireless setup
- 16 Documents / Resources
  - 16.1 References
- 17 Related Posts

brother MFC-J5340DW Ink Jet Multi Function Printer



## Unpack the machine and check the components

Remove the protective tape or film covering the machine and the supplies. The components included in the box may differ depending on your country.



#### **NOTE**

- Most of the machine illustrations in this Quick Setup Guide show the MFC-J5955DW.
- The images in this guide are for illustration purposes only and may differ from the actual products.
- Save all packing materials and the box in case you must ship your machine.
- You must purchase the correct interface cable for the interface you want to use.

#### **USB** cable

Use a USB 2.0 cable (Type A/B) that is no more than 16 feet (5 meters) long.

## Ethernet (Network) cable

Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Manuals in Spanish for this model are available at support.brother.com.


## Load plain Letter/A4 paper

After finishing the machine setup, you can change the paper type or size. For more information about paper handling, see the Online User's Guide at <a href="mailto:support.brother.com/manuals">support.brother.com/manuals</a>.



- Pull the paper tray completely out of the machine as shown by the arrow. Remove the tray top cover.
- · Fan the paper well.
- Load the paper in the tray and adjust the paper guides.
- Put on the tray top cover, and then slowly push the paper tray completely into the machine.
- Pull out the paper support until it locks into place.


## Connect the power cord



## **NOTE**

You can adjust the control panel angle to read the LCD more easily.


## Install the starter ink cartridges



Open the ink cartridge cover.

#### For MFC-J5340DW only:

Remove the orange protective part from the machine. Follow the LCD instructions to store the orange protective part inside the machine. If you must transport the machine, remove the ink cartridges and replace this part.



Follow the LCD instructions to install the ink cartridges. Close the ink cartridge cover. The machine will prepare the ink tube system for printing.

#### **NOTE**


The first time you install the ink cartridges, the machine will use extra ink to fill the ink delivery tubes. This is a one-time process that enables high-quality printing.

#### Set the date and time

Follow the LCD instructions to set the date and time. After setting the date and time, you can set the Brother LCD Message defaults.

## Check the print quality


Follow the LCD instructions, and then press [Start]. The machine prints the Print Quality Check Sheet.



Follow the LCD instructions and check the quality of the four color blocks on the sheet, and then start the cleaning procedure if required.

## Adjust the print alignment (recommended)

To adjust the print alignment before using your machine, press [Start].



- Follow the LCD instructions to print the Adjustment Sheet. The black circle mark is located in the upper right corner of the sheet.
- Place the Adjustment Sheet face down on the scanner glass. Make sure the black circle is in the upper left corner of the scanner glass.
- Follow the LCD instructions and complete adjusting the alignment.
  When finished, remove the Adjustment Sheet from the scanner glass.


## **Machine settings**

Follow the LCD instructions to configure the machine settings.


- Configure the tray settings and check the paper orientation information (not available on all models).
- Check the software installation information.

## Connect the telephone line cord

If you are not using your machine as a fax, go to 10 . For more information on using the fax feature, see the Online User's Guide.



Connect the telephone line cord. Use the jack marked LINE and guide the cord out the back of the machine.



# Close the scanner cover.

## Select your language




2. Press your language.



#### **Select the correct Receive Mode**

If you are not using your machine as a fax, go to 13.



2. Press your preferred Receive Mode.



## **Set your Station ID**

If you are not using your machine as a fax, go to 13. Store your name and fax number so the machine prints it on all outgoing fax pages.



[Settings] > [All Settings] > [Initial Setup] > [Station ID] > [Fax].


- 2. Enter your fax number (up to 20 digits) on the touchscreen and then press [OK].
- 3. Press [Name].
- 4. Enter your name (up to 20 characters) using the touchscreen, and then press [OK].



## Connect your computer or mobile device to your machine

Follow these steps to complete the setup using one of the connection types available on your machine.

Visit <u>setup.brother.com</u> to download and install Brother software.




#### **NOTE**

For Windows only, CD installation is also available (for some countries).

Follow the on-screen instructions and prompts.

#### **NOTE**

For Wired Network Connection and USB Connection, locate the correct port (based on the cable you are using) inside the machine as shown.



#### **Setup Finished**

You can now print and scan using your machine. To check for the latest firmware, visit support.brother.com/up7.

## **Important Notice for Network Security:**

The default password to manage this machine's settings is located on the back of the machine and marked "Pwd". We recommend immediately changing the default password to protect your machine from unauthorized access.


## Can't Connect? Check the following:

- · Wireless network
- Wired network
- USB connection
- Restart your wireless access point/router (if possible).
- · Disconnect the cable.
- Restart your machine and computer, and then go to 13.
- If still not successful, go to 14.
- If still not successful, visit support.brother.com for FAQs and Troubleshooting.

## Manual wireless setup


If the wireless setup is not successful, try to set up the connection manually.

Find your SSID (Network Name) and Network Key (Password) on your wireless access point/router and write them in the table provided below.



Go to your machine, and press






Select the SSID (Network Name) for your access point/router and enter the Network Key (Password). When the wireless setup is successful, the LCD displays [Connected].

If setup is not successful, restart your Brother machine and your wireless access point/router, and repeat 14 . Go to 13 to install software.

For detailed machine information and product specifications, see the Online User's Guide at <a href="mailto:support.brother.com/manuals">support.brother.com/manuals</a>.

#### **Documents / Resources**



brother MFC-J5340DW Ink Jet Multi Function Printer [pdf] User Guide MFC-J5340DW, Ink Jet Multi Function Printer, Function Printer, Printer

#### References

- setup.brother.com | Official Machine setup site | Brother
- United States | Brother support website
- Brother Solutions Center
- Brother Solutions Center
- Brother Solutions Center

Manuals+, home privacy