




canaan Avalon Nano 3 Bitcoin Miner Heater Instructions

[Home](#) » [canaan](#) » canaan Avalon Nano 3 Bitcoin Miner Heater Instructions 

Canaan Avalon Nano 3 Bitcoin Miner




Contents

- 1 Turn On The Power
- 2 Button Usage
- 3 Network Configuration
- 4 FCC Warning
- 5 Documents / Resources
 - 5.1 References
- 6 Related Posts

Turn On The Power

Insert the adapters Type-C connector into the machines power cord socket and connect the power source. The machine will turn on automatically.

Button Usage



When the Logo faces up, there are two buttons on the right side of the screen. The upper one is the Power button, and the lower is the Switch button.

- a. Click the Power button to switch the light strip effect, including stay, breathing, and flashing.
- b. Press and hold the Power button for 3 seconds to turn it off.
- c. In the off state, turn on the power and press the Power button for 3 seconds to turn the machine on.
- d. Click the Switch button to change the display content on the screen.

e. Double-click the Switch button to change the airspeed mode, including low, medium, and high modes.

f. Press and hold the Switch button for 3 seconds to enter the network configuration docking mode.

Network Configuration

a. After entering the network configuration docking mode, use the Avalon Remote App and click the “+” in the upper right corner to discover new devices.

b. Click the Search button in Discover New Devices, find the Avalon Nano 3 you want to connect to, and click it.

c. After the connection is successful, select the 2.4GHz wireless network you want the Avalon Nano 3 to join and enter the wireless network password to let the machine obtain the network connection.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Documents / Resources



- User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.