



Carson Monopix Monocular + Smartphone Adapter User Guide Manual

[Home](#) » [Carson](#) » Carson Monopix Monocular + Smartphone Adapter User Guide Manual 


User Guide



Instructions for Use



Optic Side



Inserting Phone

Fig.1



Rotate to unlock top clamp.

Fig.2



Slide top clamp into uppermost position.

Fig.3



Insert phone into left clamp.

Inserting Phone (cont.)

Fig.4




Squeeze and pull right clamp past edge of phone.

Fig.5



Release right clamp to secure phone.


Fig.6



Ensure phone is flat as possible to adapter.


Align & Lock

Fig.7




Slide phone vertically until camera is roughly aligned with camera cutout.

Fig.8



Turn alignment screw until camera is centered in camera cutout.

Fig.9



Slide top clamp down against phone edge.

Align & Lock (cont.)

While holding top clamp tight to phone, rotate to lock.

Fig.10





Fig.11 shows a properly aligned camera. If needed, use alignment screw and top clamp to make further adjustments.

Fig.11



MULTIPLE-LENS CAMERA PHONE:

If there is more than one rear-facing camera, use the primary one. Typically, the primary is a 1x wide-angle color camera, and the other camera(s) are secondary.

- For Apple dual camera phones, the primary camera is the one closest to the corner. Use photo or video mode only.
- For Android, the primary camera can be determined by which does not show an image in your app while blocking the individual camera.

For the latest instructions


on multiple camera phones, please visit:

www.carson.com/multicam.

Attaching to Optic

Align optic adapter over eyepiece and press down firmly. Be careful not to move your camera out of alignment.

Fig.12



Phone can be positioned in either portrait or landscape mode.

Fig.13



Attaching to Optic (cont.)

Fig.14



Ensure that optic adapter is flush to the eyepiece of your monocular.

Fig.15



Turn on camera. If image is not centered, repeat alignment steps (Fig. 7-11).


Fig.16



To maximize your image, pinch to enlarge image. For best results, use in video mode.


Using Monocular Without Adapter

Fig.17



If desired, attach wrist strap by screwing bolt on end of strap into the threaded socket of monocular.

Fig.18



For eyeglass wearers, eyecup should be in innermost position. If you do not wear eyeglasses, you may choose to twist eyecup out to block stray light and reflections from your view.

Fig.19



Focus monocular by turning center focus knob until viewing image is sharp.

TO REMOVE PHONE FROM ADAPTER:

To save your alignment, make no further adjustments to the top clamp and alignment knob. Simply remove phone using right clamp only as shown in Fig.4.

USING ADAPTER AGAIN:

The alignment of your phone to the adapter should be saved from the initial setup, so many steps can be skipped (Fig.1–2, 7–11) and only a quick fine adjustment of the alignment may be needed.

Frequently Asked Questions:

Q: Why does the top clamp touch the round corner of my phone, instead of the top flat edge?


A1: This is normal for some models of phones. Just fit as close to rounded edge as possible and lock top clamp as normal.

Q2: Why am I getting reflections and/or glare in my image?

A2: This may occur with indoor lighting. Please avoid overhead lighting or change the angle of the lighting relative to phone. Also, please use without flash to avoid reflections and/or glare in photos. If there's glare on your phone screen that makes image hard to view, increase brightness setting on phone and view from a position with less overhead light.

Q3: I can't align my phone vertically with the top clamp; it won't fit. What should I do?

A3: If you go through the alignment process (Fig.7–11), and there is no way to achieve vertical alignment because it's restricted by the top clamp, try removing your phone case.



Alternatively, you can remove top clamp assembly using screw as shown above. For this configuration, you will not be able to save your vertical alignment between uses. Your phone will have to be adjusted for vertical positioning each time it's placed within the adapter.

We recommend you save these four parts for use with other phones, and you can reassemble the top clamp as shown above in right figure.

Q4: How do I know which phones will work with the adapter?


A4: Please see the smartphone sizing guide below.

SMARTPHONE SIZING GUIDE

SMARTPHONE SIZING GUIDE If your phone (in its case) fits in "portrait" orientation between the 2 arrows, it will fit the smartphone monocular adapter.

Q5: My phone rotates on the eyepiece when used in landscape (horizontal) mode. What should I do? A5: To correct, rotate the monocular eyepiece clockwise to its innermost position. Q6: My other phone camera or flash is covered by adapter. Why is that?

A6: First, we recommend using the device with only the primary rear camera. If problems persist, please contact customer support. Second, the flash can be covered, and is not needed for use with optic. We recommend flash setting is turned off at all times when using adapter.



Q7: My image doesn't appear to be centered or is not a complete round image; what's wrong?

A7: The phone alignment needs to be adjusted in vertical direction using top clamp (Fig.7) and in horizontal direction by using alignment screw (Fig.8). Check that phone is flat on adapter (Fig.6), and adapter is flush with optic (Fig.14).

Tips & Tricks:

PHOTOGRAPHY

- Tap object of interest on your phone screen to autofocus. •For videos, tap and hold object of interest on phone screen for a second to lock focus. Tap again to release the focus lock.
- In low light conditions, turn your phone screen brightness to its lowest level. •For long sessions, try using battery cases or phone chargers to prevent your battery from draining.

APPS

- Share photos and videos through various apps (e.g. FaceTime, Messages, Facebook, Instagram, etc.)

STABILIZATION

- To prevent shaking while capturing photos, attach headphones to smartphone and use the volume buttons to activate shutter.
- Attach monocular to a tripod to prevent external vibrations from shaking image.
- Many phones have image stabilization features. Check your phone and turn on this feature if available. If not, there are camera apps with stabilization features.

Storage/Cleaning Information:

- For longest life of springs/plastic, store in dry area at room temperature.
 - Adapter should be cleaned with soft, damp cloth only. Do not use any chemicals or abrasives.
 - Cleaning must be done safely and carefully to avoid scratching the lenses and permanently damaging your monocular. Safe cleaning can be accomplished by following the procedure below:
1. Blow away any dust or debris on the lens (or use a soft lens brush).
 2. To remove dirt, grease or fingerprints, clean with a soft cotton cloth, rubbing in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage.
 3. .For a more thorough cleaning, photographic type lens cleaning fluid may be used. Always apply the fluid to the cleaning cloth, never directly on the lens.
 4. .IMPORTANT: Never attempt to clean your monocular internally or try to take it apart.

Customer Service:

We will be happy to help you with any problems you may experience with your MonoPix™ Monocular with Smartphone Adapter Kit. Email us at info@carson.com or call toll-free at 1-800-967-8427.

Monocular with Smartphone Adapter Kit [Manual Optimized](#)

Monocular with Smartphone Adapter Kit [Manual Original](#)