


## Cinnado D1 Smart WiFi Battery Camera User Manual




### Guarding Your Home Security

#### 1. Product Appearance



1. Lens
2. Spotlight
3. Indicator Light
4. Infrared Light
5. Microphone
6. PIR Sensor




1. SD Card Slot
2. Reset Button
3. USB-C Port
4. Speaker
5. Bracket Interface
6. Bracket Interface
7. Power on/off

### Download and install the APP

The wireless smart camera is powered by a built-in battery and supports both Android and iOS. Scan the QR code below or search 'UBox' in the App Store to download the app.





Follow the prompts to register your account.

If you've used this app before, please update it to the latest version.

## **Preparation for Connection**

1. Insert the Micro SD card while the camera is off (optional, SD card not included).
2. The camera only supports 2.4GHz Wi-Fi, not 5GHz.
3. Place the camera close to the router during setup
4. Turn on the camera.




## **Connect Camera to App**

1. Switch the camera on. It will show a red light for 3 seconds, then blink blue once, followed by continuous blue flashing.




(**Note:** If not connected for a long time, the blue light will keep flashing this is normal.)


2. Press and hold the reset button for 5 seconds. You will hear “System reset” and “The camera is now ready to begin pairing,” and the blue light will flash. (Note: After deleting the device, reset the camera before adding it again.)
3. Open the App Add the camera by selecting the ‘+’ sign or ‘Add a Device.’



4. If Bluetooth is off, a pop-up will ask you to enable it. Please turn it on.



5. Select 'Setup WiFi Device.' Listen for the voice prompt and check the camera's blue indicator light. If it's flashing, tap "YES" in the app. If not, reset the camera.





6. Name your device and click 'Next.' If your phone is connected to 2.4GHz Wi-Fi, it will automatically detect the network. Then click 'Configuring Devices.'



**(Note:** This device only supports 2.4GHz Wi-Fi. If setup fails, verify your network is on 2.4GHz.)

7. Align the QR code on your phone with the camera lens at about 10 cm. When you hear “Pairing information received,” then wait for 10secs, the app will display a prompt indicating that the camera has been successfully connected.




If you encounter pairing difficulties, simply reset the camera and try pairing again. This should resolve the issue Repeat the steps mentioned in (2) to reset.

When installing the app, please enable all requested notifications, including Bluetooth and location, or the camera may miss motion detection alerts.

## Install the camera

1. Select a suitable position for your camera. Ensure the camera is not obstructed and within Wi-Fi coverage (Wi-Fi signal should be greater than 75%).




## Install the bracket:

**Step 1:** Choose a clean, smooth, and dry surface (avoid uneven wood, leather, or stucco walls).

**Step 2:** Align the bracket screw with the camera's screw hole and tighten.


**Step 3:** Adjust the camera to the desired angle.



## Adjust the angle:


The camera can rotate 360° horizontally and 105° vertically, allowing adjustments as needed. (Adjust the camera to a suitable angle, ideally about 15 degrees downward. Then, rotate the base clockwise to secure the angle.)

About 15° downward




## How to share

1. Tap the share icon on the main page, then click “Share” on the sharing page.




2. Enter the recipient's phone number or email (used for app registration), then click “Next.”





3. Choose the recipient's permissions—different roles have different access, or you can set custom permissions. After step 3, your device will be successfully shared with family or friends.



**(Note:** The recipient must close and reopen UBox to see the sharing prompt.)

## Indicator light statues

Mode	Statues
Working	Working

Sleep	Off
Charging	Green(beside the R button)

The app will remind you to charge the camera when the battery is low. Use the Type-C cable with a 5V/2A adapter. You can check if the camera is fully charged through the app.

### Note tips

1. A camera can be bound to only one device, but a device can be linked to multiple cameras. You can share access and set viewing permissions for others.
2. Avoid pointing the camera at bright light sources, such as sunlight or bright lamps.
3. Keep the camera away from outlets, air conditioner vents, humidifier outlets, and projector heat vents.
4. Do not install the camera in areas with strong winds.
5. Do not aim the camera at a mirror. Maintain at least 1 meter of distance from wireless devices, including Wi-Fi routers and phones, to prevent interference.
6. **Warning:** Do not charge the camera in environments below zero degrees. It is recommended to keep the camera indoors for half an hour before charging. please charge the camera with a 5V power adapter before use

### Questions & Answers

## Contents [ [hide](#) ]

- 1 Q: Why does the camera battery drain quickly?
- 2 Q: Why can't I connect to Wi-Fi?
- 3 Q: Why does it still appear in the list of devices after resetting?
- 4 Q: How do I connect the camera to another router?
- 5 Q: Why doesn't the device recognize the SD card?
- 6 Q: Why can't I receive notifications on my cell phone app?
- 7 Q: Why doesn't the WiFi name appear when I try to connect?
- 7.1 Documents / Resources
  - 7.1.1 References

---

### Q: Why does the camera battery drain quickly?

1.The longer the camera operates, the faster the battery drains. To conserve battery, consider reducing the sensitivity of motion detection and limiting the duration of two-way calls and live viewing. 2.If you receive too many alarm notifications, lower the sensitivity from 'High' to 'Low.' 3.Adjust the camera's installation angle to avoid unnecessary alarms that consume battery. For instance, don't point the camera at a shimmering swimming pool, swaying trees, or heavy traffic. 4.Battery drains faster in cold environments.

---

### Q: Why can't I connect to Wi-Fi?

A:1.Ensure the mobile device is connected to a 2.4GHz network. 2.Verify that the current location has good Wi-Fi coverage and a stable connection (Wi-Fi signal should be greater than 75%). 3.Avoid using Wi-Fi extenders. 4.Check if the Wi-Fi password is entered correctly

---

### Q: Why does it still appear in the list of devices after resetting?

A: The reset only restores the network configuration of the camera and does not change the configuration in the app. To remove the camera, you must delete it from the app.

---

**Q: How do I connect the camera to another router?**

A: First, remove and reset the device in the app, and then configure the device again using the app.

---

**Q: Why doesn't the device recognize the SD card?**

A: It is recommended to insert the SD card after power is cut. Please confirm that the SD card is functioning properly and formatted as FAT32. Additionally, the TF card may not be recognized in poor internet conditions.

---

**Q: Why can't I receive notifications on my cell phone app?**

A: Please ensure that the app is running on your phone and that the relevant notification functions are enabled. Additionally, check that message notifications and permissions are enabled in your phone's system settings.

---

**Q: Why doesn't the WiFi name appear when I try to connect?**

A: On Apple devices running iOS 13 or above, you need to enable the app's 'location permission' in the system settings and set it to 'allow while using'.

**FCC Statement**

<

p>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

<

/ol>

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

**more of the following measures:**

<

ol>

3. Reorient or relocate the receiving antenna.
4. Increase the separation between the equipment and receiver.
5. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

<

li>Consult the dealer or an experienced radio/TV technician for help.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### **IC Caution:**

**English:**

<

p>This device complies with Innovation, Science and Economic Development Canada  
licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.


<

/ol>

To maintain compliance with RSS-102 RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

**French:**

## Documents / Resources

	<a href="#">Cinnado D1 Smart WiFi Battery Camera [pdf]</a> User Manual D1, 2A9GG-D1, 2A9GGD1, D1 Smart WiFi Battery Camera, D1, Smart WiFi Battery Camera, Battery Camera, Camera
---	--

## References

- [User Manual](#)

■ Cinnado

◆ 2A9GG-D1, 2A9GGD1, Battery Camera, camera, Cinnado, D1, D1 Smart WiFi Battery Camera, Smart WiFi Battery Camera

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.