



# CLEVERIO Door Sensor 51113 Manual

[Home](#) » [Cleverio](#) » CLEVERIO Door Sensor 51113 Manual

## Contents [ [hide](#) ]

- 1 CLEVERIO
- 2 Door Sensor
  - 2.1 SKU: 51113
  - 2.2 Quickstart
  - 2.3 Important safety information
  - 2.4 What is Z-Wave?
  - 2.5 Product Description
  - 2.6 Prepare for Installation / Reset
    - 2.6.1 Reset to factory default
  - 2.7 Inclusion/Exclusion
    - 2.7.1 Inclusion
    - 2.7.2 Exclusion
  - 2.8 Quick trouble shooting
  - 2.9 Association – one device controls an other device
    - 2.9.1 Association Groups:
  - 2.10 Technical Data
  - 2.11 Supported Command Classes
  - 2.12 Explanation of Z-Wave specific terms
  - 2.13 Related Posts

---

CLEVERIO

---

## Door Sensor

SKU: 51113



This is a

Alarm Sensor  
for  
**CEPT (Europe).**

Please make sure the internal battery is fully charged.

To add this device to your network execute the following action:

– Press a Func\_Button 3 time in the Door Sensor, Green LED is Blinking 3 times within 1 second.- If Inclusion Process is successful, Green led will turn off.

Please refer to the  
[Manufacturers Manual](#) for more information.

## Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

## What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to [www.z-wave.info](http://www.z-wave.info).

## Product Description

This smart door sensor is consists of sensor part and magnet part. It can sense the open and close state of the door and windows, once there is unexpected intruder, it will send alarm information to the user APP. It has mini stylish design, easy installation and long lifespan.

## Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

### Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

– Long press Func\_Button while installing batteries in HS1DS-Z – Device Reset Locally notification is Transmitted- Please use this procedure only when the network primary controller is missing or otherwise inoperable.

### Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

#### Inclusion

– Press a Func\_Button 3 time in the Door Sensor, Green LED is Blinking 3 times within 1 second.- If Inclusion Process is successful, Green led will turn off.

#### Exclusion

-Press a Func\_Button 3 times quickly.-If Exclusion Process is successful, Green led is Blinking 6 times, then turn off.

### Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

### Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always

related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

## Association Groups:

Group NumberMaximum NodesDescription

1	5	Association group 1: Lifeline association groupInclude command classe: Battery report, Notification report, and Device Reset Locally notification, Binary report.
2	5	Association group 2: Root Device group(Binary Sensor)Binary Sensor Command Class:Compatible with 300 series1-Binary Sensor reports status of open or close door via Lifeline.2- When the sensor detects status change between close door and open door, the device will be triggered.
3	5	Association group 3: Root Device group(Binary Sensor)Binary Sensor Command Class:Compatible with 300 series1-Binary Sensor reports the removed status of door sensor.2-When the sensor detects status change of tamper, the device will be triggered.
4	5	Association group 4: Root Device group(Notification)1-Notification report open door or close status via Lifeline.2- When the sensor detects status change between close door and open door, the device will be triggered.
5	5	Association group 5: Root Device group(Notification)1-Binary Sensor reports the removed status of door sensor.2- When the sensor detects status change of tamper, the device will be triggered.

## Technical Data

Hardware Platform	ZM5202
Device Type	Notification Sensor
Network Operation	Reporting Sleeping Slave
Firmware Version	HW: 255 FW: 1.37
Z-Wave Version	6.51.06
Certification ID	ZC10-19056494
Z-Wave Product Id	0x041C.0x0168.0x0168
Color	White
Supported Notification Types	Smoke Alarm
Frequency	XXfrequency
Maximum transmission power	XXantenna

## Supported Command Classes

- Association Grp Info
- Association V2
- Battery
- Device Reset Locally
- Manufacturer Specific V2
- Notification V4

- Powerlevel
- Sensor Binary V2
- Version V2
- Wake Up V2
- Zwaveplus Info V2

## Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.  
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.  
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.