



# CP PLUS CP-E51AR Ezykam Wi-Fi Camera User Guide

[Home](#) » [CP PLUS](#) » CP PLUS CP-E51AR Ezykam Wi-Fi Camera User Guide 

## Contents

- [1 CP PLUS CP-E51AR Ezykam Wi-Fi Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 What's in the Box](#)
- [5 Add Camera](#)
- [6 Frequently Asked Questions](#)
- [7 Technical Specifications](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



## CP PLUS CP-E51AR Ezykam Wi-Fi Camera



## **Product Information**

### **Specifications:**

- Storage: Supports up to 128GB Micro SD Card (not included)
- Wi-Fi: IEEE802.11b/g/n, 2.4GHz (not compatible with 5GHz Wi-Fi networks)

### **Quick Operation Guide:**

To start using your new ezykam Wi-Fi Camera, follow these steps:

1. Download the ezykam+ app from the App Store or Google Play.
2. Register an account on your ezykam+ app.
3. Plug in the power adapter for the camera.
4. Wait for the indicator light on the device to turn to a steady blue light, indicating a network connection.

Note: Make sure you read the instruction manual carefully before using the product.

## **Product Usage Instructions**

### **Add Camera**

To add a camera to your ezykam+ app, follow these steps:

1. Open the ezykam+ app and click on "Add Camera".
2. Follow the on-screen instructions and click "Continue".
3. Wait for the voice prompt, and when you hear the beep, click on "Heard the beep".

### **Share Camera with Family and Friends**

You can share your cameras with family and friends who will have access to view the camera. Follow these steps:

1. Open the ezykam+ app.
2. Go to the camera settings.
3. Select the option to share the camera.
4. Enter the email addresses or usernames of the people you want to share the camera with.

### **Wireless Range**

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router manufacturer or refer to the exact range data for your specific router model.

## **Troubleshooting**

### **The camera appears offline or unreachable**

If the camera appears offline or unreachable, follow these steps:

1. Make sure you entered the correct Wi-Fi password during the Wi-Fi setup.
2. Check whether there is any Internet connection problem.
3. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

### **Cannot connect to your Wi-Fi network**

If you cannot connect to your Wi-Fi network, follow these steps:

1. Make sure you entered the correct Wi-Fi password during the Wi-Fi setup.
2. Check whether there are any Internet connection problems.
3. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

### **FAQ**

#### **1. Can I share camera with family and friends?**

Yes, you can share your cameras with family and friends who will have access to view the camera.

#### **2. What's the Wireless Range?**

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router manufacturer or refer to the exact range data for your specific router model.

#### **3. How many cameras can I control?**


You can control cameras in an unlimited amount of locations. However, please note that your router may have a limit on how many cameras can be connected to it.

Thank you for choosing CP PLUS ezykam+. Get started using your new devices by downloading ezykam+ app, one convenient app that manages everything straight from your smart phone. Easily connect to your home Wi-Fi and control multiple devices from the touch of your fingertips

## What's in the Box



ezykam Wi-Fi Camera



USB Cable



Power Adapter



Quick Operation  
Guide

## Get Ready

- Know your Wi-Fi network and password.
- Make sure your mobile device is running iOS® 9.0 or higher or Android™ 8.0 or higher.
- Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect to 5GHz networks)

1. Download the ezykam+ app from App Store or on Google Play.



Google, Google Play and Google Home are trademarks of Google LLC. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

2. Register an account on your ezykam+ app.

- **STEP 1.**

- Select the country.
- Enter the email address.



- **STEP 2.**
  - Enter the verification code and create a password



3. Plug in


#### **How do I reset my camera?**

- Use the reset pin to press the Reset Button for several seconds until the camera starts to beep.
  - Optional: Insert Micro SD card



## Add Camera

- Open ezykam+ app, click "+" on the top right corner of the "HOME" page, then select "Specific model to add".
- Make sure that the Red LED indicator is blinking and voice prompt is audible.



- Enter your "Wi-Fi network and password", click "CONFIRM".

< Add Camera

## Enter Wi-Fi Password

**Supports 2.4GHz Wi-Fi Network Only.**

- Connect your mobile with your Wi-Fi network & ensure internet is working
- Once the mobile gets connected to the Wi-Fi, then SSID will automatically reflect
- Enter the SSID password

Aditya infotech ultra [Change Network](#)

\*\*\*\*\* [Forgot](#)

CONFIRM

- Read the instructions about “Scan the camera QR code” and click “Continue”.
- Scan the QR Code on your phone with a camera. Heard a voice prompt, click “Heard the beep”

< Add Camera

### Scan The Camera QR Code

Once you tap continue, mobile phone will display a QR code. Hold the mobile phone in front of camera approx 15~20 cm away, as shown in below picture.



15 cm to 20cm

CONTINUE

< Add Camera

### QR Code

Once the process is completed, you will hear voice prompt.




If no voice prompt, click here

HEARD THE BEEP

- When the indicator light on the device turns to a steady blue light, the network configuration is complete.
- Please refer to the specific APP interface if there are any differences.





## Frequently Asked Questions

- **Can I share the camera with family and friends?**
  - Yes, you can share your cameras with family and friends who will have access to view the camera.
- **What's the Wireless Range?**
  - The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.
- **The camera appears offline or unreachable?**
  - Make sure you enter the correct Wi-Fi password during the Wi-Fi setup. Check whether there is any Internet connection problem. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.
- **Cannot connect to your Wi-Fi network.**
  - Make sure you enter the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again
- **How many cameras can I control?**
  - CP Plus app can control unlimited number of cameras in unlimited amount of locations. Your router may have a limit of how many cameras can be connected to one router.

## Voice control works with Alexa or Google Assistant

- You can control your camera using just your voice with Alexa or Google Assistant-enabled devices.



### System Requirements

- Smartphone running iOS® 9.0 or higher or Android™ 8.0 or higher
- Existing Wi-Fi Network with internet connection

### Technical Specifications

- **Resolution:**
  - CP-E51AR= 2880×1620@20fps, H.265 encoding
  - CP-E81AR= 3840×2160@20fps, H.265 encoding
- **Field of view :** E51AR = 91.3°(D), 49°(H), 108.7°(V)
  - E81AR = 91.3°(D), 49° (H), 108.7°(V)
- **Audio:** Internal Speaker and Microphone
- **Storage:** supports up to 128GB Micro SD Card (not included)
- **Wi-Fi:** IEEE802.11b/g/n, 2.4GHz (not compatible with 5GHz Wi-Fi networks)

For further assistance, you can reach us via [ezycare@cpplusworld.com](mailto:ezycare@cpplusworld.com) Please read the instructions carefully before using the product

---

### Documents / Resources

	<p><b><a href="#">CP PLUS CP-E51AR Ezykam Wi-Fi Camera</a></b> [pdf] User Guide CP-E51AR, CP-E81AR, CP-E51AR Ezykam Wi-Fi Camera, CP-E51AR, Ezykam Wi-Fi Camera, Wi-Fi Camera, Camera</p>
--	---

### References

- [User Manual](#)