



Danfoss SonoMeter 40 Wired M-Bus Protocol Description Instruction Manual

[Home](#) » [Danfoss](#) » Danfoss SonoMeter 40 Wired M-Bus Protocol Description Instruction Manual 

Contents

- [1 Danfoss SonoMeter 40 Wired M-Bus Protocol Description](#)
- [2 General structure of protocol](#)
- [3 Selection of the data type](#)
- [4 Data request](#)
 - [4.1 CRC16 checksum calculation algorithm](#)
- [5 Settings the parameters of meter](#)
- [6 Secondary addressing](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



Danfoss SonoMeter 40 Wired M-Bus Protocol Description



General structure of protocol

General features of protocol

- Meter uses an M-bus protocol.
- Default baud rate: 2400 bps, Even, 1 Stop.
- The Baud rate can be changed.
- The protocol is the same for the Mbus interface and for the optical interface.
- The primary address of Mbus is individual for the Mbus interface and for the optical interface.

Data strings

Data string to meter SND_NKE:

1	2	3	4	5
10h	40h	A	CS	16h

- **A** – M-bus primary address of meter
- **CS** – control sum (the youngest byte of amount of 2-nd and 3-rd bytes)

Data string to meter SND_UD2

1	2	3	4	5	6	7	8...n-2	n-1	n
68h	L	L	68h	53h 73h	A	51h	Data bytes	CS	16h

- L – length of string (the number of bytes from 5-th to n-2 byte)
- A – M-bus primary address of meter
- CS – control sum (the youngest byte of the amount of 5-th to n-2 bytes)

Data string to meter REQ_UD2:

1	2	3	4	5
10h	5Bh 7Bh	A	CS	16h

- A – M-bus primary address of the meter
- CS – control sum (the youngest byte of the amount of 2-nd and 3-rd bytes)

The answer of the meter CON:

- E5h

Answer of the meter RSP_UD2:

1	2	3	4	5	6	7	8... 11	12, 1 3	14	15	16	17	18,19
68h	L	L	68h	C	A	CI	ID	Man	Vrs	Md	TC	St	Sign

20	...	...	...	...	...	... n-2	n-1	n
DIF	VIF	Data		DIF	VIF	Data	CS	16h

- L – length of string (the number of bytes from 5-th to n-2 byte)
- C – „C field“ (08)
- A – M-bus primary address of the meter
- CI – „CI field“
- ID – identification number of a meter (BSD8, used for secondary addressing, can be changed – see paragraph 4.1),
- Man – Manufacturer code (Danfoss A/S manufacturer code is „DFS“, 10 D3)
- Vrs – number of protocol versions (0Bh)
- Md – code of medium (for „heat / cold energy“: 0Dh)
- TC – counter of telegrams
- St – meter status code
- Sign – 00 00
- The bytes 20...n-2 is data from the meter:
 - DIF – code of data format
 - VIF – code of data units
 - Data– values of data
- CS – control sum (the youngest byte of the amount of 5-th to n-2 bytes).

Selection of the data type

Master sends to the meter telegram SND_UD2:

68h	03h	03h	68h	53h 73h	A	50h	CS	16h
-----	-----	-----	-----	---------	---	-----	----	-----

Selection of the data type “All data”

68h	04h	04h	68h	53h 73h	A	50h	00h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “User data”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	10h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Simple billing” (Years logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	20h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Enhanced billing” (Days logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	30h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Multi tariff billing” (Months logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	40h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Instantaneous values”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	50h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Load management values for management” (Hours logger)

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	60h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Selection of the data type “Installation and startup”

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	80h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Master sends to the meter telegram SND_UD2:

68h	04h	04h	68h	53h 73h	A	50h	90h	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	----	-----

Selection of the data type “Testing”

Answer of the meter CON (if A not equal FFh):

- E5h

The parameter list for preselecting

If not satisfied with Default parameter lists (presented in tables 1 ... 9). Obtain the desired parameter list presented in Table 11th.

(Paragraph 2.1 ... 2.9) Additionally it is needed to send the parameter selecting telegram SND_UD2:

68h	L	L	68h	53h 7 3h	A	51h	SEL1	SEL2	...	SELN	CS	16h
-----	---	---	-----	-------------	---	-----	------	------	-----	------	----	-----

- **SEL** selecting parameter code from the table of 11 (made out of sequence as many codes as you want to select of the parameters).

Note: It may be selected as many parameters but the Response telegram length can not exceed 250 bytes

Answer of the meter CON (if A not equal FFh):

- E5h

Data request

Master sends to the meter telegram SND_UD2:

10h	53h 73h	A	CS	16h
-----	---------	---	----	-----

Data request

In all cases, except A = FFh, meter response RSP_UD2 telegram with selected data (tables 1 ...9) If no data record, the answer of meter is CON:

- E5h

Application reset sub-codes and storages: All data (CI = 50 or CI = 50 00)

Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec

5	Working time without error	04 24	32 bit integer	sec
6	Energy for heating	(04 86 3B) (04 8E 3B) (04 FB 8 D 3B)	32 bit integer	(kWh), (MJ), (Mcal).
7	Energy for cooling *	(04 86 3C) (04 8E 3C) (04 FB 8 D 3C)	32 bit integer	(kWh), (MJ), (Mcal).
8	Energy of tariff 1 *	(84 10 86 3x) (84 10 8E 3x) (84 10 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
9	Energy of tariff 2 *	(84 20 86 3x) (84 20 8E 3x) (84 20 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
10	Volume	04 13	32 bit integer	0,001 m3
11	Volume of pulse input 1 *	84 40 13	32 bit integer	0,001 m3
12	Volume of pulse input 2 *	84 80 40 13	32 bit integer	0,001 m3
13	Power	04 2B	32 bit integer	W
14	Flow rate	04 3B	32 bit integer	0,001m3/h
15	Temperature 1	02 59	16 bit integer	0,01°C

16	Temperature 2	02 5D	16 bit integer	0,01°C
17	Temperature difference	02 61	16 bit integer	0,01K
18	Serial number	0C 78	32bit BCD8	
19	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling.

Meter data coding

Application reset sub-codes and storages: User data (CI = 50 10)

Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	
4	Battery operation time	04 20	32 bit integer	sec
5	Volume of pulse input 1 *	84 40 13	32 bit integer	0,001 m3
6	Volume of pulse input 2 *	84 80 40 13	32 bit integer	0,001 m3
7	Pulse value of input 1 *	02 93 28	16 bit integer	0,001 m3
8	Pulse value of input 2 *	02 93 29	16 bit integer	0,001 m3
9	Pulse value of output 1 *	02 93 2A	16 bit integer	0,001 m3
10	Pulse value of output 2 *	02 93 2B	16 bit integer	0,001 m3
11	Software version	01 FD 0E	8 bit integer	–
12	Yearly set day	42 EC 7E	Type G	–
13	Monthly set day	82 08 EC 7E	Type G	–
14	Meter type	0D FD 0B	88 bit string	–
15	Serial number	0C 78	32bit BCD8	–
16	CRC	02 7F	16 bit integer	CRC16

Application reset sub-codes and storages: Simple billing (Years logger) (CI = 50 20)

Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	44 6D	32 bit integer	Type F
2	Logger working time without error	44 24	32 bit integer	sec
3	Logger energy for heating	(44 86 3B) (44 8E 3B) (44 FB 8 D 3B)	32 bit integer	(kWh), (MJ), (Mcal).
4	Logger energy for cooling *	(44 86 3C) (44 8E 3C) (44 FB 8 D 3C)	32 bit integer	(kWh), (MJ), (Mcal).
5	Logger energy of tariff 1 *	(C4 10 86 3x) (C4 10 8E 3x) (C4 10 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
6	Logger energy of tariff 2 *	(C4 20 86 3x) (C4 20 8E 3x) (C4 20 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
7	Logger volume	44 13	32 bit integer	0,001 m3
8	Logger volume of pulse input 1 *	C4 40 13	32 bit integer	0,001 m3
9	Logger volume of pulse input 2 *	C4 80 40 13	32 bit integer	0,001 m3
10	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling

Default list

#	Parameter	DIF VIF	Type	Units
#	Parameter	DIF VIF	Type	Units
1	Logger date and time	84 08 6D	32 bit integer	Type F
2	Average temperature 1	82 08 59	16 bit integer	0,01°C
3	Average temperature 2	82 08 5D	16 bit integer	0,01°C
4	Logger working time without error	84 08 24	32 bit integer	sec
5	Logger energy for heating	(84 08 86 3B) (84 08 8E 3B) (84 08 FB 8D 3B)	32 bit integer	(kWh), (MJ), (Mcal).
6	Logger energy for cooling *	(84 08 86 3C) (84 08 8E 3C) (84 08 FB 8D 3C)	32 bit integer	(kWh), (MJ), (Mcal).
7	Logger energy of tariff 1 *	(84 18 86 3x) (84 18 8E 3x) (84 18 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).

8	Logger energy of tariff 2 *	(84 28 86 3x) (84 28 8E 3x) (84 28 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
9	Logger volume	84 08 13	32 bit integer	0,001 m3
10	Logger volume of pulse input 1 *	84 48 13	32 bit integer	0,001 m3
11	Logger volume of pulse input 2 *	84 88 40 13	32 bit integer	0,001 m3
12	Logger duration when q > qmax	84 08 BB 58	32 bit integer	sec
13	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling.

Application reset sub-codes and storages: Multi tariff billing (Months logger) (CI = 50 40)

Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	84 08 6D	32 bit integer	Type F
2	Average temperature 1	82 08 59	16 bit integer	0,01°C
3	Average temperature 2	82 08 5D	16 bit integer	0,01°C
4	Logger working time without error	84 08 24	32 bit integer	sec

5	Logger energy for heating	(84 08 86 3B) (84 08 8E 3B) (84 08 FB 8D 3B)	32 bit integer	kWh (MJ) (Mcal)
6	Logger energy for cooling *	(84 08 86 3C) (84 08 8E 3C) (84 08 FB 8D 3C)	32 bit integer	kWh (MJ) (Mcal)
7	Logger energy of tariff 1 *	(84 18 86 3x) (84 18 8E 3x) (84 18 FB 8D 3x)	32 bit integer	kWh (MJ) (Mcal)
8	Logger energy of tariff 2 *	(84 28 86 3x) (84 28 8E 3x) (84 28 FB 8D 3x)	32 bit integer	kWh (MJ) (Mcal)
9	Logger volume	84 08 13	32 bit integer	0,001 m3
10	Logger volume of pulse input 1 *	84 48 13	32 bit integer	0,001 m3
11	Logger volume of pulse input 2 *	84 88 40 13	32 bit integer	0,001 m3
12	Logger duration when $q > q_{max}$	84 08 BE 58	32 bit integer	sec
13	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling

Remark

If meter is specially configured, in table 5 listed monthly parameters data is transmitted and in accordance after inquiry ("All data" table 1) data transmission.

Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	–
4	Battery operation time	04 20	32 bit integer	sec
5	Working time without error	04 24	32 bit integer	sec
6	Energy for heating	(04 86 3B) (04 8E 3B) (04 FB 8 D 3B)	32 bit integer	(kWh), (MJ), (Mcal).
7	Energy for cooling *	(04 86 3C) (04 8E 3C) (04 FB 8 D 3C)	32 bit integer	(kWh), (MJ), (Mcal).
8	Energy of tariff 1 *	(84 10 86 3x) (84 10 8E 3x) (84 10 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).

9	Energy of tariff 2 *	(84 20 86 3x) (84 20 8E 3x) (84 20 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
10	Volume	04 13	32 bit integer	0,001 m3
11	Volume of pulse input 1 *	84 40 13	32 bit integer	0,001 m3
12	Volume of pulse input 2 *	84 80 40 13	32 bit integer	0,001 m3
13	Power	04 2B	32 bit integer	W
14	Flow rate	04 3B	32 bit integer	0,001m3/h
15	Temperature 1	02 59	16 bit integer	0,01°C
16	Temperature 2	02 5D	16 bit integer	0,01°C
17	Temperature difference	02 61	16 bit integer	0,01K
18	Meter type	0D FD 0B	88 bit string	–
19	Serial number	0C 78	32bit BCD8	–
20	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling

Application reset sub-codes and storages: Load management values for management (Hours logger) (CI = 50 60)

Default list

#	Parameter	DIF VIF	Type	Units
1	Logger date and time	C4 86 03 6D	32 bit integer	Type F
2	Average power	C4 86 03 2B	32 bit integer	W
3	Average flow	C4 86 03 3B	32 bit integer	0,001 m3/h
4	Average temperature 1	C2 86 03 59	16 bit integer	0,01 °C
5	Average temperature 2	C2 86 03 5D	16 bit integer	0,01 °C
6	Logger min flow	E4 86 03 3B	32 bit integer	0,001 m3/h
7	Logger max flow	D4 86 03 3B	32 bit integer	0,001 m3/h
8	Logger min temperature difference	E2 86 03 61	16 bit integer	0,01 K
9	Logger max temperature difference	D2 86 03 61	16 bit integer	0,01 K
10	Logger error code	F4 86 03 FD 17	32 bit integer	–
11	Logger working time without error	C4 86 03 24	32 bit integer	sec

12	Logger energy for heating	(C4 86 03 86 3B) (C4 86 03 8E 3B) (C4 86 03 FB 8D 3B)	32 bit integer	(kWh), (MJ), (Mcal).
13	Logger energy for cooling *	(C4 86 03 86 3C) (C4 86 03 8E 3C) (C4 86 03 FB 8D 3C)	32 bit integer	(kWh), (MJ), (Mcal).
14	Logger energy of tariff 1 *	(C4 96 03 86 3x) (C4 96 03 8E 3x) (C4 96 03 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
15	Logger energy of tariff 2 *	(C4 A6 03 86 3x) (C4 A6 03 8E 3x) (C4 A6 03 FB 8D 3x)	32 bit integer	(kWh), (MJ), (Mcal).
16	Logger volume	C4 86 03 13	32 bit integer	0,001 m3
17	Logger volume of pulse input 1 *	C4 C6 03 13	32 bit integer	0,001 m3
18	Logger volume of pulse input 2 *	C4 86 43 13	32 bit integer	0,001 m3
19	Logger duration when q > qmax	C4 86 03 BE 58	32 bit integer	sec
20	CRC	02 7F	16 bit integer	CRC16

x = B – for energy for heating, x = C – for energy for cooling

Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	–
4	Battery operation time	04 20	32 bit integer	sec
5	Working time without error	04 24	32 bit integer	sec
6	Test mode status	01 FF 03	8 bit integer	–
7	Device mode status	01 FF 04	8 bit integer	–
8	Software version	01 FD 0E	8 bit integer	–
9	Yearly set day	42 EC 7E	Type G	–
10	Monthly set day	82 08 EC 7E	Type G	–
11	Meter type	0D FD 0B	88 bit string	–
12	Serial number	0C 78	32bit BCD8	–
13	CRC	02 7F	16 bit integer	CRC16

Default list

#	Parameter	DIF VIF	Type	Units
1	Date and time	04 6D	32 bit integer	Type F
2	Date and time of error starting	34 6D	32 bit integer	Type F
3	Error code	34 FD 17	32 bit integer	–
4	Battery operation time	04 20	32 bit integer	sec
5	Flow rate	04 3B	32 bit integer	0,001 m3/h
6	Temperature 1	02 59	16 bit integer	0,01 °C
7	Temperature 2	02 5D	16 bit integer	0,01 °C
8	Temperature difference	02 61	16 bit integer	0,01 K
9	Pulse value of energy test output	02 FF 01	16 bit integer	–
10	Pulse value of volume test output	02 FF 02	16 bit integer	–
11	Test mode status	01 FF 03	8 bit integer	–
12	Device mode status	01 FF 04	8 bit integer	–
13	Volume high resolution	04 01	32 bit integer	mWh

14	Energy high resolution	04 10	32 bit integer	ml
15	Device configuration	01 FF 09	8 bit integer	–
16	Software version	01 FD 0E	8 bit integer	–
17	Device type	0D FD 0B	88 bit string	–
18	Seial number	0C 78	32bit BCD8	–
19	CRC	02 7F	16 bit integer	CRC16

Error code encryption

Byte N	Bite N	if bite = 1	LCD indication code “ERROR xxxx”
0	0	–	–
	1	–	–
	2	Hardware status flag Er02	8000
	3	Hardware status flag Er03	8000
	4	End of battery live time	1000
	5	Hardware status flag Er05	0008

	6	–	–
	7	–	–
1	0	–	–
	1	–	–
	2	Flow sensor is empty	0001
	3	Flow flows in a reverse direction	0002
	4	Flow rate less q_i	–
	5	–	–
	6	–	–
	7	–	–
	0	Temperature sensor 1 error or short circuit	0080
	1	Temperature sensor 1 disconnected	0080
	2	Temperature 1 < 0°C	00C0
	3	Temperature 1 > 180°C	0080
	4	Temperature sensor2 error or short circuit	0800

2	5	Temperature sensor 2 disconnected	0800
	6	Temperature 2 < 0°C	0C00
	7	Temperature 2 > 180°C	0800
3	0	Hardware status flag Er30	0880
	1	–	–
	2	Temperature difference < 3°C	4000
	3	Temperature difference > 150°C	2000
	4	Flow rate greater 1,2qs	0004
	5	Hardware status flag Er35	8000
	6	–	–
	7	Hardware status flag Er37	8000

Parameters list for preselecting

#	Parameter	SEL	DIF VIF	Type	Units

			CI = 50 Instantaneous	CI = 50 60 Hours logger	CI = 50 30 Days logger	CI = 50 40 Months logger	CI = 50 20 Years logger		
1	Date and time stamp	C8 FF 7 F 6D	04 6D	C4 86 03 6 D	84 08 6D	84 08 6D	44 6D	32 bit integer	Type F
2	Working time without error	C8 FF 7 F 24	04 24	C4 86 03 2 4	84 08 24	84 08 24	44 24	32 bit integer	sec
3	Error code	F8 FF 7 F FD 17	34 FD 17	F4 86 03 F D 17	B4 08 FD 17	B4 08 FD 17	74 FD 17	32 bit integer	–
4	Date and time of error starting	F8 FF 7 F 6D	34 6D	–	–	–	–	32 bit integer	Type F
5	Energy for heating	C8 0F F E 3B (C 8 0F FE FE 3B for „Mcal“)	(04 86 3B) (04 8E 3 B) (04 FB 8D 3B)	(C4 86 03 86 3B) (C4 86 03 8E 3B) (C4 86 03 FB 8D 3B)	(84 08 86 3B) (84 08 8E 3B) (84 08 F B 8D 3B)	(84 08 86 3B) (84 08 8E 3B) (84 08 F B 8D 3B)	(44 86 3B) (44 8E 3 B) (44 FB 8D 3B)	32 bit integer	kWh (MJ) (Mcal)
6	Energy for cooling *	C7 0F F E 3C (C 8 0F FE FE 3C for „Mcal“)	(04 86 3 C) (04 8E 3 C) (04 F B 8D 3C)	(C4 86 03 86 3C) (C4 86 03 8E 3C) (C4 86 03 FB 8D 3C)	(84 08 86 3C) (84 08 8E 3C) (84 08 F B 8D 3C)	(84 08 86 3C) (84 08 8E 3C) (84 08 F B 8D 3C)	(44 86 3C) (44 8E 3 C) (44 FB 8D 3C)	32 bit integer	kWh (MJ) (Mcal)
7	Volume	C8 FF 7 F 13	04 13	C4 86 03 1 3	84 08 13	84 08 13	44 13	32 bit integer	0,001 m3

8	Energy of tariff 1 *	C8 1F 7 E	(84 10 86 3x) (84 10 8E 3x) (84 10 F B 8D 3x)	(C4 96 03 86 3x) (C4 96 03 8E 3x) (C4 96 03 FB 8D 3x)	(84 18 86 3x) (84 18 8E 3x) (84 18 F B 8D 3x)	(84 18 86 3x) (84 18 8E 3x) (84 18 F B 8D 3x)	(C4 10 86 3x) (C4 10 8E 3x) (C4 10 FB 8D 3x)	32 bit integer	kWh (MJ) (Mcal)
9	Energy of tariff 2 *	C8 BF 7 F 7E	(84 20 86 3x) (84 20 8E 3x) (84 20 F B 8D 3x)	(C4 A6 03 86 3x) (C4 A6 03 8E 3x) (C4 A6 03 FB 8D 3x)	(84 28 86 3x) (84 28 8E 3x) (84 28 F B 8D 3x)	(84 28 86 3x) (84 28 8E 3x) (84 28 F B 8D 3x)	(C4 20 86 3x) (C4 20 8E 3x) (C4 20 FB 8D 3x)	32 bit integer	kWh (MJ) (Mcal)
10	Volume of pulse input 1 *	C8 FF 3 F 7B	84 40 13	C4 C6 03 13	84 48 13	84 48 13	C4 40 13	32 bit integer	0,001 m3
11	Volume of pulse input 2 *	C8 BF 7 F 7B	84 80 40 13	C4 86 43 13	84 88 40 13	84 88 40 13	C4 80 40 13	32 bit integer	0,001 m3
12	Average power	C8 FF 7 F 2B	04 2B	C4 86 03 2B	84 08 2B	84 08 2B	44 2B	32 bit integer	W
13	Average Flow rate	C8 FF 7 F 3B	04 3B	C4 86 03 3B	84 08 3B	84 08 3B	44 3B	32 bit integer	0,001 m3/h
14	Average Temperature 1	C8 FF 7 F 59	02 59	C2 86 03 59	82 08 59	82 08 59	42 59	16 bit integer	0,01 °C
15	Average Temperature 2	C8 FF 7 F 5D	02 5D	C2 86 03 5D	82 08 5D	82 08 5D	42 5D	16 bit integer	0,01 °C

1 6	Average Temperature difference	C8 FF 7 F 61	02 61	C2 86 03 6 1	82 08 61	82 08 61	42 61	16 bit integer	0,01 K
1 7	Min Power	E8 FF 7 F 2B	–	E4 86 03 2 B	A4 08 2B	A4 08 2B	64 2B	32 bit integer	W
1 8	Min Power date	E8 FF 7 F AB 6D	–	E4 86 03 A B 6D	A4 08 AB 6D	A4 08 AB 6D	64 AB 6D	32 bit integer	Type F
1 9	Max Power	D8 FF 7 F 2B	–	D4 86 03 2 B	94 08 2B	94 08 2B	54 2B	32 bit integer	W
2 0	Max Power date	D8 FF 7 F AB 6D	–	D4 86 03 A B 6D	94 08 AB 6D	94 08 AB 6D	54 AB 6D	32 bit integer	Type F
2 1	Min Flow rate	E8 FF 7 F 3B	–	E4 86 03 3 B	A4 08 3B	A4 08 3B	64 3B	32 bit integer	0,001 m3/h
2 2	Min Flow rate Date	E8 FF 7 F BB 6D	–	E4 86 03 B B 6D	A4 08 BB 6D	A4 08 BB 6D	64 BB 6D	32 bit integer	Type F
2 3	Max Flow rate	D8 FF 7 F 3B	–	D4 86 03 3 B	94 08 3B	94 08 3B	54 3B	32 bit integer	0,001 m3/h
2 4	Max Flow rate Date	D8 FF 7 F BB 6D	–	D4 86 03 B B 6D	94 08 BB 6D	94 08 BB 6D	54 BB 6D	32 bit integer	Type F
2 5	Min Temperature 1	E8 FF 7 F DB 59	–	E2 86 03 5 9	A2 08 59	A4 08 59	62 59	16 bit integer	0,01 °C
2 6	Min Temperature 1 Date	E8 FF 7 F D9 6D	–	E4 86 03 D 9 6D	A4 08 D9 6D	A4 08 D9 6D	64 D9 6D	32 bit integer	Type F

2 7	Max Temperature 1	D8 FF 7 F 59	—	D2 86 03 5 9	92 08 59	92 08 59	52 59	16 bit integer	0,01° C
2 8	Max Temperature 1 Date	D8 FF 7 F D9 6D	—	D4 86 03 D 9 6D	94 08 D9 6D	94 08 D9 6D	54 D9 6D	32 bit integer	Type F
2 9	Min temperature 2	E8 FF 7 F 5D	—	E2 86 03 5 D	A2 08 5D	A2 08 5D	62 5D	16 bit integer	0,01° C
3 0	Min Temperature 2 Date	E8 FF 7 F DD 6D	—	E4 86 03 D D 6D	A4 08 DD 6D	A4 08 DD 6D	64 DD 6 D	32 bit integer	Type F
3 1	Max Temperature 2	D8 FF 7 F 5D	—	D2 86 03 5 D	92 08 5D	92 08 5D	52 5D	16 bit integer	0,01° C
3 2	Max Temperature 2 Date	D8 FF 7 F DD 6D	—	D4 86 03 D D 6D	94 08 DD 6D	94 08 DD 6D	54 DD 6 D	32 bit integer	Type F
3 3	Min Temperature difference	E8 FF 7 F 61	—	E2 86 03 6 1	A2 08 61	A2 08 61	62 61	16 bit integer	0,01K
3 4	Min Temperature difference Date	E8 FF 7 F E1 6D	—	E4 86 03 E 1 6D	A4 08 E1 6D	A4 08 E1 6D	64 E1 6D	32 bit integer	Type F
3 5	Max Temperature difference	D8 FF 7 F 61	—	D2 86 03 6 1	92 08 61	92 08 61	52 61	16 bit integer	0,01K
3 6	Max Temperature difference Date	D8 FF 7 F E1 6D	—	D4 86 03 E 1 6D	94 08 E1 6D	94 08 E1 6D	54 E1 6D	32 bit integer	Type F
3 7	Duration when q < qmin	C8 FF 7 F BE 50	04 BE 50	C4 86 03 B E 50	84 08 BE 50	84 08 BE 50	44 BE 50	32 bit integer	sec

3 8	Flow min level qmin	C8 FF 7 F BE 40	05 BE 40	–	–	–	–	float	1 m3/ h
3 9	Duration when q > qmax	C8 FF 7 F BE 58	04 BE 58	C4 86 03 B E 58	84 08 BE 58	84 08 BE 58	44 BE 58	32 bit in teger	sec
4 0	Flow max level qmax	C8 FF 7 F BE 48	05 BE 48	–	–	–	–	float	1 m3/ h
4 1	Battery operation time	C8 FF 7 F 20	04 20	–	–	–	–	32 bit in teger	sec
4 2	Energy high res olution	C8 FF 7 F 01	04 01	–	–	–	–	32 bit in teger	
4 3	Volume high re solution	C8 FF 7 F 10	04 10	–	–	–	–	32 bit in teger	

x = B – for energy for heating, x = C – for energy for cooling.

Remarks:

1. Table 1...11 energy and volume DIF VIF codes are provided of comma position for 0,001 MWh, 0,001 GJ, 0,001 Gcal, and 0,001 m3. Other values can be set for energy and volume.
2. Table 1...11 parameters marked “*”, will be transmitted only if the conditions are kept:

Parameter	Condition
Energy for cooling . Logger energy for cooling	Heat meter application type – for measurement of energy consumed for heating and cooling
Energy of tariff 1. Logger energy of tariff 1	Tariff 1 function is On
Energy of tariff 2, Logger energy of tariff 2	Tariff 2 function is On
Volume of pulse input 1, Logger pulse input 1	Pulse input 1 is active
Volume of pulse input 2, Logger pulse input 2	Pulse input 2 is active
Pulse value of output 1	Pulse output 1 is active
Pulse value of output 2	Pulse output 2 is active

CRC16 checksum calculation algorithm

- The polynomial $x^0 + x^5 + x^{12}$.
- `const __u16 crc_ccitt_table[256] = {`
 - 0x0000, 0x1189, 0x2312, 0x329b, 0x4624, 0x57ad, 0x6536, 0x74bf,
 - 0x8c48, 0x9dc1, 0xaf5a, 0xbed3, 0xca6c, 0xdbe5, 0xe97e, 0xf8f7, 0x1081, 0x0108, 0x3393, 0x221a,
 - 0x56a5, 0x472c, 0x75b7, 0x643e, 0x9cc9, 0x8d40, 0xbfdb, 0xae52, 0xdaed, 0xcb64, 0xf9ff,
 - 0xe876, 0x2102, 0x308b, 0x0210, 0x1399, 0x6726, 0x76af, 0x4434, 0x55bd, 0xad4a, 0xbcc3, 0x8e58,
 - 0x9fd1, 0xeb6e, 0xfae7, 0xc87c, 0xd9f5, 0x3183, 0x200a, 0x1291, 0x0318, 0x77a7, 0x662e,
 - 0x54b5, 0x453c, 0xbdcb, 0xac42, 0x9ed9, 0x8f50, 0xfbef, 0xea66, 0xd8fd, 0xc974, 0x4204, 0x538d,
 - 0x6116, 0x709f, 0x0420, 0x15a9, 0x2732, 0x36bb, 0xce4c, 0xdfc5, 0xed5e, 0xfcd7, 0x8868,
 - 0x99e1, 0xab7a, 0xbaf3, 0x5285, 0x430c, 0x7197, 0x601e, 0x14a1, 0x0528, 0x37b3, 0x263a, 0xdecd,
 - 0xcf44, 0xfddf, 0xec56, 0x98e9, 0x8960, 0xbbfb, 0xaa72, 0x6306, 0x728f, 0x4014, 0x519d,
 - 0x2522, 0x34ab, 0x0630, 0x17b9, 0xef4e, 0xfec7, 0xcc5c, 0xdd5, 0xa96a, 0xb8e3, 0x8a78, 0x9bf1,
 - 0x7387, 0x620e, 0x5095, 0x411c, 0x35a3, 0x242a, 0x16b1, 0x0738, 0xffcf, 0xee46, 0xdcdd,
 - 0xcd54, 0xb9eb, 0xa862, 0x9af9, 0x8b70, 0x8408, 0x9581, 0xa71a, 0xb693, 0xc22c, 0xd3a5, 0xe13e,
 - 0xf0b7, 0x0840, 0x19c9, 0x2b52, 0x3adb, 0x4e64, 0x5fed, 0x6d76, 0x7cff, 0x9489, 0x8500,
 - 0xb79b, 0xa612, 0xd2ad, 0xc324, 0xf1bf, 0xe036, 0x18c1, 0x0948, 0x3bd3, 0x2a5a, 0x5ee5, 0x4f6c,
 - 0x7df7, 0x6c7e, 0xa50a, 0xb483, 0x8618, 0x9791, 0xe32e, 0xf2a7, 0xc03c, 0xd1b5, 0x2942,
 - 0x38cb, 0x0a50, 0x1bd9, 0x6f66, 0x7eef, 0x4c74, 0x5dfd, 0xb58b, 0xa402, 0x9699, 0x8710, 0xf3af,
 - 0xe226, 0xd0bd, 0xc134, 0x39c3, 0x284a, 0x1ad1, 0x0b58, 0x7fe7, 0x6e6e, 0x5cf5, 0x4d7c,
 - 0xc60c, 0xd785, 0xe51e, 0xf497, 0x8028, 0x91a1, 0xa33a, 0xb2b3, 0x4a44, 0x5bcd, 0x6956, 0x78df,
 - 0x0c60, 0x1de9, 0x2f72, 0x3efb, 0xd68d, 0xc704, 0xf59f, 0xe416, 0x90a9, 0x8120, 0xb3bb,
 - 0xa232, 0x5ac5, 0x4b4c, 0x79d7, 0x685e, 0x1ce1, 0x0d68, 0x3ff3, 0x2e7a, 0xe70e, 0xf687, 0xc41c,
 - 0xd595, 0xa12a, 0xb0a3, 0x8238, 0x93b1, 0x6b46, 0x7acf, 0x4854, 0x59dd, 0x2d62, 0x3ceb,
 - 0x0e70, 0x1ff9, 0xf78f, 0xe606, 0xd49d, 0xc514, 0xb1ab, 0xa022, 0x92b9, 0x8330, 0x7bc7, 0x6a4e,
 - 0x58d5, 0x495c, 0x3de3, 0x2c6a, 0x1ef1, 0x0f78.
- `crc_ccitt` – recompute the CRC for the data buffer

- @crc – previous CRC value
- @buffer – data pointer
- @len – number of bytes in the buffer
- u16 crc_ccitt(__u16 crc, __u8 const *buffer, size_t len){ while (len--)
- crc = (crc >> 8) ^ crc_ccitt_table[(crc ^ (*buffer++)) & 0xff]; return crc;

Settings the parameters of meter

Master sends to the meter string SND_UD2 with new identification number „ID“ (BCD8 format):

68h	09h	09h	68h	53h 73h	A	51h	0Ch	79h	ID	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	-----	----	----	-----

Changing the identification number

Answer of the meter CON (if A not equal FFh):

- E5h

Changing the identification number, Manufacturer ID and Medium

Master sends to the meter string SND_UD2 with new Complete ID (64 bit integer):

68h	0Dh	0Dh	68h	53h 73h	A	51h	07h	79h	Complete ID (64 bit)	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	-----	----------------------	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Structure of “Complete ID” (64 bit integer):

Identification number „ID“	Manufacturer ID	Generation	Medium
4 byte (BCD8 format)	2 byte	1 byte	1 byte

Remark: Generation code is ignored (In meter Generation code is fixed 0Bh)

Changing the primary address

Master sends to the meter string SND_UD2 with new primary address „aa“:

68h	06h	06h	68h	53h 73h	A	51h	01h	7Ah	aa	CS	16h
-----	-----	-----	-----	---------	---	-----	-----	-----	----	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Changing the data and time of the meter

Master sends to the meter string SND_UD2 with new primary address „aa“:

68h	09h	09h	68h	53h 7 3h	A	51h	04h	6Dh	Dat and time (Type F)	CS	16h
-----	-----	-----	-----	-------------	---	-----	-----	-----	-----------------------	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Changing the yearly set day

Master sends to the meter string SND_UD2 with new set data:

68h	08h	08h	68h	53h 7 3h	A	51h	42h	ECh	7Eh	Month and day (Type G)	CS	16h
-----	-----	-----	-----	-------------	---	-----	-----	-----	-----	------------------------	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Changing the monthly set day

Master sends to the meter string SND_UD2 with new set data:

68h	09h	09h	68h	53h 7 3h	A	51h	82h	08h	ECh	7Eh	Day (Type G)	CS	16h
-----	-----	-----	-----	-------------	---	-----	-----	-----	-----	-----	--------------	----	-----

Answer of the meter CON (if A not equal FFh):

- E5h

Remark: Changing the identification number and the set date is possible only when meter is set to SERVICE mode.

Changing the baud rate

Master sends to the meter string SND_UD2 with new baud rate code „BR“:

68h	03h	03h	68h	53h 73h	A	BR	CS	16h
-----	-----	-----	-----	---------	---	----	----	-----

Answer of the meter CON (if A not equal FFh) with old baud rate:

- E5h

Values of BR code:

- BR=B8h – for changing boud rate to 300 bps
- BR=B9h – for changing boud rate to 600 bps
- BR=BAh – for changing boud rate to 1200 bps
- BR=BBh – for changing boud rate to 2400 bps
- BR=BCh – for changing boud rate to 4800 bps
- BR=BDh – for changing boud rate to 9600 bps

Secondary addressing

Master sends to the meter string SND_UD2:

68h	0Bh	0Bh	68h	53h 73h	FD	52	NN	NN	NN	NN	HH	HH	ID	MM	CS	16h
-----	-----	-----	-----	------------	----	----	----	----	----	----	----	----	----	----	----	-----

Selecting of the meter

- NN – Identification number (secondary adress) BCD8 format (if „F“- this number ignored)
- HH – Manufacturer code, HST format (if „FF“- this byte ignored)
- ID – Identification code, HST format (if „FF“- ignored)
- MM – Medium code, SMED format (if „FF“- ignored)

The meter, whose identification number is the same, is selected for further communication and sends an answer CON:

- E5h

Communication with selected meter

Communication with selected meter carried out as usual:

- the data type for reading is selected by sending to meter strig SND_UD2 (see paragraph 2), only in this case, the M-bus address must be FDh,
- the answer of the selected meter CON:
 - E5h

for data request master sends to the meter string (M-bus address must be FDh):

10h	53h 73h	FDh	CS	16h
-----	---------	-----	----	-----

- meter response RSP_UD2 telegram with selected data (tables 1 ...9)

Deselection of secondary addressing mode

Master sends to the meter telegram SND_NKE with adress FDh:

10h	40h	FDh	CS	16h
-----	-----	-----	----	-----

Danfoss A/S

Climate Solutions danfoss.com +45 7488 2222.

Any information, including, but not limited to information on the selection of the product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogs descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative and is only binding to and to the

Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to the form, fit, or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

Documents / Resources

	Danfoss SonoMeter 40 Wired M-Bus Protocol Description [pdf] Instruction Manual SonoMeter 40 Wired M-Bus Protocol Description, SonoMeter 40, Wired M-Bus Protocol Description, Wired Protocol, M-Bus Protocol, Protocol Description
--	---