



Dash Mini Waffle Bowl Maker DMWBM100 User Manual

[Home](#) » [Dash](#) » Dash Mini Waffle Bowl Maker DMWBM100 User Manual 

Contents

- [1 Dash Mini Waffle Bowl Maker DMWBM100 User Manual](#)
- [2 IMPORTANT SAFEGUARDS](#)
- [3 Parts & Features](#)
- [4 Using Your Mini Waffle Bowl Maker](#)
- [5 CLEANING & MAINTENANCE](#)
- [6 RECIPE GUIDE](#)
- [7 CLASSIC WAFFLE BOWL](#)
- [8 SNICKERDOODLE WAFFLE BOWL](#)
- [9 CHOCOLATE WAFFLE BOWL](#)
- [10 EGG & CHEESE HASH BROWN WAFFLE BOWL](#)
- [11 Cheddar Cornbread WAFFLE BOWL](#)
- [12 FALAFEL WAFFLE BOWL](#)
- [13 Zucchini Parmesan Waffle Bowl](#)
- [14 Customer Support](#)
- [15 Warranty](#)
- [16 TECHNICAL SPECIFICATIONS](#)
- [17 Download](#)
- [18 Related Posts](#)

Dash Mini Waffle Bowl Maker DMWBM100 User Manual



[[Download Recipe Guide PDF](#)]

IMPORTANT SAFEGUARDS

PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

When using electrical appliances, basic safety precautions should be followed, including:

- Read all instructions.
- Remove all bags and packaging from appliance before use.
- Never leave appliance unattended when in use.
- Make sure the appliance is cleaned thoroughly before using.
- Do not use appliance for other than its intended use. For household use only. Do not use outdoors.
- Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure they do not play with the appliance.
- Do not operate this appliance with a damaged cord, damaged plug, after the appliance malfunctions, is dropped, or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- Do not touch the Cover of the appliance while in use, as it is very hot. Ensure that the appliance is cool before handling or touching the Cover. Unlock the Cover by using the Latch at the front of the appliance.
- Always attach plug to appliance first, then plug cord in the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- The Dash Mini Waffle Bowl Maker is NOT dishwasher safe. Ensure that you follow the directions in Cleaning & Maintenance to clean the appliance.
- Ensure that there is enough space surrounding the appliance while in use, as the appliance becomes very hot.
- For maintenance other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 7AM-7PM PT Monday-Friday or by email at support@storebound.com.

- Do not place appliance on or near a hot gas burner, hot electric burner, or in a heated oven.
- Refrain from using attachments, including external timers, that are not recommended by the appliance manufacturer, as this may result in fire, electric shock, or personal injury.
- Do not let the cord touch hot surfaces, or hang over the edges of tables or counters.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge unless they are provided with supervision and instruction concerning use of the appliance by a person responsible for their safety.
- Always be sure to unplug the appliance from the outlet prior to moving, cleaning, storage, and when not in use.
- StoreBound shall not accept liability for damages caused by improper use of the appliance.
- Improper use of the appliance can result in property damage or even in personal injury.
- To protect against electric shock do not immerse cord, plugs or the appliance in water or other liquid, extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- A short power supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. An extension cord may be used if care is exercised in its use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounding 3-wire cord. The extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.
- This appliance has a polarized plug (one blade is wider= than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Parts & Features





Using Your Mini Waffle Bowl Maker

1. Place the Mini Waffle Bowl Maker on a stable surface (photo A).



Plug in the appliance. The Heating Light will turn on to signal that the appliance is heating up (photo B).



When the Heating Light turns off, this means that the temperatures of both Cooking Surfaces are sufficiently ready for cooking. The preheating is complete.

During the cooking process, the heating element will automatically turn on and off to regulate the temperature and ensure that the Cooking Surface does not get too hot or cold. When this occurs, the Indicator Light turns on and off.

2. While the appliance is preheating, prepare your waffle recipe. You can also prepare the recipe ahead of time, as the appliance preheats quickly.

3. Open the Cover of the Mini Waffle Bowl Maker by squeezing the Latch at the front of the appliance (photo C).



WARNING: Be sure NOT to grab the Mini Waffle Bowl Maker from the top or sides, as it will be hot. Open by using the Cover Handle only.

4. Pour 3 tbsp of batter into the Lower Cooking Surface of the appliance. The recommended amount of batter for each waffle bowl is about 3 tbsp to 1/4 cup. Ensure that you do not add too much batter, as the waffle bowl will expand while cooking and may overflow if excess batter is used. Gently close the Cover (photo D).



ATTENTION: The Mini Waffle Bowl Maker will get very hot during use.
DO NOT touch the Cover of the appliance during preheating and throughout the cooking process.

5. Allow the waffle bowl to cook for about 3-5 minutes. Open the Cover to test the doneness. When the surface of the waffle bowl is golden brown and the Cover lifts easily, the waffle bowl is complete (photo E). You may adjust your cooking time according to how crispy or tender you would like your waffle bowl. The longer the waffle bowl cooks, the crispier it will be.



6. Remove your waffle bowl by using silicone or nylon tongs or spatula (photo F). The waffle bowl will be hot!



7. Place the finished waffle bowl on a paper towel and allow it to cool before adding fillings and/or toppings (photo E).



If you are using your appliance to prepare another waffle bowl, repeat the cooking instructions.

If you are finished using your Mini Waffle Bowl Maker, unplug the appliance and allow it to cool before cleaning and transporting.

CLEANING & MAINTENANCE

- Before cleaning your Mini Waffle Bowl Maker, if you have recently used the appliance, unplug it and allow it to cool completely.
- Once cool, use a paper towel or a damp cloth to gently wipe down the inside of the Mini Waffle Bowl Maker. The Upper and Lower Cooking Surfaces of the appliance are nonstick, simply wipe them clean and dry thoroughly.
- DO NOT use metal tools to clean the appliance. This will damage the nonstick coating.
- DO NOT submerge your appliance in water or other liquids. Wipe down the outside of the Mini Waffle Bowl Maker with a damp cloth and dry thoroughly.

RECIPE GUIDE

Waffle Bowl-appetit! Make delicious waffle bowls from our recipe section, from chocolate waffle bowls to hash brown waffle breakfast bowls!



CLASSIC WAFFLE BOWL

Ingredients:

1½ cups all-purpose flour
1 cups granulated sugar
2 tsp baking powder
1 tsp kosher salt
4 large eggs

½ cups whole milk
6 tbsp unsalted butter, melted
1 tsp vanilla extract

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

In a large bowl combine the flour, sugar, baking powder and salt and whisk to combine. In a separate small bowl whisk the eggs and stir in the milk, melted butter and vanilla extract. Pour the wet ingredients into the dry and whisk until blended.

Ladle 3 tbsp of batter into the preheated Mini Waffle Bowl Maker and cook until the waffle bowl is golden brown and crisp.



PUMPKIN WAFFLE BOWL

Ingredients:

2 cups all purpose flour
2 tsp baking powder
3 tbsp pumpkin pie spice
¼ cup sugar
2 tbsp light or dark brown sugar
¼ tsp kosher salt
4 large eggs
½ cup whole milk
1½ cup canned pumpkin
¾ cup unsalted butter
1 tsp vanilla extract

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

Melt butter on a small pan over low heat. Shut off heat so butter is not hot when added to the mix. Mix together the dry ingredients and set aside. Add eggs into a bowl and beat with a whisk. Add milk, pumpkin, butter and vanilla, mix to incorporate. Add dry ingredients into wet in three rounds, fully incorporate all dry ingredients before added the next round.

Add 3 tbsp of batter into preheated Mini Waffle Bowl Maker and cook until the waffle bowl is golden brown and crisp (about 3-4 minutes).

**SNICKERDOODLE WAFFLE BOWL****Ingredients:**

2 cups all purpose flour
2 tsp kosher salt
4 tsp baking powder
1/3 cup sugar
4 tsp cinnamon
3 tsp cream of tartar
2 eggs
1½ cups milk
1/3 cup butter
2 tsp vanilla extract

Directions:

Plug in your Mini Waffle Bowl to preheat.

In a small pot over low heat, add milk and butter to warm through and melt butter. In a large bowl, combine flour salt, baking powder, sugar, cinnamon, cream of tartar and whisk to combine. In a separate bowl, whisk eggs and slowly pour in the warmed milk and butter, add vanilla. Pour dry ingredients into the wet in three stages, incorporating all dry ingredients before adding the next.

Ladle 3 tbsp of batter into the preheated Mini Waffle Bowl Maker and cook for 2½ – 3½ minutes until golden brown and crisp.



CHOCOLATE WAFFLE BOWL

Ingredients:

¾ cup all-purpose flour
2 tbsp sugar
¼ cup unsweetened cocoa powder
2 tbsp melted butter
1 cup buttermilk
½ tsp baking powder
¼ tsp baking soda
1 large egg
½ cup chocolate chips

Directions:

Plug in your Mini Waffle Bowl to preheat.

In a medium bowl, sift together the flour, sugar, cocoa powder, baking powder, and baking soda. Whisk the egg, butter, and buttermilk in a separate bowl. Mix the wet ingredients with the dry. Gently fold in the chocolate chips.

Pour 3 tbsp of batter into the Lower Cooking Surface of your Mini Waffle Bowl Maker and cook the chocolate waffle bowl until crispy. Serve the waffle bowl filled with vanilla ice cream, strawberries, and powdered sugar.



Ingredients:

2½ cup all purpose flour
½ cup sugar
1 tbsp baking powder
1 tsp kosher salt
1 each vanilla bean
2 large eggs
¼ cup vegetable oil
2 cup vanilla Greek yogurt
1 cup seltzer

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

In a large bowl, mix the flour, baking powder, and salt. Cut the vanilla bean down the middle lengthwise and scrape out the seed paste. In a separate bowl, add the vanilla bean paste, eggs, oil, yogurt and mix together. Add the dry ingredients into the wet a little at a time while mixing. Once all the ingredients are incorporated, mix in the seltzer.

Pour 3 tbsp of batter into the Lower Cooking Surface of your Mini Waffle Bowl Maker. Close the lid and set a timer for 2½ minutes.



EGG & CHEESE HASH BROWN WAFFLE BOWL

Ingredients:

2½ cups frozen shredded hash brown potatoes
3 eggs
1/4 cup milk
1 cup shredded sharp cheddar cheese
1/4 cup fresh chopped chives, plus some for garnishing
salt & pepper
sour cream, for serving, if desired

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

Lay out frozen hash browns on a cookie sheet lined with paper towels for at least 15 minutes. While potatoes are thawing gather the rest of the ingredients. In a medium sized mixing bowl, mix together eggs and milk. Stir in potatoes, cheese and chives, season with ½ tsp of kosher or sea salt and 1/4 tsp ground black pepper. Spray the top and bottom cooking surface with cooking spray.

Scoop 3 tbsp of potato mixture and place into the Lower Cooking Surface of the Mini Waffle Bowl Maker. Close the cover and cook for about 5 minutes or until the waffle bowl is crisp. After removing the waffle bowl, add in your favorite breakfast fillings such as scrambled eggs, bacon, sausage or sour cream.



Cheddar Cornbread WAFFLE BOWL

Ingredients:

1½ cups all-purpose flour
1 cup yellow cornmeal
1½ tsp sugar
2 tsp baking powder
1 tsp baking soda
1 tsp salt
2 cups buttermilk
2 eggs
6 tbsp butter melted

2½ cups cheddar cheese shredded
Optional Toppings/Fillings shredded chicken/pork vegetarian chili
sour cream
extra cheddar
cilantro
scallions

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

Whisk together the dry ingredients. In a small bowl, whisk together the egg and buttermilk. Add the wet ingredients into the dry, folding together until just combined. Add in the melted butter and cheese, fold together gently.

Pour 3 tbsp of batter into the Lower Cooking Surface of your Mini Waffle Bowl Maker. Cook until the bowl is golden and crisp, about 4-5 minutes. Add in desired fillings.



FALAFEL WAFFLE BOWL

Ingredients:

½ cup canned chickpeas, well-rinsed
1 clove of garlic
½ cup red onion
1 handful of fresh parsley
1 cup baby spinach
1 tsp cumin powder
½ tsp sea salt
black pepper to taste
1/4 cup extra virgin olive oil
1 cup chickpea flour Fillings (optional) cherry tomatoes, sliced cucumbers, sliced parsley
tzatziki sauce
tzatziki dressing
hot sauce

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

Add garlic clove to a food processor and blend until minced. Add in the onions and blend until minced. Add in all other ingredients, (except the chickpea flour) and blend until minced and combined. Pour blended ingredients into a separate bowl and add in the chickpea flour, mix to combine.

Add about 3 tbsp of the mixture to the Lower Cooking Surface of your Mini Waffle Bowl Maker. Cook for 4-5 minutes or until the bowl is golden brown and crisp. Carefully remove the finished bowl with tongs. Add in your

favorite fillings.



Zucchini Parmesan Waffle Bowl

Ingredients:

2½ cups shredded zucchini

1 large egg

¼ cup whole milk

½ cup grated Parmesan cheese

2 tbsp flour

1 tbsp fresh parsley, chopped salt and pepper

Directions:

Plug in your Mini Waffle Bowl Maker to preheat.

Place shredded zucchini in a colander and toss with about ½ tsp of salt. Let sit for 30 minutes. Rinse well with cold water and squeeze out excess water. Dry on paper towels. Preheat your Mini Waffle Bowl Maker. In a medium sized bowl, combine egg, milk, parmesan and chopped parsley. In a separate bowl, combine flour, about ½ tsp of salt and ¼ tsp of freshly ground black pepper. Combine the flour mixture into the egg mixture. Fold in the zucchini.

Add about 3 tbsp of the zucchini mixture into the Lower Cooking Surface of your Mini Waffle Bowl Maker. Cook until browned and crispy, about 4-5 minutes. Pull off carefully with tongs or rubber spatula.

Customer Support

Dash values quality and workmanship and stands behind this product with our Feel Good Guarantee™. To learn more about our commitment to quality, visit bydash.com/feelgood.

Our US-based customer support team is at your service Monday – Friday during the times below. Reach us at 1 (800) 898-6970 or support@bydash.com



Hey Hawaii! You can reach our customer service team from 5AM to 5PM. And also, Alaska, feel free to reach out from 6AM – 6PM.

Warranty

STOREBOUND, LLC – 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound, LLC will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to support@storebound.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

REPAIRS

DANGER! Risk of electric shock! The Dash Mini Waffle Bowl Maker is an electrical appliance.

Do not attempt to repair the appliance yourself under any circumstances.

Contact Customer Support regarding repairs to the appliance.

TECHNICAL SPECIFICATIONS

Voltage 120V ~ 60Hz

Power Rating 375W

Stock#: DMWBM100_20200616_v1

Download

Dash Mini Waffle Bowl Maker DMWBM100 User Manual – [[Download PDF](#)]
