



Dash Portable USB Blender DPPB120 User Manual

[Home](#) » [Dash](#) » Dash Portable USB Blender DPPB120 User Manual 

Contents

- 1 Dash Portable USB Blender DPPB120 User Manual
- 2 IMPORTANT SAFEGUARDS
- 3 PARTS & FEATURES
- 4 USING YOUR PORTABLE USB BLENDER
- 5 Tips & Tricks
 - 5.1 Blending
 - 5.2 Charging
 - 5.3 Indicator Light
- 6 Layering Guide
- 7 CLEANING & MAINTANANCE
- 8 RECIPE GUIDE
- 9 Breakfast Energy Drink
- 10 PB&J Smoothie
- 11 Strawberry Shake
- 12 Green Dream Machine
- 13 Orange Creamsicle Drink
- 14 Cherry Almond Chia Protein Smoothie
- 15 Vegan Mango-Coconut Green Smoothie
- 16 FCC COMPLIANCE STATEMENT
- 17 INDUSTRY CANADA STATEMENT
- 18 Customer Support
- 19 Warranty
- 20 TECHNICAL SPECIFICATIONS
- 21 Download
- 22 Related Posts

Dash Portable USB Blender DPPB120 User Manual



DPPB120

[[Download Recipe Guide PDF](#)]

IMPORTANT SAFEGUARDS

To get the most out of your Dash Portable USB Blender, be sure to read through these important callouts. Keep this Instruction Manual handy and stay safe!

- Remove all packaging and labels from appliance prior to use. To protect against risk of electrical shock, do not put cord, plugs, or appliance in or near water or other liquids.
- Do not put cord, plugs, or appliance in or near water or other liquids, microwave oven or freezer, on a hot gas plate, hot electric burner or in a heated oven. Do not operate this appliance with a damaged charging cable, after the appliance malfunctions, or is damaged in any manner.
- Do not use or assemble/disassemble appliance while plugged into the charger. Avoid contact with moving parts. Make sure the motor stops completely before disassembling.
- Only use attachments that are recommended or sold by the appliance manufacturer. Do not use without the Lid in place.
- Do not leave this appliance unattended while it is operating.
- Do not let the charging cable hang over the edge of tables, counters, or touch hot surfaces.
- Always make sure that the Bottle is locked securely in place before engaging the motor. Do not remove the Bottle before the blender is finished operating.
- The blades in the Blender are sharp. Do not touch the blades with bare hands and keep hands and utensils

away from moving blades. If food becomes lodged, turn off Blender before trying to remove ingredients. Always wait for the blades to stop before opening the Bottle.

- When cleaning, do not submerge the Blending Base (with electrical parts) in any liquid; instead use a soft, wet cloth to wipe down. The Base is NOT dishwasher safe.
- Do not operate the Blender when the Bottle is empty, as this may damage the blender.
- Do not put anything carbonated in your Blender and do not let food sit in your Blender for long periods of time, as these situations may cause pressure to build up that could result in a mess, damage to the blender or possible injury.
- Do not use hot liquids over 120°F/49°C, as this can cause damage to the Jar and Base.
- Keep the blending time below 2 minutes to prevent the motor from overloading or overheating. If the motor stops abruptly, allow the motor temperature to decrease before continuing to blend.
- Always place hard ingredients or ice cubes in the blender first, so that once the blender is flipped, they are farthest away from the blades.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience or knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- This appliance is not a toy. Do not let children use this appliance. Close supervision is necessary when any kitchen appliance is used by or near children.
- For any maintenance other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 9AM – 9PM EST Monday – Friday, or by email at support@bydash.com. StoreBound shall not accept liability for damages caused by improper use of the appliance.

PARTS & FEATURES



USING YOUR PORTABLE USB BLENDER

1. To charge your Portable USB Blender, plug the USB-C side of your Charging Cable into the Blending Base (photo A) and the USB-A side of the Cable into any compatible power adapter.



2. Remove the Drinking Lid from the top of the Bottle. Make sure the Bottom Cap is properly attached to the bottom of the Bottle (photo B).



3. Fill the Bottle with what you'd like to blend (photo C). For best performance, see our Layering Guide on Page 14.



4. Unscrew and remove the Blade Cover from the Blending Base (photo D).



5. Screw the Base to the top of the Bottle, making sure the small arrow on the Bottle is aligned with the arrow on the Base (photo E). Once the Bottle and Base are properly aligned you're ready to blend!



NOTE: It is possible to tighten the base past the arrow. Make sure the arrow and base are aligned or the Indicator Light will blink and the blender will not activate.

6. Flip your Blender over and press the Power Button to start a 40 second blending cycle (photo F). Press the Power Button again to stop blending earlier than that.



7. Once blending has stopped, flip your Blender over and unscrew the Base from the Bottle (photo G).



8. Reattach the Drinking Lid to the Bottle (photo H). To unlock the Lid, simply move the lock to the bottom position and press the gray button to open the lid. Enjoy!



9. After cleaning your Blending Base, be sure to reattach the Blade Cover to avoid injury and for easy transportation and storage.

To help blend your ingredients, we recommend gently shaking the blender while it is active. This prevents large pieces of food or frozen fruit from jamming the blades.

Tips & Tricks

Blending

- Remove fruit peels, pits and seeds before blending. Your blender can blend frozen fruit, but for easier blending, allow frozen fruit to thaw for at least 15 minutes.

Tip: try prepping your smoothie with frozen fruit the night before and let it thaw in the fridge overnight.

- For best performance, do not blend anything bigger than ½ – 1” sized pieces.
- For best performance, when blending fresh or frozen fruit, mix 1:1 with water or milk.
- Do not blend meat, hard, sticky or dry foods.
- When blending ice, be sure to blend 1:1 with water. Use the smallest sized ice possible.

Charging

To extend the life of your Portable USB Blender, we recommend:

- Using the included USB-C Charging Cable to charge it. If lost or misplaced, a non-fast charging USB-C charging cable will work fine. DO NOT use a USB-A to USB-C charging cable to charge the Portable USB Blender.
- Charging your Blender once every 2-3 months to keep the rechargeable battery fresh.
- **NOTE:** the blender will not activate while it is charging.

Indicator Light


The Indicator Light can blink and show a variety of colors, depending on the situation:

- Blinks 2-3 times when the base and jar aren't aligned: the blender will not turn on.
- Lights up when blending.
- Red light flashes 8 times: battery is dead.

- White light slowly flashes while it is charging.
- Fully charged: white light will stay on until the charger is removed.
- Blender shuts off and red light flashes 4 times: food is stuck/overload protection. Try giving your blender a shake and hitting the Power Button again.

Layering Guide

Once your Bottle is packed, attach the Blending Base, flip and blend!



CLEANING & MAINTANANCE

The Bottle, Drinking Lid, Bottom Cap, and Blade Cover are all top-rack dishwasher safe. The Blending Base is NOT dishwasher safe. Wipe down the Blending Base with a wet cloth to clean.

For a quick and easy way to clean the blades, add warm water (about 2/3 of the bottle) and a drop of dish soap to your assembled blender and run a blending cycle. When finished, pour out soapy water and rinse.

NEVER touch the blades. Clean using the above method or a nylon cleaning brush.

RECIPE GUIDE

Follow us! **Instagram**

@bydash | recipes, videos, & inspiration
@unprocessyourfood | veg & vegan-friendly meals



Breakfast Energy Drink

Calories: 193
Total Fat: 4 g
Protein: 3 g
Fiber: 6 g
Cholesterol: 0mg
Carbohydrates: 38 g

Ingredients:

¼ cup frozen blueberries
½ banana, sliced
¼ cup oats
½ tsp vanilla
1 cup Unsweetened Vanilla Almond Milk (or milk of choice)

Chef Tip!

Add a scoop of your favorite protein powder for an extra kick!

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the frozen fruit moving onto the blades.
3. Blend to desired consistency.



PB&J Smoothie

Calories: 330
Total Fat: 17 g
Protein: 10 g
Fiber: 7 g
Cholesterol: 0 mg
Carbohydrates: 42 g

Ingredients:

2 tbsp creamy peanut butter

½ frozen banana, sliced

½ cup organic frozen strawberries (about 4-5 small strawberries)

½ cup Unsweetened Vanilla Almond Milk (or milk of choice)

Chef Tip!

Add a scoop of your favorite protein powder for an extra kick!

Directions:

1. Prepare the frozen banana and strawberries by slicing. The banana should be sliced in ¼ in pieces and any large berries should be sliced in half.
 2. Add the ingredients to the blender in the order above. You can use any milk you prefer in this recipe.
 3. Attach the blender base and tilt the blender in a circle at a 45° angle to keep the frozen fruit moving. This smoothie recipe has a lot of frozen fruit so you may need to shake the blender to keep the blades from jamming, this is normal.
 4. Blend for 2 cycles or until all the frozen fruit is processed.
-

**Strawberry Shake**

Calories: 190

Total Fat: 6 g

Protein: 5 g

Fiber: 6 g

Cholesterol: 1 mg

Carbohydrates: 31 g

Chef Tip!

Add a scoop of your favorite protein powder for an extra kick!

Ingredients:

¾ cup frozen sliced strawberries

¼ cup yogurt

1 tbsp maple syrup,

¾ cup Unsweetened Vanilla Almond Milk (or milk of choice)

1 tbsp chia seeds

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the frozen fruit moving onto the blades.
3. Blend to desired consistency.
4. Serve and top your bowl how you like it! We recommend granola, nuts, seeds, dried fruit, honey, fresh fruit, or

coconut flakes.



Green Dream Machine

Calories: 420
Total Fat: 23 g
Protein: 7 g
Fiber: 14 g
Cholesterol: 0 mg
Carbohydrates: 55 g

Ingredients:

½ cup baby kale
½ frozen banana, sliced
¼ avocado, sliced
1 tbsp maple syrup
1 tbsp chia seeds
¾ cup Unsweetened Vanilla Almond Milk (or milk of choice)

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
 2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the solids moving onto the blades.
 3. Blend to desired consistency.
-



Orange Creamsicle Drink

Calories: 346
Total Fat: 1 g
Protein: 6 g
Fiber: 11 g
Cholesterol: 2 mg
Carbohydrates: 84 g

Ingredients:

½ frozen banana, sliced into ¼" slices
2 orange sections, peeled

½ cup plain yogurt
½ cup orange juice

Directions:

1. Add the ingredients above in the order they are listed into the blending bottle.
2. Attach the blender base. Tilt the blender at a 45° angle and press the power button. Rotate the blender at an angle to keep the fruit moving onto the blades.
3. Blend for 2 cycles or until all the frozen banana is processed.

Chef Tip!

Fresh squeezed OJ takes this recipe over the top! Juicing 1 orange makes about ½ cup of fresh squeezed juice.



Cherry Almond Chia Protein Smoothie

Calories: 200
Total Fat: 4 g
Protein: 18 g
Fiber: 4 g
Cholesterol: 28 mg
Carbohydrates: 22 g

Ingredients:

¾ cup frozen cherries
1 tsp vanilla extract
1 tsp almond extract
1 scoop (¼ cup) vanilla protein powder
¾ cup Unsweetened Vanilla Almond Milk (or milk of choice)
1 tsp chia seeds

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
 2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the solids moving onto the blades.
 3. Blend to desired consistency.
-



Vegan Mango-Coconut Green Smoothie

Calories: 319
Total Fat: 2 g
Protein: 3 g
Fiber: 6 g
Cholesterol: 0 mg
Carbohydrates: 74 g

Ingredients:

½ cup spinach
½ cup frozen mango
½ frozen banana, sliced
¾ cup orange juice
½ cup coconut milk
1 tbsp maple syrup

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
 2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the frozen fruit moving onto the blades.
 3. Blend to desired consistency.
-



Calories: 258
Total Fat: 0 g
Protein: 7 g
Fiber: 1 g
Cholesterol: 10 mg
Carbohydrates: 55 g

Ingredients:

1 cup cold brew
1 cup nonfat frozen yogurt or vanilla ice cream
½ cup ice cubes
2 tsp honey

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients.
2. Attach the Blending Base and tilt the blender at a 45° angle and press the Power Button. Rotate the blender at an angle to keep the solids moving onto the blades.
3. Blend to desired consistency.



FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

INDUSTRY CANADA STATEMENT

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.


Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Customer Support

Dash values quality and workmanship and stands behind this product with our Feel Good Guarantee™. To learn more about our commitment to quality, visit bydash.com/feelgood.

Our customer support teams in the US and Canada are at your service Monday – Friday during the times below. Contact us at 1 (800) 898-6970 or support@bydash.com



Hey Hawaii! You can reach our customer service team from 3AM to 3PM. And also, Alaska, feel free to reach out from 5AM to 5PM.

Warranty

STOREBOUND, LLC – 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound, LLC will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to support@bydash.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR

FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

REPAIRS

DANGER! Risk of electric shock! The Dash Portable USB Blender is an electrical appliance. Do not attempt to repair the appliance yourself under any circumstances. Contact Customer Support regarding repairs to the appliance.

TECHNICAL SPECIFICATIONS

Power Rating 7.4V (9.62WH) Stock#: DPPB120_20220517_v2

Download

Dash Portable USB Blender DPPB120 User Manual – [[Download PDF](#)]
