

Contents [[hide](#)]

1 Delta Electronics DOP-100 Series HMI Touchscreen

2 Usage Instructions

2.1 Accessories and Models

2.2 Analog IO Units

2.3 Area Scan Cameras

2.4 Communication Interface Units

2.5 Control Modules

3 Accessories, Model(s): DPA-CBL, QPS-CBL

4 Accessories, communication interfaces, Model(s): DVPCP02-H*, DVPDT02-H*, DVPPF02-H*

5 Accessories, I/O extensions for DI/DO units, Model(s): DVPAETB* Accessories, temperature sensors, Model(s): DVP08TC-H* Accessories: I/O extension, Model(s): AHBP00M2-5A

6 Accessory I/O extensions, Model(s): AHXBP04M1-5A

7 Accessory I/O extensions, “AH Series”, Model(s): AHAADP followed by 01-09, followed by EF, followed by -5A.

8 Accessory Open type RS-485 Repeater, Model(s): IFD5710

9 Accessory Open type, “AH Series”, Model(s): AHBP followed by 00 to 12, followed by numbers, alphabets or blank. I/O extension for DI/DO units, Model DVPAETB, followed by numbers, alphabets or blank. Fiber module, AHAADP followed by 01-09, followed by EF, followed by -5A.

10 Analog IO units, Model(s): AH01AD*, AH01DA*, AH01LC*, AH01XA*, AH02AD*, AH02DA*, AH02LC*, AH02XA*, AH04AD*, AH04DA*, AH04LC*, AH04XA*, AH06AD*, AH06DA*, AH06LC*, AH06XA*, AH08AD*, AH08DA*, AH08LC*, AH08XA*, AH16AD*, AH16DA*, AH16LC*, AH16XA*

11 Analog IO units, Model(s): AS02 followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

12 Analog IO units, Model(s): AS04 followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -

B, -C or any numbers or alphabets, may be followed by blank

13 Analog IO units, Model(s): AS06 followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

14 Analog IO units, Model(s): AS08 followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

15 Area Scan 3D Camera, Model(s): DMV-TI300GSM, DMV-TI300-SSG

16 Area Scan Camera, Model(s): DMV-C series (followed by a, followed by b, followed by G, followed by c, followed by d) where a can be "C or V or L or X", where b can be "300, 400, 800, 1M6, 2M1, 3M2, 5M0, 6M3, 12M or 20M", where c can be "C or M", where d can be "005, 008, 016, 023, 036, 055, 060, 075, 120 or 290"

17 Communication interface units, Model(s): COA02, DMV1000-80GX, DNA02, DVPCOPM-SL, DVPEN01-SL, DVPPF02-SL, DVS005*, DVS008*, DVS016*, ENA01-EIP, ENA01-MOD, RTU-485, RTU-DNET, RTU-PD01

18 Communication interface units, keypad accessories, Model(s): DMV1000-KEY

19 Communication interfaces, listed accessories, Model(s): DVPSCM*

20 Computer Numerical Control, Model(s): NC followed by 200 or 300 or 310 or 311, followed by A, P or AH, followed by MS, MI, LI, GI, GS or GP, maybe followed by additional suffix(es) or number(s).

21 Control modules, Model(s): DCH1000A, DVP10PM00M*, DVP12SA10R*, DVP12SE11R*, DVP12SE11T*, DVP14SS11R*, DVP14SS11R2*, DVP14SS11T*, DVP14SS11T2*, DVP20PM00D*, DVP20PM00M*, DVP28SS211S, ELCPC12NNAR

22 Control modules, Model(s): DVP followed by 12, 14, 20 or 28 followed by SS2 or SX2, followed by 11, followed by R, T or S.*

23 Control modules, Model(s): DVP followed by 14, 16, 24, 30, 32, 20, 40, 60 or 80 followed by ES, EX, SS or EC, may be followed by

24 Control modules, Model(s): DVP may be followed by any alphanumeric, followed by 16, 20, 32, 40, 48, 60, 64 or 80, followed by EH, followed by 00, followed by R, T or M.*

25 Control modules, Model(s): DVP may be followed by any alphanumeric, followed by 10, 24, or 28, followed by SX or SV, followed by 11 or 211, followed by R or T

26 Control modules, Model(s): DVP followed by 12, 10, 15, 32, or 50 followed by SA, SC, MC, or ES, may be followed by 2, followed by 11, followed by R, S, T, or P.*

27 Control Modules, Model(s): DVP26SE11R, DVP26SE11S, DVP26SE11T, DVP28SA211R, DVP28SV11T2, DVP28SV11TC, DVPX10MC11T, DVPX12SE11T, DVPX28SV11R2, DVPX40EH00T3, Model DVPX14SS211R and DVPX14SS211T.

28 Control Modules, "–", Model(s): DVP28SA211S, DVP28SA211T

29 Control units, Model(s): DVP28SS211R, DVP28SS211T

29 Control units, Model(s): DVP-ECC02T-H, DVP-ECC02T-H

30 Counter module Unit, Model(s): Model AS followed by 02, followed by HC, followed, followed by -A.

31 CPU Unit, Model(s): AHCPU521-DNP, AHXCPU500-EN, AHXCPU500-RS2, AHXCPU510-EN, AHXCPU530-EN

32 CPU units, Model(s): AS324 followed by P, T, or MT, followed by -A or any numbers or alphabets, may be followed by blank

33 CPU units, Model(s): AS332 followed by P, T, or MT, followed by -A or any numbers or alphabets, may be followed by blank

34 CPU units, Model(s): CPU unit, Model AS Model AS, followed by 3, followed by 00, followed by N, followed by -A or any numbers or alphabets, maybe followed by 2 or blank

35 CPU units, Model(s): CPU Unit, Model AS Model AS, followed by 3, followed by 20, followed by P or T, followed by -B or any numbers or alphabets, maybe followed by 2 or blank

36 CPU units, Model(s): Model AS Model AS, followed by 2, followed by 28, followed by R, T, or P, followed by -A or any numbers or alphabets, maybe followed by 2 or blank

37 Digital IO Unit, Model(s): AS04SIL-A

38 Digital IO units, Model(s): AH followed by 08, 16, 32, 64, followed by A thru Z or 0 thru 9, followed by M, N, P, R, followed by 00 thru 99, followed by R, T, P, S, X, N, followed by A thru Z or 0 thru 9, followed by A, B, C.*

39 Digital IO units, Model(s): Model AS followed by 08, 16, 32, 64, followed by A, followed by M, N, or P, followed by 0 or 1, followed by 0, 1, or 2, followed by N, R, T or P, followed by -A or any numbers or alphabets, maybe followed by blank.

40 EtherCAT Slave remote I/O modules, Model(s): R1-EC5500D0, R1-EC5500D1, R1-EC5621D0, R1-EC5621D1, R1-EC7062D0, R1-EC7062D1, R1-EC8124D0, R1-EC8124D1, R1-EC9144D0, R1-EC9144D1

41 Expansion I/O units, Model(s): DVP01HC-H*, DVP01PU-H*, DVP02HC-H*, DVP06XA-H*

42 Expansion I/O units, Model(s): DVP followed by 02, 04 or 06 followed by AD, DA, TC, XA or PT, followed by E2.* (Rated 24V dc.)

43 Expansion I/O units, Model(s): DVP followed by 08, 14, 16, 24 or 32 followed by XM, XN or XP, may be followed by 2, followed by 00, 01 or 11, followed by R, N or T.*

44 Expansion I/O units, Model(s): DVPX where X may be any alphanumeric, followed by 08, 16, 32 or 48, followed by HN, HM or HP, followed by 11 or 00, followed by R, T or N.*

45 Expansion modules, Model(s): ADP485-01*, DOP-EXIO14RAE, DOP-EXIO28RAE, DOP-EXLNGJ1AE, DOP-EXLNGJ2AE, DOPEXLNGJ4AE, DOP-EXLNHJ1AE, DOP-EXLNHJ2AE, DOP-EXLNHJ4AE, DOP-EXLNTJ1AE, DOP-EXLNTJ2AE, DOPEXLNTJ4AE, DVP01AD-S, DVP01DA-S, DVP01LC-SL*, DVP01PT-S, DVP01PU-S, DVP02LC-SL*, DVP04PT-S, DVP04PU-S, DVP04TC-S*, DVP06PU-S, DVP06SN11N*, DVP06SN11P*, DVP06ST11N*

DVP04FC-S, DVP04FC-S , DVP06FC-S, DVP06SN11N , DVP06SN11R , DVP06ST11N ,
DVP06ST11R*, DVP06XA, DVP08RT-S*, DVP08SM10N*, DVP08SM11N*, DVP08SN11N*,
DVP08SN11R*, DVP08SN11R*, DVP08SN11T*, DVP08SP11R*, DVP08SP11T*,
DVP08ST11N*, DVP08ST11R*, DVP10RC-E2*, DVP16SM11N*, DVP16SN11T*,
DVP16SP11R*, DVP16SP11T*, DVP16SP11TS*, DVP20LC-SL*, DVP32SM11N*,
DVP32SN11TN*, DVPDNET-SL*, DVPDT01-S*, DVPPF01-S*, DVPX16SM11N,
DVPX16SN11T, DVPX16SP11T, ELC-EX08NNAN

46 Expansion modules, Model(s): DVP02DA followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP04AD followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP04DA followed by -S, or -S2, may be followed by additional suffixes or blank Expansion modules, Model(s): DVP06AD followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP06DA followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP06PT followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion units, Model(s): DVP04AD-SL, DVP04DA-SL

47 Extension Accessory Device, Model(s): NC-CAB-DMC*** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-ADC** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-DAC** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-R****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-T****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-TAD** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EXM-M** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EXM-S** * is number and # is alphabet or blank

48 Extension Accessory Device, Model(s): NC-PAN-***AM-P# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-P**** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-R****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-T**** * is number and # is alphabet or blank

49 Hand-held programmers, Model(s): DVPHPP0*

50 Human Machine Interface, Model(s): DOP-103DQ, DOP-103SQ, DOP-103WQ, DOP-103WQZ0, DOP-107PV, DOP-107WVCS, DOP-110WS, DOP-110WSY0, DOP-B07SS411, DOP-BX03E211, DOP-BX03S210, DOP-BX03S211, DOP-BX07E415, DOP-BX07E515, DOP-BX07PS415, DOP-BX07PS515, DOP-BX07S401K, DOP-BX07S411, DOP-BX07S415, DOP-BX07S515, DOP-BX08E515, DOP-

51 Human Machine Interface, Model(s): DAM Series followed by 0 thru 9, followed by 00 thru

99, followed by A~Z, Followed by D, Followed by MP-C or MP-D

52 Human Machine Interface, Model(s): DOP Series DOP-107EG, DOP-107BG, DOP-107BV, DOP-107EV, DOP-107CV, DOP-110CS, DOP-103BQ, DOP-103BQZ0, DOP-103SQ

53 Human Machine Interface, Model(s): DOP-103DQZx (where 0 = number, could be 0 thru 9)

54 Human Machine Interface, Model(s): DOP-105CQ, DOP-107DV, DOP-107IV, DOP-108IG, DOP-110IS, DOP-110IG, DOP-110CG

55 Human Machine Interface, Model(s): DOP-112WX, DOP-112MX, DOP-115WX, DOP-115MX

56 Human Machine Interface, Model(s): DXMC-1FA1RN-70 and DXMC-1FA2RN-70 (both followed by suffix F, A, S or D)

57 Human Machine Interface, Model(s): MP1-P10D-15 series followed by 0 or 1, followed by 0 ~ 6, or A or B, follow by A to Z(D=Delta version), followed by 0~9 or A~Z

58 Human machine interfaces, Model(s): DOP-B03E210*, DOP-B03S210*, DOP-B05S111

59 Human machine interfaces, Model(s): DOP-B03E211* * = may be followed by additional suffixes.

60 Human machine interfaces, Model(s): DOP-B03S211* * = may be followed by additional suffixes.

61 Human machine interfaces, Model(s): DOP-B07 may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

62 Human machine interfaces, Model(s): DOP-B08 may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

63 Human machine interfaces, Model(s): DOP-B10 may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

64 Human machine interfaces, Model(s): DOP-BX05S111, DOP-BX07S401K and DOP-BX07E411

65 Human machine interfaces, Model(s): DOP-W105 may be followed by additional suffixes

Human machine interfaces, Model(s): DOP-W127 may be followed by additional suffixes

Human machine interfaces, Model(s): DOP-W157 may be followed by additional suffixes

66 Human machine interfaces, Model(s): HMC, followed by 08 or 07, followed by -, followed by A thru Z, followed by 0 thru 9, followed by 00 thru 99, followed by S or H, followed by 0 thru 6, followed by 0 thru 6.

67 Industrial Ethernet Switch, Model(s): DVS-008W00-M12, DVS-G008W01, DVS-G008W01-KR

68 Industrial Ethernet Switch, Model(s): DVS-109 followed by I or W, followed by 00, 01, or 02, followed by -1GE

69 Industrial Machine Vision Controller, Model(s): DMV1000-GE2-VL, DMV1000-GE2-VLM,

DMV3000-GE2-VL and DMV3000-GE2- VLM

70 Industrial Network Equipment, Model(s): DVS-G002I00C-TF, DVS-G928W01, IFD8540

71 IO Unit, Model(s): AHX05PM-5A, AHX10COPM-5A, AHX10DNET-5A, AHX10EN-5A, AHX10PM-5A., AHX10SCM-5A, AHX16AM10N- 5A, AHX16AN01R-5A, AHX32AM10N-5A, AHX32AN02T-5A, AHX64AM10N-5C, AHXBP06M1-5A, AHXBP08M1-5A, AHXRTU-DNET-

72 Open Type, Industrial Ethernet Switch, Model(s): DVW-W02W2-E2-XX where XX can be any alphanumeric character or blank for marketing purpose.

73 Open type, Programmable controllers, Model(s): DVS followed by G005I, G008I, 008I, 110W02,108W02 followed by any alphabets, numbers or blank.

74 Open type, Programmable controllers, “AH Series”, Model(s): AH followed by CPU, followed by 500, 501, 510, 511, 520, 521, 530, and 531 followed by RS, EN, followed by numbers, alphabets or blank.

75 Open type, Programmable controllers, “DVP SERIES”, Model(s): DVP201LC-SL *, DVP202LC-SL *, DVP211LC-SL *

76 Open-type, Compact Vision System, Model(s): DMV2000-CL4-HSM and DMV2000-CL2-HSM

77 Open-type, Compact Vision System, Model(s): Model DMV2000-CL4-HS, and DMV2000-CL2-HS

78 Panel PC, Model(s): TP70P-16TP1R, TP70P-16TP1T, TP70P-211LC1T, TP70P-21EX1R, TP70P-21EX1T, TP70P-22XA1R, TP70P- 22XA1T, TP70P-32TP1R, TP70P-32TP1T, TP70P-RM0, TP70P-RM1, TP70P-RM2

79 Power Module, Model(s): Model AHXPS05-5A

80 Power modules, Model(s): AHPS05*, AHPS15*, DVPPS01, DVPPS02

81 Power supply modules, Model(s): DPR20A, DPS024-24V43, DVPPS02, DVPPS05

82 Pressure sensors, Model(s): DPA01*, DPA10*

83 Programmable Automation Controller, Model(s): CMC-MH2P01-003, Model MH1-C50 Series, NC10EB, NC10EB100, NC10EB200

84 Programmable Automation Controller, Model(s): AX-8yyEP0XYZW Series where y= 0-9 or A-Z, X=A-Z, Y=A-Z, Z=0-9 and W=T or P

85 Programmable Automation Controller, Model(s): NC30E, NC30EH, NC30EB, and NC30EBH maybe follow by 100, 200, 300, 400, 500, 600

86 Programmable Automation Controller, Model(s): R2-EC0004, R2-EC1004, and R2-EC2004 ,may be followed by D0 to D9 or blank

87 Programmable Controllers, Model(s): AHBP04MR1-5A, AHBP06ER1-5A, AHBP06MR1-5A, AHBP08ER1-5A, AHBP08MR1-5A, AHCPU560-EN2, AS02ADH-A, AS524C-B, AS516E-R DVP02PIL-E2 DVP08NTC-S DVP15MC11T DVP15MC11T-06 DVP50MC11T-06

- D, DVP32C11T, DVP32C11C, DVP32MC11T, DVP32MC11C, DVP32MC11T-00, DVP32ES311T, DVP50MC11T, DVPX28SV11T2, Model DVP14SA211TF and DVP16SP11TF, RTU-CN01, TP04P-20EXL1T
- 88 Programmable Controllers, Model(s): AS5YYZSW-B Series where YY can be 08, 16, 24, 32, 40, 48, 56, 64, 1H or 2H, where Z can be E or C, where S can be blank, where W can be T or blank
- 89 Programmable Controllers, Model(s): CMC-EC0004, CMC-EC1004, and CMC-EC2004 ,may be followed by -001 to -009
- 90 Programmable Controllers, Model(s): CPU Unit Model AS, followed by 2, followed by 18, followed by RX, TX, or PX, followed by – A or any numbers or alphabets, maybe followed by 2 or blank.
- 91 Programmable Controllers, Model(s): DVP02 may be followed by TKR-S, TKN-S, TKL-S, TUR-S, TUN-S, TUL-S, UHL-S, KHL-S
- 92 Programmable Controllers, Model(s): DVPxyz Series where x can be 20 or 28, and y can be SV3 or SX3, and z can be 11T, 11R or 11S
- 93 Programmable Controllers, Model(s): MH2-P10N-RXYDZ Series (N=N or E. R=N or P.X=0.Y=A~Z, 0~9. D=A~Z, 0~9.Z= A~Z, 0~9)
- 94 Programmable Controllers, “AS series”, Model(s): Model AS , followed by 02, 04 followed by PU, followed by -A
- 95 Programmable human machine interfaces, Model(s): DOP-A10TCTD, DOP-A10THTD1, DOP-A75CSTD, DOP-AE10THTD, DOP- AE10THTD1, DOP-AE80THTD, DOP-AE80THTD0, DOP-AS35THTD, DOP-AS38BSTD, DOP-AS38BSTD-W, DOP-AS57BSTD, DOP- B05S100, DOP-B05S101, DOP-B07E411, DOP-B07S200, DOP-B07S201, DOP-B07S201A, DOP-B07S211, DOP-B07S410, DOP- B07S411K, DOP-BX07S410, TP04G-AL-C, TP04G-BL-C
- 96 Programmable human machine interfaces, Model(s): DOP followed by -A or -AE, followed by 57, followed by G, C or B, followed by STD, may be followed by -W.
- 97 Programmable human machine interfaces, Model(s): DOP-NP5 followed by -MQ or -SQ, followed by 0 thru 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.
- 98 Programmable human machine interfaces, Model(s): TP followed by 02, 04, 05 or 08 followed by T or G, followed by A or B, followed by S, followed by 1 or 2
- 99 Programmable human machine interfaces, Model(s): TP04P followed by 00 thru 32, followed by TP, EX or XA, followed by 0-9, followed by R or T, followed by additional alphanumeric letters or blank
- 100 Programmable Logic Controller, Model(s): AX-332EP0MB1P, AX-332EP0MB1T
- 101 Programmable Logic Controller, Model(s): AX-CxxEB0MD1T Series ,where xx can be 06 or 12
- 102 Programmable logic controllers Model(s): DVP followed by 10 thru 60 followed by EC

102 Programmable Logic Controllers, Model(s): DVP followed by 10 thru 60, followed by EO, followed by 00, followed by R or T.*

103 Programmable Logical Controller, Model(s): ASRTU-EC16AP1TA, DVP28EX300MT, R2-EC0902D0

104 Programmable Logical Controller, Model(s): AS1XY series where X can be 32, 48 or 64, and Y can be T-A, R-A or P-A

105 Programmable Logical Controller, Model(s): AX-3YYZA0SW Series where YY can be 00, 04, 08, 16, 24 or 64, where Z can be E, N or EL, where S can be MA1 or PA1, where W can be T or P

106 Programmable Logical Controller, Model(s): DVPaEX3b series where a can be 22 or 36, b can be 00R or 00T

107 Programmable Logical Controller⁵⁵, Model(s): DVP32ES300TEC

108 Programmable Logical Controller⁵⁵, Model(s): DVPXES3Y series where X can be 32, 48, 64 or 80 and Y can be 00R or 00T

109 Remote IO Communication Module, Model(s): RTU-ECAT

110 Switching power supply module, Model(s): AS-PS02 and AS-PS02A

111 T, Model(s): DVP06PT-E2

112 Various & communication IO units, Model(s): AHRTUCOPM*, AHRTUDNET*, AHRTUETHN*, AHRTUPFBS*

113 Various & communication IO units, Model(s): AH followed by 01 thru 30 followed by PT, PTG, TC, HC, PM, MC, EN, SCM, DNET, PFBM, PFBS, EIP. COPM, and EMC, followed by numbers, alphabets or blank. Model AH, followed by RTU, followed by COPM, DNET, ETHN, PFBS, followed by numbers, alphabets or blank

114 Various & communication IO units, Model(s): AS00SCM followed by -A or any numbers or alphabets, may be followed by blank

115 Various & communication IO units, Model(s): ASXXYYYYY-Z, maybe followed by blank. XX represents 00 or 01, YYYYY represents SCM, DNET, Z represents A or any numbers or alphabets.

116 Specifications

116.1 Frequently Asked Questions (FAQ)

116.2 Where can I send quote requests?

116.3 How can I place an order?

117 Documents / Resources

117.1 References

118 Related Posts

Delta Electronics DOP-100 Series HMI Touchscreen



USER MANUAL

Usage Instructions

Accessories and Models

For additional information and accessories, refer to the following model numbers:

- DPA-CBL, QPS-CBL for communication interfaces
- DVPCP02-H*, DVPDT02-H*, DVPPF02-H* for communication interfaces
- DVPAETB* for I/O extensions for DI/DO units
- DVP08TC-H* for temperature sensors

Analog IO Units

The analog IO units are available in various models including AH01AD*, AH02DA*, AH04LC*, etc. Choose the appropriate model based on your requirements.

Area Scan Cameras

Choose from models like DMV-TI300GSM, DMV-C series, etc. based on your specific needs for scanning applications.

Communication Interface Units

Models like COA02, DMV1000-80GX, DNA02, etc. offer different communication options for your programmable controllers.

Control Modules

Select from models like DCH1000A, DVP10PM00M*, DVP12SA10R*, etc. to control and manage your automation processes effectively.

View model for additional information

Accessories, [Model\(s\): DPA-CBL, QPS-CBL](#)

Accessories, communication interfaces, [Model\(s\): DVPCP02-H*, DVPDT02-H*, DVPPF02-H*](#)

Accessories, I/O extensions for DI/DO units, [Model\(s\): DVPAETB*](#) Accessories, temperature sensors, [Model\(s\): DVP08TC-H*](#) Accessories: I/O extension, [Model\(s\): AHBP00M2-5A](#)

Accessory I/O extensions, [Model\(s\): AHXBP04M1-5A](#)

Accessory I/O extensions, “AH Series”, [Model\(s\): AHAADP](#) followed by 01-09, followed by EF, followed by -5A.

Accessory Open type RS-485 Repeater, [Model\(s\): IFD5710](#)

Accessory Open type, “AH Series”, [Model\(s\): AHBP](#) followed by 00 to 12, followed by numbers, alphabets or blank. I/O extension for DI/DO units, Model DVPAETB, followed by numbers, alphabets or blank. Fiber module, AHAADP followed by 01-09, followed by EF, followed by -5A.

Analog IO units, [Model\(s\): AH01AD*, AH01DA*, AH01LC*, AH01XA*, AH02AD*, AH02D](#)

Analog IO units, [Model\(s\): AS02](#) followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

Analog IO units, [Model\(s\): AS04](#) followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

Analog IO units, [Model\(s\): AS06](#) followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

Analog IO units, [Model\(s\): AS08](#) followed by AD, DA, LC, RTD, TC, or XA, followed by -A, -B, -C or any numbers or alphabets, may be followed by blank

Area Scan 3D Camera, [Model\(s\): DMV-TI300GSM, DMV-TI300-SSG](#)

Area Scan Camera, [Model\(s\): DMV-C series \(followed by a, followed by b, followed by G, followed by c, followed by d\)](#) where a can be “C or V or L or X”, where b can be “300, 400, 800, 1M6, 2M1, 3M2, 5M0, 6M3, 12M or 20M”, where c can be “C or M”, where d can be “005, 008, 016, 023, 036, 055, 060, 075, 120 or 290”

SCeondmQmuuotneicRaetqiouenstasctcoeisnsfoo@ryaudteovmiacteesd,pMt.coodm[el\(s\): RTU-EN01](#)

Call +1(800)985-6929 To Order or Order Online At Deltaacdrives.com

Communication interface units, [Model\(s\): COA02, DMV1000-80GX, DNA02, DVPCOPM-SL, DVPEN01-SL, DVPPF02-SL, DVS005*, DVS008*, DVS016*, ENA01-EIP, ENA01-MOD, RTU-485, RTU-DNET, RTU-PD01](#)

Communication interface units, keypad accessories, [Model\(s\): DMV1000-KEY](#)

Communication interfaces, listed accessories, [Model\(s\): DVPSCM*](#)

Computer Numerical Control, [Model\(s\): NC](#) followed by 200 or 300 or 310 or 311, followed by A, P or AH, followed by MS, MI, LI, GI, GS or GP, maybe followed by additional suffix(es) or number(s).

Control modules, [Model\(s\): DCH1000A, DVP10PM00M*, DVP12SA10R*, DVP12SE11](#)

Control modules, [Model\(s\): DVP](#) followed by 12, 14, 20 or 28 followed by SS2 or SX2, followed by 11, followed by R, T or S.*

Control modules, [Model\(s\): DVP](#) followed by 14, 16, 24, 30, 32, 20, 40, 60

or 80 followed by ES, EX, SS or EC, may be followed by

2, followed by 00, 01, 10 or 11, followed by R, RM, S, T, RE, TE.*

Control modules, [Model\(s\): DVP](#) may be followed by any alphanumeric, followed by 16, 20, 32, 40, 48, 60, 64 or 80, followed by EH, followed by 00, followed by R, T or M.*

Control modules, [Model\(s\): DVP](#) may be followed by any alphanumeric, followed by 10, 24, or 28, followed by SX or SV, followed by 11 or 211, followed by R or T

Control modules, [Model\(s\): DVP followed by 12, 10, 15, 32, or 50](#) followed by SA, SC, MC, or ES, may be followed by 2, followed by 11, followed by R, S, T, or P.*

Control

Modules, [Model\(s\): DVP26SE11R, DVP26SE11S, DVP26SE11T, DVP28SA211R, DVP28SA211S, DVP28SA211T, DVPX14SS211R and DVPX14SS211T.](#)

Control Modules, “–”, [Model\(s\): DVP28SA211S, DVP28SA211T](#)

Control units, [Model\(s\): DVP28SS211R, DVP28SS211T](#)

Counter module Unit, [Model\(s\): Model AS](#) followed by 02, followed by HC, followed, followed by –A.

CPU Unit, [Model\(s\): AHCPU521-DNP, AHXCPU500-EN, AHXCPU500-RS2, AHXCPU510-EN, AHXCPU530-EN](#)

CPU units, [Model\(s\): AS324](#) followed by P, T, or MT, followed by -A or any numbers or alphabets, may be followed by blank

CPU units, [Model\(s\): AS332](#) followed by P, T, or MT, followed by -A or any numbers or alphabets, may be followed by blank

CPU units, [Model\(s\): CPU unit, Model AS](#) Model AS, followed by 3, followed by 00, followed by N, followed by -A or any numbers or alphabets, maybe followed by 2 or blank

CPU units, [Model\(s\): CPU Unit, Model AS](#) Model AS, followed by 3, followed by 20, followed by P or T, followed by -B or any numbers or alphabets, maybe followed by 2 or blank

CPU units, **Model(s):** Model AS Model AS, followed by 2, followed by 28, followed by R, T, or P, followed by -A or any numbers or alphabets, maybe followed by 2 or blank

Digital IO Unit, **Model(s):** AS04SIL-A

Digital IO units, **Model(s):** AH followed by 08, 16, 32, 64, followed by A thru Z or 0 thru 9, followed by M, N, P, R, followed by 00 thru 99, followed by R, T, P, S, X, N, followed by A thru Z or 0 thru 9, followed by A, B, C.*

Digital IO units, **Model(s):** Model AS followed by 08, 16, 32, 64, followed by A, followed by M, N, or P, followed by 0 or 1, followed by 0, 1, or 2, followed by N, R, T or P, followed by -A or any numbers or alphabets, maybe followed by blank.

EtherCAT Slave remote I/O modules, **Model(s):** R1-EC5500D0, R1-EC5500D1, R1-EC5621D0, R1-EC5621D1, **R1-EC7062D0, R1-EC7062D1, R1-EC8124D0, R1-EC8124D1, R1-EC9144D0, R1-EC9144D1**

SEetnhdeQrCuAotTe SRleaqvueesrtesmttooitnefol@/Oaumtomodauteldepst,.cMom**odel(s)**: **R1-EC60x2D0, R1-ECC60aly1 2+D1**(180(x0=)908,51-6, 922o9rT3o),O(ryd=e0r
oorrO2r)der Online At Deltaacdrives.com

Expansion I/O units, **Model(s):** DVP01HC-H*, DVP01PU-H*, DVP02HC-H*, **DVP06XA-H***

Expansion I/O units, **Model(s):** DVP followed by 02, 04 or 06 followed by AD, DA, TC, XA or PT, followed by E2.* (Rated 24V dc.)

Expansion I/O units, **Model(s):** DVP followed by 08, 14, 16, 24 or 32 followed by XM, XN or XP, may be followed by 2, followed by 00, 01 or 11, followed by R, N or T.*

Expansion I/O units, **Model(s):** DVPX where X may be any alphanumeric, followed by 08, 16, 32 or 48, followed by HN, HM or HP, followed by 11 or 00, followed by R, T or N.*

Expansion modules, **Model(s):** ADP485-01*, DOP-EXIO14RAE, DOP-

EXIO28RAE, DOP-EXLNGJ1AE, DOP-EXLNGJ2AE, DOPEXLNGJ4AE, DOP-EXLNHJ1AE, DOP-EXLNHJ2AE, DOP-EXLNHJ4AE, DOP-EXLNTJ1AE, DOP-EXLNTJ2AE, DOPEXLNTJ4AE, DVP01AD-S, DVP01DA-S, DVP01LC-SL*, DVP01PT-S, DVP01PU-S, DVP02LC-SL*, DVP04PT-S, DVP04PU-S, DVP04TC-S*, DVP06PU-S, DVP06SN11N*, DVP06SN11R*, DVP06ST11N*, DVP06ST11R*, DVP06XA, IS*, DVP08SM10N*, DVP08SM11N*, DVP08SN11N*, DVP08SN11R*, DVP08SNE2*, DVP16SM11N*, DVP16SN11T*, DVP16SP11R*, DVP16SP11T*, DVP16SPSL*, DVP32SM11N*, DVP32SN11TN*, DVDPNET-SL*, DVDPDT01-S*, DVPPF01-S*, DVPX16SM11N, DVPX16SN11T, DVPX16SP11T, ELC-EX08NNAN

Expansion modules, Model(s): DVP02DA followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP04AD followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP04DA followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP06AD followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP06DA followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion modules, Model(s): DVP06PT followed by -S, or -S2, may be followed by additional suffixes or blank. Expansion units, Model(s): DVP04AD-SL, DVP04DA-SL

Extension Accessory Device, Model(s): NC-CAB-DMC*** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-ADC** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-DAC** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-R****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-T****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EIO-TAD** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EXM-M** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-EXM-S** * is number and # is alphabet or blank

Extension Accessory Device, Model(s): NC-PAN-***AM-P# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-P**** * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-R****# * is number and # is alphabet or blank Extension Accessory Device, Model(s): NC-TBM-T**** * is number

and # is alphabet or blank

Hand-held programmers, [Model\(s\): DVPHPP0*](#)

Human Machine Interface, [Model\(s\): DOP-103DQ, DOP-103SQ, DOP-103WQ, DOP-103WQZ0, DOP-107PV, DOP-107WVCS, DOP-110WS, DOP-110WSY0, DOP-B07SS411, DOP-BX03E211, DOP-BX03S210, DOP-BX03S211, DOP-BX07E415, DOP-BX07E515, DOP-BX07PS415, DOP-BX07PS515, DOP-BX07S401K, DOP-BX07S411, DOP-BX07S415, DOP-BX07S515, DOP-BX08E515, DOP-](#)

[SBeXn0d8QSu5o1t5e, RDeOquPe-sBtXs 1to0Ein5fo1@5, aDuOtoPm-aBtXed1p0tE.c6o1m5, DOP-BX10PE515, DOP-BXC10aISI 4+111\(8,0D0O\)9P8-5B-6X91209ST5o11O, rDdeOr Po-rBOXr1de0rSO61n5lin, eDAOtPD-eBlXta1a0cVdrSiv5e1s1.c, om](#)

Model DOP-107WV, and Model DOP-107WVZ0, [Model DOP-B07S410](#)

Human Machine Interface, [Model\(s\): DAM Series](#) followed by 0 thru 9, followed by 00 thru 99, followed by A~Z, Followed by D, Followed by MP-C or MP-D

Human Machine Interface, [Model\(s\): DOP Series](#) DOP-107EG, DOP-107BG, DOP-107BV, DOP-107EV, DOP-107CV, DOP-110CS, DOP-103BQ, DOP-103BQZ0, DOP-103SQ

Human Machine Interface, [Model\(s\): DOP-103DQZx](#) (where 0 = number, could be 0 thru 9)

Human Machine Interface, [Model\(s\): DOP-105CQ, DOP-107DV, DOP-107IV, DOP-108IG, DOP-110IS, DOP-110IG, DOP-110CG](#)

Human Machine Interface, [Model\(s\): DOP-112WX, DOP-112MX, DOP-115WX, DOP-115MX](#)

Human Machine Interface, [Model\(s\): DXMC-1FA1RN-70 and DXMC-1FA2RN-70](#) (both followed by suffix F, A, S or D)

Human Machine Interface, [Model\(s\): MP1-P10D-15 series](#) followed by 0 or 1, followed by 0 ~ 6, or A or B, follow by A to Z(D=Delta version), followed by 0~9 or A~Z

Human machine interfaces, [Model\(s\): DOP-B03E210*](#), [DOP-B03S210*](#), [DOP-B05S111](#)

Human machine interfaces, [Model\(s\): DOP-B03E211*](#) * = may be followed by additional suffixes.

Human machine interfaces, [Model\(s\): DOP-B03S211*](#) * = may be followed by additional suffixes.

Human machine interfaces, [Model\(s\): DOP-B07](#) may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

Human machine interfaces, [Model\(s\): DOP-B08](#) may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

Human machine interfaces, [Model\(s\): DOP-B10](#) may be followed by P or V, followed by S or E, followed by 401, 41x, 411, 415, 511, 515 or 615.*

Human machine interfaces, [Model\(s\): DOP-BX05S111](#), [DOP-BX07S401K](#) and [DOP-BX07E411](#)

Human machine interfaces, [Model\(s\): DOP-W105](#) may be followed by additional suffixes Human machine interfaces, [Model\(s\): DOP-W127](#) may be followed by additional suffixes Human machine interfaces, [Model\(s\): DOP-W157](#) may be followed by additional suffixes

Human machine interfaces, [Model\(s\): HMC](#), followed by 08 or 07, followed by -, followed by A thru Z, followed by 0 thru 9, followed by 00 thru 99, followed by S or H, followed by 0 thru 6, followed by 0 thru 6.

Industrial Ethernet Switch, [Model\(s\): DVS-008W00-M12](#), [DVS-G008W01](#), [DVS-G008W01-KR](#)

Industrial Ethernet Switch, [Model\(s\): DVS-109](#) followed by I or W, followed by 00, 01, or 02, followed by -1GE

Industrial Machine Vision Controller, [Model\(s\): DMV1000-GE2-VL](#), [DMV1000-GE2-VLM](#), [DMV3000-GE2-VL](#) and [DMV3000-GE2-VLM](#)

Industrial Network Equipment, [Model\(s\): DVS-G002I00C-TF](#), [DVS-G928W01](#), [IFD8540](#)

IO Unit, [Model\(s\): AHX05PM-5A](#), [AHX10COPM-5A](#), [AHX10DNET-](#)

5A, AHX10EN-5A, AHX10PM-5A, AHX10SCM-5A, AHX16AM10N-5A, AHX16AN01R-5A, AHX32AM10N-5A, AHX32AN02T-5A, AHX64AM10N-5C, AHXBP06M1-5A, AHXBP08M1-5A, AHXRTU-DNET-

5A

Open Type, Industrial Ethernet Switch, **Model(s):** DVW-W02W2-E2-XX where XX can be any alphanumeric character or blank for marketing purpose.

Open type, Programmable controllers, **Model(s):** DVS followed by G005I, G008I, 008I, 110W02, 108W02 followed by any alphabets, numbers or blank.

SOenpdenQutoytpeeR, ePqruegsrtsatmo minfaob@leautoomntarteodllpet.rcso, m**Model(s):** R1-EC5512D0, R1-ECCa7II 0+A1(28D000),9R815—6E9C2790FT2oDO0r,dRer1o-Er CO7rd0eEr2ODn0li,nRe1A—tEDCe7I0taAa2cDdr1iv, eRs1.c—om

EC70F2D1, R1-EC70E2D1

Open type, Programmable controllers, “AH Series”, **Model(s):** AH followed by CPU, followed by 500, 501, 510, 511, 520, 521, 530, and 531 followed by RS, EN, followed by numbers, alphabets or blank.

Open type, Programmable controllers, “DVP SERIES”, **Model(s):** DVP201LC-SL*, DVP202LC-SL *, DVP211LC-SL *

Open-type, Compact Vision System, **Model(s):** DMV2000-CL4-HSM and DMV2000-CL2-HSM

Open-type, Compact Vision System, **Model(s):** Model DMV2000-CL4-HS, and DMV2000-CL2-HS

Panel PC, **Model(s):** TP70P-16TP1R, TP70P-16TP1T, TP70P-211LC1T, TP70P-21EX1R, TP70P-21EX1T, TP70P-22XA1R, TP70P-22XA1T, TP70P-32TP1R, TP70P-32TP1T, TP70P-RM0, TP70P-RM1, TP70P-RM2

Power Module, [Model\(s\): Model AHXPS05-5A](#)

Power modules, [Model\(s\): AHPS05*, AHPS15*, DVPPS01, DVPPS02](#)

Power supply modules, [Model\(s\): DPR20A, DPS024-24V43, DVPPS02, DVPPS05](#)

Pressure sensors, [Model\(s\): DPA01*, DPA10*](#)

Programmable Automation Controller, [Model\(s\): CMC-MH2P01-003, Model MH1-C50 Series, NC10EB, NC10EB100, NC10EB200](#)

Programmable Automation Controller, [Model\(s\): AX-8yyEP0XYZW Series](#) where y= 0-9 or A-Z, X=A-Z, Y=A-Z, Z=0-9 and W=T or P

Programmable Automation Controller, [Model\(s\): NC30E, NC30EH, NC30EB, and NC30EBH](#) maybe follow by 100, 200, 300, 400, 500, 600

Programmable Automation Controller, [Model\(s\): R2-EC0004, R2-EC1004, and R2-EC2004](#) ,may be followed by D0 to D9 or blank

Programmable Controllers, [Model\(s\): AHBP04MR1-5A, AHBP06ER1-5A, AHBP06MR1-5A, AHBP08ER1-5A, AHBP08MR1-5A, AHCPU560-EN2, AS02ADH-A, AS524C-B, AS516E-B, DVP02PU-E2, DVP08NTC-S, DVP15MC11T, DVP15MC11T-06, DVP50MC11T-06, DVP32ES311T, DVP50MC11T, DVPX28SV11T2, Model DVP14SA211TF and DVP16SP11TF, RTU-CN01, TP04P-20EXL1T](#)

Programmable Controllers, [Model\(s\): AS5YYZSW-B Series](#) where YY can be 08, 16, 24, 32, 40, 48, 56, 64, 1H or 2H, where Z can be E or C, where S can be blank, where W can be T or blank

Programmable Controllers, [Model\(s\): CMC-EC0004, CMC-EC1004, and CMC-EC2004](#) ,may be followed by -001 to -009

Programmable Controllers, [Model\(s\): CPU Unit Model AS](#), followed by 2, followed by 18, followed by RX, TX, or PX, followed by – A or any numbers or alphabets, maybe followed by 2 or blank.

Programmable Controllers, [Model\(s\): DVP02](#) may be followed by TKR-S, TKN-S, TKL-S, TUR-S, TUN-S, TUL-S, UHL-S, KHL-S

Programmable Controllers, [Model\(s\): DVPxyz Series](#) where x can be 20

or 28, and y can be SV3 or SX3, and z can be 11T, 11R or 11S

Programmable Controllers, [Model\(s\): MH2-P10N-RXYDZ Series](#) (N=N or E. R=N or P.X=0.Y=A~Z, 0~9. D=A~Z, 0~9.Z= A~Z, 0~9)

Programmable Controllers, “AS series”, [Model\(s\): Model AS](#) , followed by 02, 04 followed by PU, followed by -A

Programmable human machine interfaces, [Model\(s\): DOP-A10TCTD, DOP-A10THTD1, DOP-A75CSTD, DOP-AE10THTD, DOP-AE10THTD1, DOP-AE80THTD, DOP-AE80THTD0, DOP-AS35THTD, DOP-AS38BSTD, DOP-AS38BSTD-W, DOP-AS57BSTD, DOP-B05S100, DOP-B05S101, DOP-B07E411, DOP-B07S200, DOP-B07S201, DOP-B07S201A, DOP-B07S211, DOP-B07S410, DOP-B07S411K, DOP-BX07S410, TP04G-AL-C, TP04G-BL-C](#)

Programmable human machine interfaces, [Model\(s\): DOP](#) followed by -A or -AE, followed by 57, followed by G, C or B, followed by STD, may be followed by -W.

[SPernodgQrauomtemRaebqlueeshtus mtoainnfom@aacuhtoinmeatiendtpetr.cfoamces,](#)

[Model\(s\): DOP-NP3 folloCwaelld+1b\(y80–0M\)9Q8,5f-](#)

6o9II2o9wTeodObryde0r tohrrOur9d,erfoOllnoliwneedAtbDye0ltaoarc1dr,ives.com followe
d by 0 or 1, may be followed by B.

Programmable human machine interfaces, [Model\(s\): DOP-NP5](#) followed by -MQ or -SQ, followed by 0 thru 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

Programmable human machine interfaces, [Model\(s\): TP](#) followed by 02, 04, 05 or 08 followed by T or G, followed by A or B, followed by S, followed by 1 or 2

Programmable human machine interfaces, [Model\(s\): TP04P](#) followed by 00 thru 32, followed by TP, EX or XA, followed by 0-9, followed by R or T, followed by additional alphanumeric letters or blank

Programmable Logic Controller, [Model\(s\): AX-332EP0MB1P, AX-332EP0MB1T](#)

Programmable Logic Controller, [Model\(s\): AX-CxxEB0MD1T Series](#) ,where xx can be 06 or 12

Programmable logic controllers, [Model\(s\): DVP](#) followed by 10 thru 60, followed by EC, followed by 00, followed by R or T.*

Programmable Logical Controller, [Model\(s\): ASRTU-EC16AP1TA, DVP28EX300MT, R2-EC0902D0](#)

Programmable Logical Controller, [Model\(s\): AS1XY](#) series where X can be 32, 48 or 64, and Y can be T-A, R-A or P-A

Programmable Logical Controller, [Model\(s\): AX-3YYZA0SW](#) Series where YY can be 00, 04, 08, 16, 24 or 64, where Z can be E, N or EL, where S can be MA1 or PA1, where W can be T or P

Programmable Logical Controller, [Model\(s\): DVPaEX3b](#) series where a can be 22 or 36, b can be 00R or 00T

Programmable Logical Controller55, [Model\(s\): DVP32ES300TEC](#)

Programmable Logical Controller55, [Model\(s\): DVPXES3Y](#) series where X can be 32, 48, 64 or 80 and Y can be 00R or 00T

Remote IO Communication Module, [Model\(s\): RTU-ECAT](#)

Switching power supply module, [Model\(s\): AS-PS02 and AS-PS02A](#)

T, [Model\(s\): DVP06PT-E2](#)

Various & communication IO units, [Model\(s\): AHRTUCOPM*, AHRTUDNET*, AHRTUETHN*, AHRTUPFBS](#)

Various & communication IO units, [Model\(s\): AH](#) followed by 01 thru 30 followed by PT, PTG, TC, HC, PM, MC, EN, SCM, DNET, PFBM, PFBS, EIP. COPM, and EMC, followed by numbers, alphabets or blank. Model AH, followed by RTU, followed by COPM, DNET, ETHN, PFBS, followed by numbers, alphabets or blank

Various & communication IO units, [Model\(s\): AS00SCM](#) followed by -A or any numbers or alphabets, may be followed by blank

Various & communication IO units, [Model\(s\): ASXXYYYYY-Z](#), maybe followed by blank. XX represents 00 or 01, YYYYY represents SCM, DNET, Z represents A or any numbers or alphabets.

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow – Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow – Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2023 UL LLC."

Specifications

- Brand: Delta Electronics Inc
 - Model Number: E206327
 - Country of Origin: Taiwan
-

Frequently Asked Questions (FAQ)


Where can I send quote requests?

You can send quote requests to info@automatedpt.com.

How can I place an order?

To order, you can call +1(800)985-6929 or visit Deltaacdrives.com for online orders.

Documents / Resources

	<p>Delta Electronics DOP-100 Series HMI Touchscreen [pdf] User Manual</p> <p>DOP-100 Series HMI Touchscreen, DOP-100 Series, HMI Touchscreen, Touchscreen</p>
--	---

References

- [User Manual](#)

Related Posts



[Delta Electronics ME300 Series Drive Owner's Manual](#)

Delta Electronics ME300 Series Drive Specifications:
Model: VFD-ME300-C-PD Dimensions: W: 87.0mm [3.43in], W1: 73.0mm [2.87in], H: 157.0mm [6.18in],...



[Element Electronics EM2PTAD14BS 14 Inch 1080p FHD Touchscreen Portable Monitor User Guide](#)

Element Electronics EM2PTAD14BS 14 Inch 1080p FHD Touchscreen Portable Monitor User Guide How to Use the Folio Case...



[DELTA ELECTRONICS UNOLite Indoor Air Quality Monitor User Guide](#)

DELTA ELECTRONICS UNOLite Indoor Air Quality Monitor Specifications Power Adapter: CE Certified, 12VDC, 1A, 12W Communication Protocols: Modbus,...

[ERNI ELECTRONICS 224562 TE Connectivity ELECTRONICS Datasheet](#)



ERNI ELECTRONICS 224562 TE Connectivity

ELECTRONICS Datasheet Product Information

Designation Description Ansaughaube Hood

Abspulrichtung Reel off Direction Leiterplatten-Layout...

Delta
Electronics

Delta Electronics, DOP-100 Series, DOP-100 Series HMI Touchscreen, HMI Touchscreen,
touchscreen

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.