

digitech XC0412 Temperature Humidity Weather Station



digitech XC0412 Temperature Humidity Weather Station User Manual

[Home](#) » [Digitech](#) » digitech XC0412 Temperature Humidity Weather Station User Manual 

Contents

- [1 digitech XC0412 Temperature Humidity Weather Station](#)
- [2 Specifications](#)
- [3 OVERVIEW MAIN UNIT](#)
- [4 LCD DISPLAY](#)
- [5 GETTING STARTED](#)
- [6 IMPORTANT NOTE](#)
- [7 SPECIFICATIONS](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

digitech

digitech XC0412 Temperature Humidity Weather Station




Specifications

- **Product Name:** Temperature/Humidity Weather Station
- **Model:** XC0412
- **Wireless:** Thermo-Hygro Sensor
- **LED:** Indicator
- **LCD;** Display
- **Wall Mounting:** Holder
- **Reset:** Key
- **Channel Slide:** Switch (1-3)
- **Battery Compartment:** (2 x AA batteries)
- **Effective Transmission Range:** 30m

Thank you for selecting this delicate wireless weather station. Utmost care has gone into the design and manufacture of the clock. This manual is used for the AU version. Please read the instructions carefully according to the version you purchased and keep the manual well for future reference.

OVERVIEW MAIN UNIT



1. LCD display

2. [HISTORY] key

1. In normal mode, press to display the past 24-hour pressure records.

3. [MEM] key

1. In normal mode, press to check maximum and minimum thermo-hydro readings, or press and hold for 3 seconds to delete both records.

4. [12/24 /] key

1. In normal mode, press to switch between 12 or 24-hour format of time display, or press and hold for 3 seconds to activate wireless sensor pairing mode.
2. In setting mode, press to decrease the setting values.

5. [CH /] key

1. In normal mode, press to switch between CH 1~3 of the outdoor sensor's weather display, or press and hold for 2 seconds to enter auto-cycle mode.
2. In setting mode, press to increase the setting values.

6. [TIME] key

1. In normal mode, press to switch between alarm 1 and alarm 2, or press and hold for 2 seconds to enter time setting mode.
2. In time setting mode, press to stop the setting.

7. [ALARM] key

1. In normal mode, press to turn on/off alarm 1 and alarm 2, or press and hold for 2 seconds to enter alarm setting mode.
2. In alarm setting mode, press to stop the setting.

8. [RESET] key

1. In case of malfunction, press to reset the main unit.

9. [SNOOZE / LIGHT] key

1. When an alarm is sounding, press to stop the current alarm and enter snooze.
2. When an alarm is sounding, press and hold for 2 seconds to stop the current alarm, the clock will sound again in the next day.

10. [BARO] key

1. In normal mode, press to switch between hPa (mb) and inHg, or press and hold for 3 seconds to enter the “rel” and “abs” switch mode.


11. [°C / °F] key

1. In normal mode, press to switch between Celsius and Fahrenheit.

12. Battery compartment

LCD DISPLAY

1. Time section
2. Weather forecast & baro pressure section
3. Ch. 1-3 Temperature & humidity reading
4. Indoor temperature & humidity reading
5. Calendar and alarm section
6. Moon phase section



WIRELESS THERMO-HYGRO SENSOR

1. LED indicator

1. Flashes when the remote unit is transmitting.

2. LCD display

1. to show the detected temperature or humidity of the sensor.

3. Wall mounting holder

4. [RESET] key


1. Press to restart the sensor.

5. [CHANNEL] slide switch

1. Assign the transmitter to Channel from 1 to 3.

6. Battery compartment

1. Accommodates 2 x AA size batteries.



GETTING STARTED

WIRELESS SENSOR

1. Remove the battery door.
2. Insert 2 x AA-size batteries into the battery compartment. Make sure you insert them the right way according to the polarity information marked on the battery compartment.
3. Replace the battery door.

NOTE: The sensor will now start transmitting signals, and the LED indicator will flash.

- Once the channel is assigned to a sensor, you can only change it by removing the batteries or resetting the sensor, you also need to press and hold the [12/24 / V] key for 3 seconds on the main unit to pair this sensor.
- After replacing the batteries of the wireless sensor or the unit fails to receive the wireless sensor signal of a specified channel, you need to press and hold the [12/24 / V] key for 3 seconds on the main unit to pair this sensor again.
- Avoid placing the transmitter in direct sunlight, rain, or snow.
- The building material and the position of the receiver and transmitter affect the effective range. So try various locations to obtain the best result.
- Place the units away from metal objects and electrical appliances to minimize interference. Position the receiver and transmitter within the effective transmission range: of 30m in usual circumstances.

MAIN UNIT

1. Remove the battery door and insert 2 x AA batteries into the battery compartment, according to the polarity mark on the battery compartment.
2. After the batteries are installed, all LCD segments will be shown.
3. Press the [RESET]
4. Replace the battery door.

NOTE: If no display appears on the LCD after installing the batteries, press the [RESET] key by using a metal wire.

VIEW MULTIPLE WIRELESS SENSOR CHANNELS

1. In normal mode, press **[CH / ^]** key to switch the display between CH 1~3.
2. In normal mode, press and hold **[CH / ^]** key for 2 seconds to enter auto-cycle mode, After a “bi” sound, it will alternately display the CH 1~3 at 4-second intervals.
3. During auto-cycle mode, press **[CH / ^]** key again to stop auto-cycle mode and display the current channel.

TIME AND CALENDAR SETTING

1. In normal mode, press and hold [TIME] key for 2 seconds to enter date and time setting mode.
 2. Press **[CH / ^]** or [12/24 / V] key to adjust the setting.
 3. Press [TIME] key to enter the next setting.
 4. The setting sequence: year → DM / MD → month → day → DST AUTO / OFF → hour → minute → second → weekday language.
 5. Press [TIME] key or leave the unit for 30 seconds to complete the setting and return to normal mode.
- Weekday language GB → FR → DE → ES → IT

ALARM TIME SETTING AND DISPLAY

1. In normal time mode, press [TIME] key to select alarm 1 or alarm 2.
2. In alarm1/alarm2 mode, press and hold [ALARM] key for 2 seconds until alarm hour
3. Press **[CH / ^]** or [12/24 / V] key to change the value
4. Repeat the above operations to set the alarm time in this order: Hour → Minute → Ice pre-alarm on/off.
5. Press [ALARM] key or leave the unit for 30 seconds to return to normal mode.



USING ALARM AND SNOOZE FUNCTION


1. Set the desired alarm time as described in the previous section.
2. Or press [ALARM] key to turn on alarm 1, press it again to turn on alarm 2, and press it thrice to turn on both alarm 1 and alarm 2, with the alarm icons “ ” and / or “ ” displays on the LCD. Press it again to turn off both alarm 1 and alarm 2, with the icons disappear.
3. When the clock reaches the alarm time, the alarm sound will start.



Where it can be stopped by following operation

- **a)** Auto-stop after 2 minutes alarming if without any operation and the alarm will activate again in the next day.
- **b)** By pressing the [SNOOZE / LIGHT] key to enter snooze the alarm will sound again after 5 minutes.
- **c)** By pressing and holding the [SNOOZE / LIGHT] key for 2 seconds to stop the alarm and will activate again in the next day
- **d)** By pressing the [ALARM] key to stop the alarm the alarm will activate again the next day.

NOTE:

- The alarm function will turn on automatically once you set the alarm time.
- The snooze could be used continuously in 24 hours.



- During the snooze, the alarm icons “ ” and / or “ ” will keep flashing.
- The ice pre-alarm will be activated when the alarm 1 and / or 2 is on.
- Once the ice pre-alarm activates, the preset alarm will sound 30 minutes earlier if the outdoor temperature is below -3°C.
- To activate the ice pre-alarm function, pls ensure:
 - **a.** Turn on the ice pre-alarm function in the alarm setting mode.
 - **b.** Turn on the corresponding alarm.

READING INDOOR/OUTDOOR TEMPERATURE & HUMIDITY FUNCTION

In normal mode, press [°C / °F] key to switch between °C /°F temperature unit. The temperature and humidity will display “Hi / Lo / —” on the conditions in the following chart




Area	Condition	Display
Temperature	Temperature < -40°C	LO
	Temperature > 70°C	HI
Humidity	Humidity < 20%	LO
	Humidity > 90%	HI
	Temperature < -40°C or > 70°C	—

NOTE:

- If no signals are received or the transmission is interfered, “- -” will appear on the LCD.
- Relocated the clock or transmitter in other positions and made sure the transmission is within the effective range of 30m approx.

BARO, TEMPERATURE AND HUMIDITY TREND

The Barometric pressure, temperature, and humidity trend indicator shows the trends of changes in the forthcoming few minutes. Arrows indicate a rising, steady or falling trend.

Arrow indicator			
Trend	Rising	Steady	Falling

BAROMETRIC/ATMOSPHERIC PRESSURE

SELECT THE PRESSURE DISPLAY MODE

Press and hold the [BARO] key for 2 seconds to enter the select model that allows you to select between:

- **abs** — the absolute atmospheric pressure of your location.
- **rel** — the relative atmospheric pressure based on the sea

TO SET RELATIVE ATMOSPHERIC PRESSURE VALUE

1. Get the atmosphere pressure data of the sea level (it is also the relative atmosphere pressure data of your home area) through the local weather service, internet, and other weather channels.
2. Press and hold [BARO]
3. Press **[CH / ^]** or [12/24 /] key to switch to “real” mode.
4. Press [BARO] key once again until the “real” atmosphere pressure digit flashes.
5. Press **[CH / ^]** or [12/24 /] key to change its value.
6. Press [BARO] key to save and exit the setting mode, or let it exit automatically 30 seconds later without pressing any key.







TO SELECT THE MEASUREMENT UNIT FOR THE BAROMETER Use the [BARO] key to change the unit between hPa (mb) / inHg.

NOTE:

- When powering up the main unit, it will display the relative pressure reading and the default value is 1013 MB/hPa (29.91 inHg), which refers to the average atmosphere pressure.
- When you change the relative atmosphere pressure value, the weather indicators will change along with it.
- The relative atmosphere pressure is based on the sea level, but it will change with the absolute atmosphere pressure changes after operating the clock for 1 hour.

WEATHER FORECAST

The built-in barometer can notice atmosphere pressure changes. Based on the data collected, it can predict the weather conditions in the forthcoming 24 ~ 72 hours

					
Sunny	Partly Cloudy	Cloudy	Rainy	Stormy	Snowy

Note

1. The accuracy of a general pressure-based weather forecast is about 70% to 75%.
2. The weather forecast is meant for the next 24 ~ 72 hours, it may not necessarily reflect the current situation.
3. The Snowy weather forecast is not based on the atmospheric pressure, but based on the temperature of the current channel. When the outdoor temperature is below -3°C, the Snowy weather indicator will be displayed on the 24-HOUR FORECAST display section.

PAST 24 HOURS HISTORY PRESSURE RECORD

- The current and historical atmosphere is shown near the 24-HOUR FORECAST section.
- To check the pressure history in a particular hour during the past 24 hours, press the [HISTORY] key. Each press on the key will go back by an hour.
- Under the pressure history mode, press any key (except
- [HISTORY] key) to go back to the normal mode, or let it exit automatically 30 seconds later without pressing any key.











MAX / MIN RECORD

The main unit preserves the MAX / MIN weather data records since the last manual reset.

1. In normal mode, press [MEM] key once to show the indoor & current outdoor channel maximum temperature and humidity records.
2. Press [MEM] key repeatedly to show the minimum records.
3. Press [MEM] key again to exit.
4. To erase all the MAX / MIN records, press and hold [MEM] key for 3 seconds.


MOON PHASE

The main unit can show the northern hemisphere moon phase status, below is the table which illustrates how the moon will appear on the main unit.


Moon Phase Icon	Description	Moon Phase Icon	Description
	New Moon		Full Moon
	Waxing Crescent		Waning Gibbous
	First quarter		Third quarter
	Waxing Gibbous		Waning Crescent

LOW BATTERY ICON



When the battery indicator “” appears on the clock section or the LCD becomes dim, replace it with 2 new AA



size batteries at once; If the low battery indicator “”, appears in the outdoor section, it indicates that the battery power of the transmitter is not enough, and you should replace with 2 x AA size batteries at once.

IMPORTANT NOTE

- This main unit is intended to be used only indoors.
- Do not subject the unit to excessive force, shock, dust, temperature, or humidity.
- Do not cover the ventilation holes with any items such as newspapers, curtains, etc.
- Do not immerse the unit in water. If you spill liquid over it, dry it immediately with a soft, lint-free cloth.
- Do not clean the unit with abrasive or corrosive materials.
- Do not tamper with the unit's internal components. This invalidates the warranty.
- Only use fresh batteries. Do not mix new and old batteries.
- Do not dispose of old batteries as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

Attention! Please dispose of used units or batteries in an ecologically safe manner.
Technical specifications and user manual contents for this product are subject to change without notice.

SPECIFICATIONS

MAIN UNIT

Dimensions (W x H x D)	85 x 143.5x 51mm
Main power	2 x AA size 1.5V batteries
Barometer display range	540 to 1100hPa (mb), 15.95 to 32.49inHg
Operating temperature range	-5°C to 50°C (23°F to 122°F)
Display temperature range (In / Outdoor)	-40°C to 70°C (-40°F to 158°F)
Display humidity range (In / Outdoor)	RH 20% to 90 %
Resolution of temperature	1 decimal place of °C/°F (above -10°C / °F) Integer of °C /°F (below -10°C / °F or above 100 °F
Resolution of humidity	1%
The number of sensors support	Up to 3 units

WIRELESS SENSOR

Dimensions (W x H x D)	65 x 100 x 35mm
Main power	2 x AA size 1.5V batteries (Lithium battery recommended for low-temperature environment)
Operating temperature range	-20°C to 60°C (-4°F to 140°F)
Operating humidity range	RH 1% to 99 % (non-condensing)
RF frequency	433MHz
RF transmission range	30 meters

FAQ

- **Q: How do I change the channel of the outdoor sensor's weather display?**
 - A: In normal mode, press the [CH /] key to switch between CH 1~3 of the outdoor sensor's weather display.
- **Q: How do I activate wireless sensor pairing mode?**
 - A: In normal mode, press and hold the [12/24 /] key for 3 seconds on the main unit to activate wireless sensor pairing mode.
- **Q: How do I check the past 24 hour pressure records?**
 - A: In normal mode, press the [HISTORY] key to display the past 24 hour pressure records.
- **Q: How do I check the maximum and minimum thermo-hydro readings?**
 - A: In normal mode, press the [MEM] key to check the maximum and minimum thermo-hydro readings. Press and hold for 3 seconds to delete both records.
- **Q: How do I switch between a 12 or 24 hour format of time display?**
 - A: In normal mode, press the [12/24 /] key to switch between the 12 or 24-hour format of time display. Press and hold for 3 seconds to activate wireless sensor pairing mode.


- **Q: How do I decrease the setting values?**
 - A: In setting mode, press the [12/24 /] key to decrease the setting values.
- **Q: How do I increase the setting values?**
 - A: In setting mode, press the [CH /] key to increase the setting values.
- **Q: How do I switch between alarm 1 and alarm 2?**
 - A: In normal mode, press the [TIME] key to switch between alarm 1 and alarm 2. Press and hold for 2 seconds to enter time setting mode.
- **Q: How do I turn on/off alarm 1 and alarm 2?**
 - A: In normal mode, press the [ALARM] key to turn on/off alarm 1 and alarm 2. Press and hold for 2 seconds to enter alarm setting mode.
- **Q: How do I stop the current alarm and enter snooze?**
 - A: When the alarm is sounding, press the [SNOOZE / LIGHT] key to stop the current alarm and enter snooze.
- **Q: How do I stop the current alarm completely?**
 - A: When the alarm is sounding, press and hold the [SNOOZE / LIGHT] key for 2 seconds to stop the current alarm. The clock will sound again in the next day.
- **Q: How do I switch between hPa (mb) and inHg?**
 - A: In normal mode, press the [BARO] key to switch between hPa (mb) and inHg. Press and hold for 3 seconds to activate the barometric pressure trend graph display.

Distributed by:

TechBrands by Electus Distribution Pty. Ltd.

- **ADDRESS:** 320 Victoria Rd, Rydalmere NSW 2116 Australia
- **Ph:** 1300 738 555
- **Int'l:** +61 2 8832 3200
- **Fax:** 1300 738 500
- www.techbrands.com
- Made in China

Documents / Resources

	<p>digitech XC0412 Temperature Humidity Weather Station [pdf] User Manual XC0412 Temperature Humidity Weather Station, XC0412, Temperature Humidity Weather Station, Humidity Weather Station, Weather Station, Station</p>
---	--

References

-  [Manual-Hub.com](https://www.manual-hub.com) - Free PDF manuals!
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.