



DoreMidi MIDI HUB-8 Box(HUB-8) Instruction Manual

[Home](#) » [DoreMidi](#) » DoreMidi MIDI HUB-8 Box(HUB-8) Instruction Manual 

Contents

- [1 DoreMidi MIDI HUB-8 Box\(HUB-8\)](#)
- [2 Introduction](#)
- [3 Appearance](#)
- [4 Connection](#)
- [5 Product Parameters](#)
- [6 Precautions](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



DoreMidi MIDI HUB-8 Box(HUB-8)




Introduction

The MIDI HUB 8 box (HUB 8) is a high-performance USB 3.1 MIDI hub designed by DOREMiDi. The USB of HUB 8 is a USB3.1 super high-speed interface with a communication speed of 10Gbps (1.25GB/s). HUB 8 has 2 USB 3.1 HOST ports, which can be connected to USB MIDI instruments and other USB devices. It has 6 x6 MIDI DIN ports and can be connected to devices with MIDI DIN ports. Each port has 16 channels of standard MIDI for communication all standard MIDI commands. It is a good instrument interface hub.

Appearance

1. C IN 5V~9V: The product power supply interface uses a DC5.5*2.1 plug to power the product. The power supply voltage is 5V~ 9 VDC, and it has a power indicator.
2. USB 3.1 TO HOST: Standard USB 3.1 TO HOST interface, used to connect to a computer, no need to drive, plug and play, with connection indicator. The product can be powered through this interface.
3. update key: Supports firmware upgrades, and can upgrade the compatibility of special MIDI devices.
4. MIDI IN : The MIDI input interface uses a standard five pin MIDI cable to connect to the output interface of the MIDI device.
5. USB3.1 HOST : The super high speed USB3.1 host interface, through the USB A plug, connects MIDI devices with USB To HOST, and other USB devices.
6. IDI OUT : The MIDI output interface uses a standard five pin MIDI cable to connect to the input interface of the MIDI device.



Steps for usage

- **Power supply and connect to the computer**

Use a USB B to USB A cable to connect to the computer through the “USB 3.1 TO HOST” interface, and the power indicator will also light up.

- **External power supply**

If the USB interface power supply is insufficient, you need to supply power to the HUB 8 through an external power supply. Use DC5.5*2.1 plug power supply to supply power to HUB 8, the power supply voltage is 5V~9VDC

- **Connect the MIDI input device**

Use a standard five-pin MIDI cable to connect the MIDI input device to the MIDI IN interface of HUB 3.

- **Connect the MIDI output device**

Use a standard five-pin MIDI cable to connect the MIDI output device to the MIDI OUT interface of HUB 3.


- **Connect a USB MIDI device**

Connect a USB MIDI device or another USB device through the “USB 3.1 HOST” interface. After the connection is successful, the USB work indicator of the corresponding interface will light up.

- **Product upgrade**

If the product cannot be used on your instrument, please contact customer service (info@doremidi.cn) to upgrade the

Connection



After HUB 8 is connecting to the computer, there will be MIDI Group1 and MIDI Group2. MIDI Group1 corresponds to MIDI IN/OUT1~3 of HUB 8, and MIDI Group2 corresponds to MIDI IN/OUT4~6 of HUB 8. The mapping between the MIDI port name and HUB 8's MIDI interface is as follows:

MIDI Inputs/Outputs	MIDI Port Name	HUB-8 Interface
MIDI Inputs	MIDI Group1	MIDI IN1
	MIDIIN2 (MIDI Group1)	MIDI IN2
	MIDIIN3 (MIDI Group1)	MIDI IN3
	MIDI Group2	MIDI IN4
	MIDIIN2 (MIDI Group2)	MIDI IN5
	MIDIIN3 (MIDI Group2)	MIDI IN6
MIDI Outputs	MIDI Group1	MIDI OUT1
	MIDIOUT2 (MIDI Group1)	MIDI OUT2
	MIDIOUT3 (MIDI Group1)	MIDI OUT3
	MIDI Group2	MIDI OUT4
	MIDIOUT2 (MIDI Group2)	MIDI OUT5
	MIDIOUT3 (MIDI Group2)	MIDI OUT6

Product Parameters

Name	Description
Model	HUB-8
Size (L x W x H)	224*70*36mm
Weight	450g
USB Communication Rate	10Gbps(1.25GB/s)
USB Version	USB 3.1
USB TO HOST Interface	Super high-speed USB 3.1 interface, no driver required, plug and play
USB TO HOST Compatibility	Compatible with Windows, Mac, iOS, Android and other systems without driver, plug and play
USB HOST Interface	Super high-speed USB 3.1 interface, can connect USB MIDI devices, and other USB devices
USB HOST Compatibility	Compatible with USB 3.1 and below USB devices
USB HOST Power Supply Parameters	When using a single USB3.1 HOST interface, the power supply does not exceed 5V/3A
MIDI Interface	High-performance FTP processing with one input and one output 16-channel MIDI interface, Built-in high-speed Isolator
MIDI Compatibility	Compatible with all musical instruments with MIDI standard interface
Power In Interface	If the USB TO HOST power supply is insufficient, you can use DC 5V~9V to power the HUB-8
Stand-by Current	80~100mA
Working Power Consumption	Depends on the external USB and MIDI devices
Indicator Light	Power indicator, USB work indicator, MIDI DIN communication indicator
Firmware Upgrade	Support firmware upgrade

Precautions

1. This product contains a circuit board.
2. Rain or immersion in water will cause the product to malfunction.
3. Do not heat, press, or damage internal components.
4. Non professional maintenance personnel shall not disassemble the product.
5. If the product is disassembled or damaged by improper use, the warranty is not available.
6. The working voltage of the product's external power supply is 5V~9VDC. Using a voltage lower or more than this voltage may cause the product to fail to work or be damaged.

Questions & Answers

• Question: Does the computer need to install a driver?

Answer: The computer usually comes with a USB MIDI standard driver, no need to install additional drivers. If the computer prompts that the driver is not installed, it may be that the sound card is not installed properly. Please update or reinstall the computer sound card driver. Win10 MIDI driver solution:
<https://windowsreport.com/install-midi-drivers-pc/>

• Question: Can the MIDI OUT of HUB 8 supply power to MIDI devices?

Answer: 5V power supply can be provided, but the power supply is not high. If the external MIDI device requires a higher voltage, it is recommended to supply additional power.

• Question: Can the USB HOST interface supply power to USB musical instruments?

Answer: You can supply power, but pay attention to whether the power input of “POWER IN” can meet the working requirements of USB MIDI

• **Problem: The MIDI OUT/IN interface does not work.**

Answer: Please follow the steps below

- Make sure that the “MIDI OUT” of the product is connected to the “MIDI IN” of the musical instrument, and the “MIDI IN” of the product is connected to the “MIDI OUT” of the musical instrument.
- When all MIDI messages are output/input on the corresponding interface, the indicator light of the MIDI interface will flash.

• **Problem: The USB HOST interface does not work.**


Answer: Please follow the steps below:

- Ensure that the power indicator of “POWER IN” is on.
- Confirm that the instrument can work normally and the instrument’s USB interface is equipped with MIDI function (for example, the connection can recognize the MIDI device).
- Try to supply power to the product through “POWER IN” first, and then connect to the instrument through “USB HOST”, and see if the indicator light of “USB HOST” lights up.
- If the “USB HOST” indicator still doesn’t light up, or MIDI messages cannot be transmitted after it’s on, please contact customer service to solve it. If the problem is not resolved, please contact customer service.

Manufacturer:

Shenzhen Huashi Technology Co., Ltd Address: Room 9A, 9th Floor, Kechuang Building, Quanzhi Technology Innovation Park, Shajing Street, Baoan District, Shenzhen, Guangdong, China Post Code: 518104 Customer Service Email: info@doremidi.cn

Documents / Resources

	<p>DoreMidi MIDI HUB-8 Box(HUB-8) [pdf] Instruction Manual MIDI HUB-8 Box, HUB-8 Box</p>
---	--

References

- [W How to install midi drivers in Windows 10](#)