



EHX 219191 Big Muff Pi with Tone Wicker Fuzz Pedal User Manual

[Home](#) » [EHX](#) » EHX 219191 Big Muff Pi with Tone Wicker Fuzz Pedal User Manual 

Contents

- [1 EHX 219191 Big Muff Pi with Tone Wicker Fuzz Pedal](#)
- [2 BIG MUFF PI WITH TONE WICKER](#)
- [3 THEORY OF OPERATION](#)
- [4 CONTROLS](#)
- [5 WARRANTY INFORMATION](#)
- [6 FCC COMPLIANCE](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



EHX 219191 Big Muff Pi with Tone Wicker Fuzz Pedal



BIG MUFF PI WITH TONE WICKER

With Enhanced Tone Processing Congratulations on your purchase of the BIG MUFF Pi with TONE WICKER! The BMPTW is a battery operated distortion pedal that maintains the legendary Big Muff Pi sound while offering two powerful and dynamic tonal adjustments that are unique to any distortion or fuzz product found in the market today. The original BIG MUFF PI sound is maintained while new tonal variations deliver edgy and aggressive sonic possibilities.

THEORY OF OPERATION

The BIG MUFF Pi with TONE WICKER is an effects pedal designed to deliver all of the sonic power of the legendary Big Muff Pi while providing user editing capabilities that are unique to the Tone Wicker design. Wicker mode opens up the high-frequency bandwidth of your distortion sound delivering a top-end that is new and exciting. The Tone switch, when set to OFF, defeats the Big Muff's Tone knob yielding an extremely powerful distortion with a fire-breathing new Big Muff Pi character.

CONTROLS

- **Sustain knob** – As in the original Big Muff Pi, adjusts the amount of sustain and distortion.
Tone Knob – The Tone knob allows the musician to dial in just the right setting between deep bass and high treble.
Volume Knob – The volume knob sets the overall output level of the effect.
Wicker Switch – Activate Wicker mode by flipping the Wicker switch up to the ON position where the high-frequency bandwidth is opened up for a bright and clear top end. Set the Wicker switch to OFF to obtain the classic Big Muff Pi sound.
- **Tone Switch** – The Tone switch allows the user to activate the Tone knob or to completely bypass the tone circuitry. When the Tone switch is set to ON, the Tone knob is active, just like a standard Big Muff. When the Tone switch is set to OFF, the Tone knob and all of its circuitry is bypassed. This setting yields a totally new Muff distortion with a powerful drive and uncolored gain. High output with attitude. Please Note: When the Tone switch is set to OFF, turning the Tone knob will produce no change to your sound. In addition, it is normal for the output volume of your Big Muff Pi with Tone Wicker to increase when moving the Tone switch from ON to

OFF.

- **Status LED** – When the LED is lit; the BMPTW effect is active. When the LED is off, the BMPTW is in True Bypass mode. The Footswitch toggles between effect and bypass modes.
- **INPUT Jack** – This ¼" jack is the audio input to the BMW. The input impedance presented at this jack is 130 km.
- **OUTPUT Jack** – This ¼" jack is the audio output from the BMW. When the BMW is in Bypass mode, the OUTPUT jack is connected directly to the INPUT jack.
- **9V Power Jack** – The Big Muff with Tone Wicker is battery powered. You may use an external AC Adapter power supply instead of the battery. Connect the AC Adapter's plug to the 9V Power Jack at the top of the BMW. The power jack's polarity is center negative. The BMW requires a clean 9VDC power supply at 50mA.

We recommend the Electro-Harmonix US96DC-200BI power supply.

WARRANTY INFORMATION

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term. If you should need to return your unit for service within the warranty period, please contact the appropriate office listed below. Customers outside the regions listed below, please contact EHX Customer Service for information on warranty repairs at info@ehx.com or +1-718-937-8300. USA and Canadian customers: please obtain a Return Authorization Number (RA#) from EHX Customer Service before returning your product. Include with your returned unit: a written description of the problem as well as your name, address, telephone number, e-mail address, and RA#; and a copy of your receipt clearly showing the purchase date.

The United States & Canada

- EHX CUSTOMER SERVICE
- ELECTRO-HARMONIX
- c/o NEW SENSOR CORP.
- 47-50 33RD STREET
- LONG ISLAND CITY, NY 11101
- Tel: 718-937-8300
- Email: info@ehx.com

Europe

- JOHN WILLIAMS
- ELECTRO-HARMONIX UK
- 13 CWMDONKIN TERRACE
- SWANSEA SA2 0RQ
- UNITED KINGDOM
- Tel: +44 179 247 3258
- Email: electroharmonixuk@virginmedia.com

This warranty gives a purchaser specific legal rights. A purchaser may have even greater rights depending upon the laws of the jurisdiction within which the product was purchased.
To hear demos on all EHX pedals visit us on the web at www.ehx.com Email us at info@ehx.com


FCC COMPLIANCE

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment under FCC rules.

Documents / Resources

	EHX 219191 Big Muff Pi with Tone Wicker Fuzz Pedal [pdf] User Manual 219191, Big Muff Pi with Tone Wicker Fuzz Pedal
---	---

References

-  [Electro-Harmonix](#)