

Ekster PFMCCW Multi Use Trackable Card



Ekster PFMCCW Multi Use Trackable Card User Manual

[Home](#) » [Ekster](#) » Ekster PFMCCW Multi Use Trackable Card User Manual 

Contents

- [1 Ekster PFMCCW Multi Use Trackable Card](#)
- [2 Product Overview](#)
- [3 Quick Instructions](#)
- [4 Main Functions](#)
- [5 Instructions for Device Button](#)
- [6 Wireless Charging Instructions](#)
- [7 Regulatory Safety Information](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)




Ekster PFMCCW Multi Use Trackable Card



Important tips: When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:

1. Change the phone's network, such as switching between WiFi and mobile network;
2. Factory Reset for the device: When the device is powered on, double-click the device button. The device will beep, then immediately long press the device button for eight seconds until the device beeps for the second time and the indicator light flashes. Release the button, Factory Reset is completed.
(Note: after long pressing the device button for 2 seconds, the device will sound "tick, tick, tick", and the indicator light near the button flashes. Do not release it. Continue to press and hold the button until the device emits a music for the second time, and the indicator light flashes. Release the button).
3. Pair with Find My app.

Product Overview



Quick Instructions

1. Turn on the device

Press and hold the button for 5 seconds, the device will beep and turn on.

2. Pair the device

- Open the Find My opp.
- Hold the device close to your iPhone•, top the Items tab, top+ and then Add Other Item.
- Top Connect.
- Type a name for your device, select on emoji.
- Top Agree to acknowledge that this item will be linked to your Apple" ID.
- Top Finish.

3. Enable Lost Mode

- Open the Find My opp, tap the Items tab, then tap your item.
- Under Lost Mode, tap Enable.
- Read the instructions, top Continue and enter a phone number or email address.
- Confirm the information, customize the lost message, and tap Activate.

4. Remove the device

- Open the Find My opp, top the Items tab, then top your item.
- Top Remove Item and then tap Remove to complete the operation.

Note: After removing the device in the opp, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and opp cannot be paired at this time. If you need to pair the device, you need to click the device button once, the device will ring and the light will flash once. At this point, the device enters the pairing state and can be re-paired with the opp.

Main Functions

1. Locate your item

If your missing item isn't nearby, the Find My app can still help you track it down using the Find My network – hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app.

2. Play Sound

- Open the Find My app, tap the Items tab, then tap your item.
- Click Play Sound, and the device will beep, so you can find the item easily.

Instructions for Device Button

1. Power on

Long press the button for five seconds, the device will beep, the light will flash three times, and the device will be turned on.

2. Device status confirmation

Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

3. The device enters the pairing state again

After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button once, the device will beep, and the light will flash once. At this time, the device enters the pairing state and can be paired with the app again.

4. Factory Reset

First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for eight seconds until the device beeps and the light flashes three times. Release the button to complete factory reset. The device can now be paired.

5. Power off

When the device is on, press the device button 5 times in 2 seconds. The device will beep, the light will flash three times, the device will be powered off.

Wireless Charging Instructions

1. There is a wireless charging location sign on the back of the device, which corresponds to being placed in the center of the wireless charger;
2. The red LED light is on during normal charging, and the green LED light is on when fully charged;
3. 1.2c charging, usually fully charged within 100 minutes when there is no power;
4. Full charge standby time, approximately 5-6 months.

European Union-Disposal Information

The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste.

When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Regulatory Safety Information

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN

Swallowing may lead to serious injury in as little as 2 hours or death due to chemical burns and potential perforation of the esophagus.

If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for assistance.

KEEP BATTERIES OUT OF REACH OF CHILDREN

- Keep in original package until ready to use
- Call a local poison control center for treatment information.
Australia: 13 11 26
- Canada: 1-[800-268-9017](tel:800-268-9017) (Ontario), 1-[800-567-8911](tel:800-567-8911) (BC), 1-[800-463-5060](tel:800-463-5060) (Quebec) US: [800-498-8666](tel:800-498-8666). Verify suitably. emergency call numbers for your country.
- Do not use if the compartment is not secure.
- Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.
- Risk of fire and burns.
- Do not recharge, disassemble, heat (-20°C +70°C) or incinerate.
Rated voltage 3V
Rated current ~175 mAh
- Immediately dispose of used batteries and keep away from children. Do NOT dispose of batteries in household trash.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.

Safety Statement

Article 12

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article 14

The application of low-power frequency electric machinery shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low-power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machinery and equipment for legal communications or industrial and scientific applications.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Legal notice

Use of the Works with Apple® badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple® Find My network product specifications and requirements. Apple® is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple®, Apple® Watch, iPad®, iPadOS®, macOS®, and watchOS® are trademarks of Apple® Inc., registered in the U.S. and other countries. IOS® is a trademark or registered trademark of Cisco® in the U.S. and other countries and is used under license.

FAQ

When can the device be located?

When an item is separated from its owner for a period of time, it can be found by other Apple® devices that are part of the Find My network, and the owner can start to get the location of the device.

How to confirm whether the device has been turned on?

Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

How is the device designed to discourage unwanted tracking?

If any Find My Network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPod, or iPad, Find My will send a notification to your Apple device. This feature is available on iOS 10 or iPadOS 14.5 or later.
2. If you don't have an iOS® device or a smartphone, a Find My network accessory that hasn't been with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.

How is my privacy protected?

Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple® or Proton Mail knows the location of your device or the identity of the device that helps find it.

Documents / Resources



[Ekster PFMCCW Multi Use Trackable Card](#) [pdf] User Manual

2BGPK-PFMCCW, 2BGPKPFMCCW, pfmcw, PFMCCW Multi Use Trackable Card, PFMCCW, Multi Use Trackable Card, Use Trackable Card, Trackable Card, Card

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.