



ENFORCER SK-B141-PQ Bluetooth Single Gang Keypad with Reader Installation Guide

[Home](#) » [ENFORCER](#) » ENFORCER SK-B141-PQ Bluetooth Single Gang Keypad with Reader Installation Guide 

ENFORCER®



Bluetooth Single-Gang
Keypad with Reader
SK-B141-PQ
Product Specifications



Contents

[1 What's in the Box:](#)

[2 Specifications](#)

[3 Sample Wiring Diagram](#)

[4 IMPORTANT NOTES](#)

[5 Single-Gang Keypad with Reader](#)

[6 Documents / Resources](#)

[6.1 References](#)

[7 Related Posts](#)

What's in the Box:

Single-Gang Keypad / Reader Reader

4x Mounting screws

4x Plastic wall anchors

12x Wire crimps

1x Diode 1x Varistor

1x SK-B141-PQ ENFORCER Bluetooth ®

1x Security screw bit


1x Quick Installation/Setup Guide

1x Product Specifications



Specifications

Operating voltage	9-25 VDC
Current Standby	55mA@12VDC, 30mA@24VDC
draw Active (max.)	100mA@12VDC, 55mA@24VDC
Form C	2.0A@30VDC
Outputs Tamper alarm	100mA@30VDC (solid state N.C.)
Egress input	N.O. Ground
Door sensor input	N.C. Ground
Proximity reader	EM 125kHz
IP Rating	IP65 Weather-resistant
Enclosure material	Zinc alloy
Operating humidity	0-95%, non-condensing
Operating temperature	4 ⁰ -122° F (-20 ⁰ -50° C)
Dimensions	3 ¹ / ₈ "x4 ¹³ / ₁₆ "x7 ⁷ / ₈ " (79x123x23 mm)
Weight	1-lb 3.8-oz (560g)

Sample Wiring Diagram




IMPORTANT NOTES

*To protect the relay, you must install the enclosed diode—with the cathode (striped end ) toward the positive side—for DC powered locks OR install the varistor (MOV, ) for AC powered locks and for † electromagnetic locks unless your lock has a diode/MOV built in (all SECO-LARM electromagnetic locks have built-in protection). Do not install both. Failure to install as directed will void the warranty. Download the Installation Manual and Administrator Guide from www.seco-larm.com for complete instructions. Use the blue wire for fail-secure applications and the yellow wire for fail-safe applications. Use electrical tape to insulate the end of any unused wire.




ENFORCER Bluetooth® Installation and Mounting

Single-Gang Keypad with Reader



Remove Back

Using the security bit, remove the screw and housing back.




Mark Holes for Drilling

Using the back, mark mounting and wiring holes.



5/16" (8mm)




At least
1 1/4" (3cm)



Drill Holes

Drill the five holes. The wiring hole should be at least $\varnothing 1 \frac{1}{4}$ " ($\varnothing 3$ cm).



1. Feed Wires into Wall

Push connected wires through the hole in the wall, taking care not to loosen any connectors.

2. Mount Back to Wall

Mount the back to the wall using the supplied screws and wall anchors or other screws.

3. Mount Keypad to Back

Slide the device to engage the tab on the top of the back, and secure with the security screw.

The Bluetooth ® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by SECO-LARM is under license. Other trademarks and trade names are those of their respective owners.

FCC/IC COMPLIANCE STATEMENT FOR BLUETOOTH MODULE FCC ID: K7TRB8762 IC ID: 2377ARB8762
THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT WARNING: Incorrect mounting which leads to exposure to rain or moisture inside the enclosure could cause a dangerous electric shock, damage the device, and void the warranty. Users and installers are responsible for ensuring that this product is properly installed and protected from moisture.

IMPORTANT: Users and installers of this product are responsible for ensuring that the installation and configuration of this product complies with all national, state, and local laws and codes. SECO-LARM will not be held responsible for the use of this product in violation of any current laws or codes.

California Proposition 65 Warning: These products may contain chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.



NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO LARM reserves the right to change specifications without notice.

SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2024 SECO LARM U.S.A., Inc. All rights reserved.

SECO-LARM® U.S.A., Inc.
16842 Millikan Avenue, Irvine, CA 92606
Phone: [949-261-2999](tel:949-261-2999) | [800-662-0800](tel:800-662-0800)
Website: www.seco-larm.com
Email: sales@seco-larm.com


 PITGW1
MA_SK-B141-PQ_240305.docx

Documents / Resources

 	<p>ENFORCER SK-B141-PQ Bluetooth Single Gang Keypad with Reader [pdf] Installation Guide</p> <p>SK-B141-PQ, SK-B141-PQ Bluetooth Single Gang Keypad with Reader, SK-B141-PQ, Bluetooth Single Gang Keypad with Reader, Single Gang Keypad with Reader, Gang Keypad with Reader, Keypad with Reader, with Reader, Reader</p>
--	---

References

- [La Armería de Madrid - fabricantes de armas y rifles](#)
- P65Warnings.ca.gov
- [User Manual](#)