



## essentiel EB\_SK-10-F Silent Keyboard User Guide

[Home](#) » [essentiel](#) » [essentiel EB\\_SK-10-F Silent Keyboard User Guide](#) 



### EB\_SK-10-F Silent Keyboard User Guide



Thank you for purchasing the Sweet Touch Boulanger keyboard. We pay particular attention to the RELIABILITY, EASE OF USE and DESIGN of our products. Your keyboard is equipped with silent keys for soft, discreet and responsive typing offering the user optimal comfort. We hope you will be completely satisfied with this EB\_SK- 10-F keyboard.

## Contents

- [1 Package contents](#)
- [2 Technical features](#)
- [3 Connection](#)
- [4 Using the multimedia keys](#)
- [5 Instructions for use](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

## Package contents

- 1 wired EB\_SK-10-F keyboard with a USB cable
- 1 user guide

## Technical features


Plug and play Installation	No additional software required
Number of keys	105
Multimedia keys	12
Inclination	7-8 ° (fixed)
Power supply	5 V 50 mA
Cable length	1.5 m PVC cable
USB compatibility	2.0
Required configuration	Compatible with Windows 7/8/10 and Mac OS (but only available for standard keys under Mac OS system)
Dimensions and weight	423 x 121 x 30 mm 436g ± 50g (with cable)
Storage temperature	-20°C to +60°C
Operating temperature	-5°C to +40°C

## Connection

- Plug the keyboard's USB plug into a free USB port on your computer.
- The computer automatically detects and installs new hardware.
- Your keyboard is then ready for use.

## Using the multimedia keys

This keyboard has 12 multimedia keys that give you direct access to multimedia controls such as volume control or play and skip functions.



	+		Open the default media player
	+		Decrease the volume
	+		Turn up the volume
	+		Mute
	+		Go back to the previous track or file
	+		Skip to the next track or file
	+		Play / pause a track or file
	+		Stop playing a track or file
	+		Launch your default browser
	+		Open the default e-mail
	+		Access the file explorer
	+		Access internet browser favourites
	+		Windows lock function If the Windows key does not seem to work anymore, check that the key is not locked by pressing Fn + Windows to lock or unlock

## Warning icons

Button	Indicator light	Description
	Locking the numeric keypad	When the light is on, the numeric keypad is active. When the indicator light is off, the alternate functions of the numeric keypad can be used.
	Caps lock	The indicator lights up when caps lock is on and only allows you to use capital letter entry or alternate key functions.
	Scrolling	The indicator lights up when the scroll lock is activated and allows you to scroll the page with the arrow keys regardless of the cursor position.

## Instructions for use

BEFORE USING THE APPLIANCE FOR THE FIRST TIME, PLEASE READ THESE SAFETY INSTRUCTIONS CAREFULLY AND SAVE THEM FOR FUTURE REFERENCE.

- This keyboard is designed for indoor use with a computer that has a USB port.
- Do not place the keyboard near a window where it is exposed to direct sunlight.
- Do not place the keyboard in places where it will be exposed to splashing water, humidity, or extreme heat.
- Do not use it with wet hands.
- Do not place heavy objects on the keyboard.
- Supervise children to make sure they do not play with the keyboard or its cable.
- Make sure that the cable is positioned so that a child or animal cannot pull on it or become entangled in it.
- Do not let the cable hang over the edge of a desk.
- Handle the keyboard with care.
- Avoid subjecting the keyboard to excessive knocks or vibrations. Do not shake it or drop it.
- Do not press the keys excessively or repeatedly. Do not use your fists or any other object to press the keys.  
This type of damage is the main cause of premature keyboard malfunction.
- Do not attempt to disassemble, modify, adjust, or repair the keyboard.
- Clean the exterior surface of the keyboard by wiping it with a cloth and a mild cleaning solution. Make sure that no liquid enters the keyboard.
- Do not use any solvents, such as gasoline or alcohol, and any abrasive cleansers or sponges.

## RSI Syndrome

Repetitive Stress Injury (RSI) syndrome is an injury caused by repeated small movements, such as frequent typing, writing text messages, or using a mouse. Typical symptoms are pain in the fingers, wrist, elbow, or neck.

### To prevent RSI syndrome from occurring, we advise you to:

- Organise your workstation in an ergonomic way.
- Position the keyboard and mouse so that your arms are placed close to your body at a 90 degree angle.
- Make sure your wrists are supported and keep them aligned horizontally with your fingers and forearms.
- Take regular short breaks to stretch your wrists, arms and shoulders.
- Make sure your feet are flat on the floor and your back is straight and supported.

All information, drawings, sketches and images in this document are the sole property of SOURCING & CREATION.

SOURCING & CREATION reserves all rights relating to its trademarks, creations and information. Any copy or reproduction, by any means whatsoever, will be deemed and considered counterfeit.

## Documents / Resources