




# EXTECH DV25 Dual Range AC Voltage Detector + Flashlight User Manual

[Home](#) » [EXTECH](#) » EXTECH DV25 Dual Range AC Voltage Detector + Flashlight User Manual 

# EXTECH®

DV25 Dual Range AC Voltage Detector + Flashlight  
User Manual



## USER MANUAL

Model DV25 Dual Range AC Voltage Detector + Flashlight

### Contents

- [1 Safety](#)
- [2 Specifications](#)
- [3 Operating Instructions](#)
- [4 BATTERY](#)
- [INSTALLATION](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)
- [6 Related Posts](#)

## Safety

**WARNING:** Risk of Electrocution. Before use, always test the Voltage Detector on a known live circuit to verify

proper operation

**WARNING:** Risk of Electrocution. Keep hands and fingers on the body of the probe and away from the probe tip  
**CAUTION:** Read, understand, and follow Safety Rules and Operating Instructions in this manual before using this product.

Do not attempt to repair this unit. There are no user-serviceable parts.

Do not expose the unit to extreme temperatures or high humidity

Do not use the unit if it is wet or damaged

Do not apply more than the rated voltage between the probe tip and ground.

Do not operate with the case open



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present




Double insulation

## Specifications

Voltage Sensitivity	100V to 1000V AC, 50/60Hz 24V to 1000V AC, 50/60Hz
Detection distance	<0.2"
Operating Temperature	0 to 50°C (32 to 122°F)
Storage Temperature	20 to 60°C (-4 to 140°F)
Altitude	Operate below 2000 meters
Relative Humidity	80% up to 31°C, decreasing to 50% at 50°C
Battery	2 AAA batteries
Dimensions/Weight	159x25mm (6.25x1") / 42g (1.5oz)
Safety	For indoor use and in accordance with Overvoltage Category IV-1000V, Pollution Degree 2.

## Operating Instructions

### AC VOLTAGE DETECTION



1. For low voltage testing (24 to 100V), press and hold the 24V button (5). For standard electrical work (>100V) this is not necessary.
2. Touch the probe tip (7) to the hot conductor or insert it into the hot side of the electrical outlet.
3. If AC voltage is present, the detector cone will illuminate and the detector will beep.

**NOTE:** The detector is designed with high sensitivity. Static electricity or other sources of energy may randomly trip the sensor. This is a normal operation.

#### **FLASHLIGHT**

Press and hold the flashlight ON/OFF button (2) to turn on the flashlight (1).

#### **BATTERY INSTALLATION**

1. Remove the end cap (3) by inserting a small screwdriver in the pocket clip (4) to release the catch.
2. Insert two AAA batteries (observe polarity).
3. Replace the end cap



**NOTE:** If your meter does not work properly, check the battery to make sure that it is still good and that it is properly inserted. Never dispose of used batteries or rechargeable batteries in household waste. As consumers, users are legally required to take used batteries to appropriate collection sites, the retail store where the batteries were purchased, or wherever batteries are sold. Disposal: Do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical

and electronic equipment.



Copyright © 2021 Teledyne FLIR LLC


DV25-en-US\_2.3 11/21

All rights reserved including the right of reproduction in whole or in part in any form

ISO-9001 Certified

[www.extech.com](http://www.extech.com)

Documents / Resources

	<p><a href="#">EXTECH DV25 Dual Range AC Voltage Detector + Flashlight</a> [pdf] User Manual DV25, Dual Range AC Voltage Detector Flashlight, DV25 Dual Range AC Voltage Detector Flashlight</p>
---	--

References

- [🔗 Extech is now on FLIR.com | Teledyne FLIR](#)
- [🔗 Extech is now on FLIR.com | Teledyne FLIR](#)