



Faultless Electronic Z-Wave Deadbolt A29-WG014-S2 Manual

[Home](#) » [Faultless](#) » Faultless Electronic Z-Wave Deadbolt A29-WG014-S2 Manual 

Contents

- 1 Faultless
- 2 Electronic Z-Wave Deadbolt
 - 2.1 SKU: A29-WG014-S2
 - 2.2 Quickstart
 - 2.3 Important safety information
 - 2.4 What is Z-Wave?
 - 2.5 Product Description
 - 2.6 Prepare for Installation / Reset
 - 2.6.1 Reset to factory default
 - 2.7 Inclusion/Exclusion
 - 2.7.1 Inclusion
 - 2.7.2 Exclusion
 - 2.8 Quick trouble shooting
 - 2.9 Association – one device controls an other device
 - 2.9.1 Association Groups:
 - 2.10 Configuration Parameters
 - 2.10.1 Parameter 1: Guiding code on/off
 - 2.10.2 Parameter 2: vacation mode on/off
 - 2.10.3 Parameter 3: volume on/off
 - 2.10.4 Parameter 4: auto-lock on/off
 - 2.10.5 Parameter 5: auto lock time 10-99
 - 2.11 Technical Data
 - 2.12 Supported Command Classes
 - 2.13 Explanation of Z-Wave specific terms
 - 2.14 Related Posts

Electronic Z-Wave Deadbolt

SKU: A29-WG014-S2



Quickstart

This is a
secure
Door Lock – Keypad
for
U.S. / Canada / Mexico.

Please make sure the internal battery is fully charged.

To add this device to your network execute the following action:

1.Press [SET] for 1 second.2.Programming Code(4-8 digits)3.Press the buttons # 9 0 #4.Include successfully (beep x 1)

Please refer to the
[Manufacturers Manual](#) for more information.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

Great Convenience Touch to activate, touch to lock Connect your Z-Wave smart home system and operate from anywhere Holds up to 25 user codes Holds up to 4 single-entry codes Vacation mode (deactivates all user codes temporarily) Auto-lock with adjustable delay (5 – 99 seconds) Back-up mechanical keyway Uncompromised Security ANSI Grade 2 quality lever set operates over 500,000 times ANSI A156.25 compliant – resistant to dust, rain, and corrosion under variable temperatures 4-digit random guiding code prevents code-probing Touch screen is temporarily disabled after 4 consecutive incorrect entries Easy Installation Easy installation with a Philips screwdriver Fits most standard door preparations Online video instruction available (please scan the QR code on this box)

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

1. Press and hold [SET] button while inserting the battery back. 2. Hold the set button until long beep has finished. 3. Restoring the lock to factory settings will remove its connection to your network and clear all devices from its association group. The reset procedure should only be used when the primary controller is missing or inoperable.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

1. Press [SET] for 1 second. 2. Programming Code (4-8 digits) 3. Press the buttons # 9 0 # 4. Include successfully (beep x 1)

Exclusion

1. Press [SET] for 1 second. 2. Programming Code (4-8 digits) 3. Press the buttons # 9 0 # 4. Exclude successfully (beep x 1)

Quick trouble shooting

Here are a few hints for network installation if things don't work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.

4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group NumberMaximum NodesDescription

1	5	Z-Wave Plus Lifeline
---	---	----------------------

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 1: Guiding code on/off

Value 0x00 =off0x01 =on

Size: 1 Byte, Default Value: 1

SettingDescription

0 – 1	0x00 =off0x01 =on
-------	-------------------

Parameter 2: vacation mode on/off

Value 0x00 =off0x01 =on

Size: 1 Byte, Default Value: 0

SettingDescription

0 – 1	0x00 =off0x01 =on
-------	-------------------

Parameter 3: volume on/off

Value 0x00 =off0x01 =on

Size: 1 Byte, Default Value: 1

SettingDescription

0 – 1	0x00 =off0x01 =on
-------	-------------------

Parameter 4: auto-lock on/off

Value 0x00 =off0x01 =on

Size: 1 Byte, Default Value: 0

SettingDescription

0 – 1	0x00 =off0x01 =on
-------	-------------------

Parameter 5: auto lock time 10-99

Value 0X0A~0X63= 10~99 Seconds

Size: 1 Byte, Default Value: 10

SettingDescription

10 – 99	10~99 Seconds
---------	---------------

Technical Data

Hardware Platform	ZM5202
Device Type	Door Lock – Keypad
Network Operation	Listening Sleeping Slave
Firmware Version	HW: 255 FW: 3.01:01.01
Z-Wave Version	6.71.03
Certification ID	ZC10-18116314
Z-Wave Product Id	0x0262.0x0003.0x0003
Supported Notification Types	Access ControlPower Management
Door Lock Type	Lever Handle
Security V2	S2_ACCESS_CONTROL
Frequency	XXfrequency
Maximum transmission power	XXantenna

Supported Command Classes

- Association Grp Info
- Association V2
- Battery
- Device Reset Locally
- Door Lock
- Manufacturer Specific
- Notification V3

- Powerlevel
- Security
- Security 2
- Supervision
- Transport Service V2
- User Code
- Version V2
- Zwaveplus Info V2

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announce that it is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.