

FERM ESM1010 Random Orbital Sander 430W User Manual

Home » FERM » FERM ESM1010 Random Orbital Sander 430W User Manual



Contents

- 1 FERM ESM1010 Random Orbital Sander
- 430W
- **2 SAFETY WARNINGS**
- **3 TECHNICAL DATA**
- **4 NOISE AND VIBRATION**
- **5 Vibration level**
- 6 DESCRIPTION (fig. A)
- **7 ASSEMBLY**
- 8 USE
- 9 Cleaning and maintenance
- **10 WARRANTY**
- 11 ENVIRONMENT
- 12 Documents / Resources
 - 12.1 References
- **13 Related Posts**



FERM ESM1010 Random Orbital Sander 430W



Thank you for buying this Ferm product. By doing so you now have an excellent product, delivered by one of Europe's leading suppliers. All products delivered to you by Ferm are manufactured according to the highest standards of performance and safety. As part of our philosophy we also provide an excellent customer service, backed by our comprehensive warranty. We hope you will enjoy using this product for many years to come.

SAFETY WARNINGS

WARNING

Read the enclosed safety warnings, the additional safety warnings and the instructions. Failure to follow the safety warnings and the instructions may result in electric shock, fire and/or serious injury. Keep the safety warnings and the instructions for future reference.

The following symbols are used in the user manual or on the product:

- · Read the user manual.
- · Risk of personal injury.
- · Risk of electric shock.
- Immediately remove the mains plug from the mains if the mains cable becomes damaged and during cleaning and maintenance.
- Wear safety goggles. Wear hearing protection.
- · Wear a dust mask.
- · Double insulated.
- Do not dispose of the product in unsuitable containers.

The product is in accordance with the applicable safety standards in the European directives.

Additional safety warnings for orbital sanders

Contact with or inhalation of dust coming free during use (e.g. lead-painted surfaces, wood and metal) can endanger your health and the health of bystanders. Always wear appropriate protective equipment, such as a dust mask. Always use proper dust extraction during use.

- Do not work materials containing asbestos. Asbestos is considered carcinogenic.
- Do not use the machine for sanding magnesium workpieces.
- Wear safety goggles. Wear hearing protection. If necessary, use other protective means, such as safety gloves, safety shoes, etc.
- Hold the machine by the insulated gripping surfaces where the accessory may contact hidden wiring or the
 mains cable. If the accessory contacts a ,live' wire, the exposed metal parts of the machine can also become
 ,live'. Risk of electric shock.
- Make sure that the workpiece is properly supported or fixed.
- Only use sanding paper that is suitable for use with the machine.
- Only use sanding paper with the correct dimensions. Make sure that the sanding paper is properly mounted.
- Inspect the sanding paper before each use. Do not use sanding paper that is worn because of prolonged use.
- Never put the machine down on a table or a workbench before it has been switched off.

Electrical safety

Always check that the voltage of the power supply corresponds to the voltage on the rating plate.

- Do not use the machine if the mains cable or the mains plug is damaged.
- Only use extension cables that are suitable for the power rating of the machine with a minimum thickness of 1.5 mm2. If you use a extension cable reel, always fully unroll the cable.

TECHNICAL DATA

- Mains voltage V~ 230
- Mains frequency Hz 50
- Power input W 430
- No-load speed min-1 5,000 13,000
- Protection class IP 20
- · Weight kg 2.1

NOISE AND VIBRATION

- Sound pressure (Lpa) dB(A) 77
- Acoustic power (Lwa) dB(A) 88
- Uncertainty (K) dB(A) 3
- Vibration m/s2 7.6
- Uncertainty (K) m/s2 1.5

Vibration level

The vibration emission level stated in this instruction manual has been measured in accordance with a standardised test given in EN 60745; it may be used to compare one tool with another and as a preliminary assessment of exposure to vibration when using the tool for the applications mentioned

using the tool for different applications, or with different or poorly maintainted accessories, may significantly

increase the exposure level

• the times when the tool is switched off or whenit is running but not actually doing the job, may significantly reduce the exposure level

Protect yourself against the effects of vibration by maintaining the tool and its accessories, keeping your hands warm, and organizing your work patterns


DESCRIPTION (fig. A)




Your orbital sander has been designed for sanding wood, metal, plastics and painted surfaces.

- 1. On/off switch
- 2. Dustbag
- 3. Speed adjustment wheel
- 4. Sanding pad
- 5. Main grip
- 6. Lock-on button
- 7. Dustbag connection

ASSEMBLY







Before assembly, always switch off the machine and remove the mains plug from the mains.

Mounting

- Mount sanding paper (8) with the required grain size onto the sanding pad (4). Make sure that the perforation in the sanding paper (8) corresponds with the perforation on the sanding pad (4).
- Use coarse sanding paper (grain 50) for sanding rough, uneven surfaces.
- Use medium sanding paper (grain 80) for removing the remaining scratches from the coarse sanding paper.
- Use fine sanding paper (grain 120) for finishing surfaces

Removing

Remove the sanding paper (8) from the sanding pad (4)

USE

The On/Off switch Fig. A

Switch the machine on by pressing the On/Off switch (1). When you release the On/Off switch (1) the machine will turn off.

Lock-on Button Fig. A

You can lock the On/Off switch (1) by pressing the On/Off switch (1) and then pressing the lock-on button (6). To release the switch-lock; shortly press the On/Off switch (1) again

Setting the speed (fig. A)

The speed adjustment wheel is used for setting the speed. The speed adjustment wheel can be set to 6 positions. The ideal speed depends on the required grain size and on the material to be worked.

dust extraction (fig. C)

- Insert the dustbag (9) into the dustbag connection (7).
- Turn the dustbag (9) clockwise until it locks into place.

Hints for optimum use

- · Clamp the workpiece.
- Firmly hold the machine with both hands.
- · Switch on the machine.
- Place the sanding pad with sanding paper on the workpiece.
- Slowly move the machine over the workpiece, firmly pressing the sanding pad against the workpiece.
- Do not apply too much pressure on the machine. Let the machine do the work.
- Switch off the machine and wait for the machine to come to a complete standstill before putting the machine down.

Cleaning and maintenance

Before cleaning and maintenance, always switch off the machine and remove the mains plug from the mains.

- · Regularly clean the housing with a soft cloth.
- Keep the ventilation slots free from dust and dirt. If necessary, use a soft, moist cloth to remove dust and dirt from the ventilation slots.
- Regularly clean the sanding pad to avoid inaccuracies during use.

- Replacing the sanding pad (fig. d)
- · In case of wear, the sanding pad must be replaced
- If necessary, remove the sanding paper.
- Loosen the screws (10) from the sanding pad (4).
- Remove the old sanding pad (4).
- Mount the new sanding pad (4).
- Tighten the screws (10) to the sanding pad (4)..

WARRANTY

Consult the enclosed warranty terms.

ENVIRONMENT

disposal

The product, the accessories, and the packaging must be sorted for environmentally friendly recycling.

Only for EC countries

Do not dispose of power tools into domestic waste. According to the European Guideline 2012/19/EU for Waste Electrical and Electronic Equipment and its implementation into national right, power tools that are no longer usable must be collected separately and disposed of in an environmentally friendly way. The product and the user manual are subject to change. Specifications can be changed without further notice.

Documents / Resources



<u>FERM ESM1010 Random Orbital Sander 430W</u> [pdf] User Manual ESM1010 Random Orbital Sander 430W, ESM1010, Random Orbital Sander 430W, Orbital Sander 430W, Sander 430W

References

• FERM Power Tools - Power to create

Manuals+,