

**Contents** [ [hide](#) ]

- [1 Flydigi Vader 3/3 Pro Game Controller](#)
- [2 INSTRUCTIONS FOR USE](#)
- [3 Connect With Computer](#)
- [4 Basic operations](#)
- [5 Specification](#)
- [6 Appearance](#)
- [7 Frequently Asked Questions](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

FLYDIGI

## Flydigi Vader 3/3 Pro Game Controller




## INSTRUCTIONS FOR USE

## Innovative Force-switchable Trigger

Toggle the back gear switch to switch the trigger gear

1. **Linear gear:** precise control, 9mm long key travel, Hall stepless magnetic induction, precision throttle
2. **Microswitch gear:** fast trigger, 0.3mm ultra-short key travel, mouse-level micro motion response, easy continuous shooting



## Flydigi Space Station For More Customize Setting

Visit Our official website [www.flydigi.com](http://www.flydigi.com) download “Flydigi Space Station”, you can customize buttons, macros, body feeling, trigger and other functions.

- **The trigger vibrates**

Switch trigger vibration, set vibration mode

- **Somatosensory mapping**

The motion can be mapped to a joystick/mouse, making shooting games more accurate

- **Joystick adjustment**

Set the center dead band and sensitivity curve



- **Light conditioning**


Set up a variety of light effects, adjust color and brightness


## Connect With Computer


### Wireless dongle connection

1. Plug the dongle into the computer's USB port

2. Dial the back gear to , press the  button, the controller will be connected automatically, and the first indicator light is solid white
- 3.




If the indicator is blue, press and hold the  key at the same time until the indicator turns white

4. The next time you use it, press the  button once, and the controller will be connected automatically

## Wired connection

Connect the computer and the controller through the USB cable, and the indicator light is solid white to indicate that the connection is successful

## BT connection


Turn the back mode gear to  and connect the Xbox Wireless Controller to your computer's BT Setting

## Connect to Switch

1. Click the controller icon on the Switch homepage to enter [Change grip/order]

2. Shift the back gear to **NS**




3. Press the  button, the controller will be connected automatically, and the first indicator light is solid blue

4. The next time you use it, press the  button once and the controller will automatically connect





**In Switch mode, the key and key-value mapping relationship is as follows**


|   |   |   |   |        |       |   |             |
|---|---|---|---|--------|-------|---|-------------|
| A | B | X | Y | SELECT | START |  | O           |
| B | A | Y | X | –      | +     | home page   | Screens hot |


**Connect an Android/iOS device**

1. Shift the back mode gear to

2. Press the  button once to wake up the controller




3. Turn on the device's Bluetooth, connect to the Xbox Wireless Controller, and the controller indicator
4. The next time you use it, press the  button once and the controller will automatically connect




## Basic operations

- **Power on:** Press the [Home] button once
- **Power off:** switch back gear; After 5 minutes of no operation, the controller will automatically turn off
- **Low battery:** The second LED flashes red
- **Charging:** The second indicator is solid red
- **Fully charged:** The second indicator is solid green


## Specification


| mode  | Applicable Platforms | Light   | Connection method | System requirements |
|---|----------------------|---|-------------------|---------------------|
|  | PC                   | Long press +X to switch to XInput mode, the indicator | Dongle/ Wireless  | Win 7 and Above     |

|   |                    |   |          |  |
|---|--------------------|---|----------|--|
|  | PC/Android/<br>iOS | tor is white Long press +<br>A to switch to D Input mo<br>de, the indicator is blue | BT/Wired | Win 7 and Abo<br>ve Android 10<br>and Above iO<br>S 14 and Abov<br>e |
| <b>NS</b>   | Switch             | Blue  | BT/Wired | Switch   |

- **X Input mode:** suitable for the vast majority of games that natively support controllers
- **D Input mode:** For emulator games that natively support controllers
- **D Input mode:** For emulator games that natively support controllers
- **Wireless RF:** Bluetooth 5.0
- **Service distance:** less than 10 meters
- **Battery information:** rechargeable lithium-ion battery, battery capacity 800mAh, charging time 2 hours, charging voltage 5V, charging current 800mA
- **Operating current:** less than 45mA when in use, less than 45μA in standby
- **Temperature range:** 5 °C ~ 45 °C use and storage

## Appearance





## The name and content of harmful substances in the product

| Toxic or Hazardous Substances and Elements    |    |    |    |    |     |      |
|---|----|----|----|----|-----|------|
| Part Name                                     | Pb | Hg | Cd | Cr | PBB | PBDE |
| PCB Board                                     |    |    |    |    |     |      |
| Shells  |    |    |    |    |     |      |
| Packaging                                     |    |    |    |    |     |      |
| Wires   |    |    |    |    |     |      |
| Polymer battery                               |    |    |    |    |     |      |
| Silicone                                      |    |    |    |    |     |      |
| Small structural parts such as metal and tape |    |    |    |    |     |      |

This form has been prepared in accordance with the provisions of SJ/T 11364

- O Indicates that the content of the hazardous substance in all homogeneous materials of this part is within the limit specified in GB/T 26572-2011 Require the following
- X Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the provisions of GB/T 26572-2011 The limited requirements

Scan QR code to read the user manual




## Frequently Asked Questions

How to upgrade the controller firmware?

Install the Feizhi space station on the computer, or install the Feizhi game hall on the mobile phone, and upgrade the firmware according to the software boot

## Documents / Resources

|   |   |
|---|---|
|  | <p><a href="#">Flydigi Vader 3/3 Pro Game Controller</a> [<a href="#">pdf</a>] User Manual</p> <p>Vader 3, Vader 3 Pro, Vader 3-3 Pro Game Controller, Pro Game Controller, Game Controller, Controller</p> |
|---|---|

## References

- [User Manual](#)

■ FLYDIGI

◆ controller, FLYDIGI, Game Controller, Pro Game Controller, Vader 3, Vader 3 Pro, Vader 3-3 Pro Game Controller

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*



Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.