

FOOING HZB-12-G Ice Maker Machine Counter Top Instruction Manual

Home » FOOING » FOOING HZB-12-G Ice Maker Machine Counter Top Instruction Manual







HZB-12/G INSTRUCTION MANUAL

It is important that you read these instructions before using your portable ice maker and we strongly recommend that you keep them in a safe place for future reference.

Contents

- 1 Your safety and the safety of others are very important.
- **2 GETTING TO KNOW YOUR UNIT**
- 3 Postion of control panel & function
- **4 USING YOUR ICE MAKER**
- **5 TECHNINCAL PARAMETERS & CIRCUIT DIAGRAM**
- **6 EXPLOSIVE DRAWINGS**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Your safety and the safety of others are very important.

We have provided many important safety messages manual and your appliance.

Always read and obey all safety messages.

This is the safety alert symbol:



All safety messages will follow the safety alert symbol and the word "DANGER" or "WARNING".





WARNING

These words mean:

You can be killed or seriously injured if you don' timmediate follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

PREPARING YOUR ICE MAKER FOR USE

When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons or property. Read all instructions before using any appliance.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not operate this, or any other appliance with a damaged cord.
 - If the supply cord is damaged, it must be replaced by the manufacturer or its service agent ora similarly qualified person in order to avoid a hazard.
 - This ice-maker must be positioned so that the plug is accessible.
 - Connect to properly polarized outlets only. No other appliance should be plugged into the same outlet. Be sure that the plug is fully inserted into the receptacle.
- Donotrun the power cord over carpeting or other heat insulators. Do not cover the cord. Keep cord away from traffic areas, and do not submerge in water.
- We do not recommend the use of an extension cord, as it may overheat and become a risk of fire. If you must use an extension cord, use No. 0.75mm2 minimum size and rated no less than 16A/250V~ with a plug.
- Unplug the ice maker before cleaning or making any repairs or servicing.
- Exercise caution and use reasonable supervision when appliance is used near children.
- Do not use your ice-maker outdoors. Place the ice-maker away from direct sunlight and make sure that there is

at least 10 cm of space between the back of your unit and wall. Keep a minimum distance of 10 cm on each side of your unit free.

- Do notuse other liquid to make the ice-cube other than water.
- Do not clean your ice maker with flammable fluids. The fumes can create a fire hazard or explosion.
- · Do nottip over.
- If the ice maker is brought in from outside in wintertime, give it afew hours to warm up to room temperature before plugging itin.
- This apptiance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance. This appliance must be earthed.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended to be used in household and similar applications such as
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.



Warning: Risk of fire/flammable materials used.

Pleaseaccording to local regulations regarding disposal of the appliance for its flammable blowing gas.

WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

WANING: Do not damage the refrigerant circuit.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process or ice harvesting process, other than those recommended by the manufacturer.

WARNING: Do not use other type of electrical appliances inside the ice-maker. WARNING:

This appliance must be earthed.

IMPORTANT:

The wires in this mains lead are colored in accordance with the following code:

Green or Green with a strip yellow: Grounding


Blue: Neutral Brown: Live

To avoid a hazard due to instability of the appliance, it must be placed at an even or flat surface.

GETTING TO KNOW YOUR UNIT

General instrucion

- 1. Ice scoop.
- 2. Ice full sensor
- 3. Ice basket
- 4. Top cover with transparent window
- Air exhausting
- 6. Water drain cap: at front btm side of the unit.
- 7. MAXIMUM WATER LEVEL: — Remove the ice basket, you can see the water level mark.




Postion of control panel & function

ControlPanel: Easy to use, visible functions touch display setting.

- A. Selected ice size displaying: Small and Large.
- B. Power indicator
- C. Ice-Fullindicator
- D .Water shortage indicator
- E. Button to turn on/off the unit.
- F. Button to select ice cube size.





Automatic self-cleaning program

Plugontheunit,press "ON/OFF" button on control panel for more than 5 seconds, to enter the self-Cleaning program need 30 minutes ,the "S, L" indicator flashes in turn during cleaning. After cleaning, Drain the water from the inner tank through the drainage outlet at the bottom of the machine.


UNPACKING YOUR ICE MAKER

- 1. Remove the exterior and interior packaging. Check if ice basket and ice scoop inside. If any parts are missing, please contact our customer service.
- 2. Remove the tapes for fixing ice shovel, ice basket & ice scoop. Clean the tank & ice basket.
- 3. Put the ice maker on level & flat counter top without direct sunlight and other sources of heat (i.e.: stove, furnace, radiator). Maker sure that there is at least 4 inches gap between the back & LH/RH sides with the wall.
- 4. Allow one hour for the refrigerant fluid to settle before plugging the ice maker in.
- 5. The appliance must be positioned so that the plug is accessible.

WARNING: fill with potable water only. Only use drinking water.

ASSEMBLE HANDLE

Rotate the handle to the same angle as the mounting hole on the machine, Put It onthe machine.



CONNECTING YOUR ICE MAKER

- * Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged please call our customer service.
- 1. This unit should be properly grounded for your safety. The power cord of this appliance is equipped with a three-prong plug which mates with standard three prong wall outlets to minimize the possibility of electric shock.
- 2. Plug your appliance into an exclusive, properly installed, grounded wall outlet. Do not under any circumstances, cut or remove the third (ground) prong from the power cord.
 - Any questions concerning power and/or grounding should be directed toward a certified electrician.
- 3. This appliance requires a standard 220-240Volt, 50Hz electrical outlet with good grounding means.

CLEANING AND MAINTAINING YOURICE MAKER

Before using your ice maker, it is strongly recommended to clean it thoroughly.

- 1. Take out the ice basket.
- 2. Clean the interior with diluted detergent, warm water and a soft cloth.
- 3. Then use the water to rinse the inside parts, and drain out the water by unplugging the drain cap on front bottom side.
- 4. The outside of the ice maker should be cleaned regularly with a mild detergent solution and warm water.
- 5. Dry the interior and exterior with a clean soft cloth.
- 6. When the machine is not to be used for along time, drain water completely & dry the interior.

USING YOUR ICE MAKER


- Open the cover, remove the ice basket and pour water into tank.
 Keep water level below the water level mark.
- 2. Press"ON/OFF" button on the control panel to begin the ice making cycle.
- 3. Select the ice cube size by pressing the "Select" button. If the room temperature is lower than 15°C, itis

- recommended to select small ice cube in order to avoid ice sticking together.
- 4. Theice making cycle lasts approx. 6 to 13 minutes, depending on seletion of ice cube size and the room temperature. The recommended room temperature is 10°C to 38°C.
- 5. If water pump can't inject water, the ice maker will stop automatically, and the "ADD WATER?" indicator will be on.Press "ON/OFF" button, fill water up to the max. water level markand press "ON/OFF" button again to turn on the unit again. Allow the refrigerant liquid inside the compressor at least 3 minutes to settle before restarting.
- 6. Theice maker stops when the ice basket is full and the "ICE FULL" indicator will be on.
 - **Warning:** Direct sunlight or sunlight reflection may cause infared sensor malfunction. If the unit doesn't stop even ice cubes obstruct sensor, move the unit where no sunlight.
- 7. Change water in the water reservoir every 24 hours to ensure a reasonable hygiene level. If unit isn't to be used, drain all the water and dry the tank.


PROBLEM	PROBLEM CAUSE	SOLUTION		
TROUBLESHOOT"ADD WATER" i ndicator is on.	Lack of Water.	Stop the ice maker, fill water, and press "CN/OFF" button again to restart the unit.		
"ICE FULL" indicator is on.	Ice is full in basket.	Remove ice from ice basket. Continuous press "Select" button 5 second s, the unit could make ice 10 cycles even " Ice" indicator is on.		
Ice cubes stick together.	The ice making cycle is too lo ng.	Stop the ice maker, and restart it when the ice blocks melt. Select the small size ice c ube selection.		
	Water temperature in inner ta nk is too low.	Replace the water. Temperature of water r ecommended at 8-32°C		
	Room temperature or water t emperature in inner tank is too high.	The room temperature should be 10-43 °C , water temperature should be 8-32°C		
Ice making cycle is normal but no i ce formed.	Refrigerant in cooling system leaks.	Verify by a qualified technician.		
	Pipe in the cooling system is blocked.	Verify by a qualified technician.		

TECHNINCAL PARAMETERS & CIRCUIT DIAGRAM

Model	HZB-12/G
Power	220-240v~/50Hz
Protection Type	I
Climate Type	SN/N/ST/T
Ice Making Current	0.8A
Ice Harvest Current	1.0A
Refrigerant	R600a/17g
Net Weight	6.2Kg
Vesicant	C5H10
Enclosure	Plastic



EXPLOSIVE DRAWINGS



S/N	Part description	Qty/ Per	S/N	Part description	Qty/ Per	S/N	Part description	Qty/ Per
1	Power cord	1	14	Evaporator	1	27	Stainless wire	1
2	plastic clip	1	15	Micro switch	2	28	Water Supply pipe	1
3	Back panel	1	16	Inner tank bracket, L H	1	29	Synchronous motor	1
4	Plate back support	1	17	Back btm panel	1	30	Condenser	1
5	DC water pump	1	18	Back top panel	1	31	DC Fan motor	1
6	Silicon pump sealing	1	19	Displaying PCB	1	32	Nylon plug drain	1
7	Handle	1	20	Touch pad	1	33	Copper tube filter	1
8	Control box cover	1	21	Front top panel	1	34	Rubber foot	3
9	Main PCB	1	22	Water filter	1	35	plastic bottom	1
10	Control box	1	23	Ice scoop	1	36	Compressor	1
11	Ice making box	1	24	Ice basket	1	37	Magnetism valve	1
12	Ice scoop link	2	25	Foaming asm	1	38	Internal Wire	1
13	Ice shovel	1	26	Inner tank bracket, R H	1			



Documents / Resources



<u>FOOING HZB-12-G Ice Maker Machine Counter Top</u> [pdf] Instruction Manual HZB-12-G Ice Maker Machine Counter Top, HZB-12-G, Ice Maker Machine Counter Top, Maker Machine Counter Top, Counter Top, Top

References

• User Manual

Manuals+,