



FRIGGA T7 Series Real Time Temperature User Manual

[Home](#) » [FRIGGA](#) » FRIGGA T7 Series Real Time Temperature User Manual 

Contents

- [1 FRIGGA T7 Series Real-Time Temperature](#)
- [2 Product Usage Instructions](#)
- [3 Appearance Instruction](#)
- [4 Display Instruction](#)
- [5 Instructions](#)
 - [5.1 Stop](#)
- [6 Salute Extraordinary](#)
- [7 FCC](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



FRIGGA T7 Series Real-Time Temperature



Specifications

- Indicator LED
- Start/Stop Key Display Info
- LCD Display
- Bluetooth Printing
- Sleep Mode (Flight Mode)
- Device ID

Product Usage Instructions

Start

Long press the Start/Stop button until “REC” is shown on the LCD interface. This indicates that the device is ready to monitor. The LCD interface will also display the record quantity.

Setting

You can change the thresholds and settings via the Frigga cloud platform. On the “Device Setting” page, you can:

- Change the temperature thresholds
- Add alarm notification personnel
- Share equipment with someone
- Set up position notification
- Set up automatic flight mode

Transport

Place the device into the goods and begin transportation.

Monitoring

Whether you have set up the device or not, you can monitor the temperature, humidity, location, and route through the Frigga cloud platform. The platform will notify relevant personnel by mail or SMS if the temperature exceeds the limit. It will also notify the presupposed person when the device reaches the designated location. Additionally, when the device arrives near the designated airport, it will enter flight mode automatically.

Stop

There are three ways to end the journey:

1. Long press the Start/Stop button until "REC" disappears from the LCD interface to stop the device.
2. Connect the device to a computer via a USB cable and export the PDF report from the device.
3. Using the cloud platform, inform the device to stop. The device will respond within one reporting interval in a good signal environment.

Report

When the recording is stopped, the device will automatically generate a PDF report. You can access this report directly by connecting the device to a PC via a USB cable. The Frigga cloud platform also backs up the entire transportation data, which can be viewed using the device ID.

FAQ

Q: What should I do if the device doesn't upload data to the cloud?

- A: Please confirm that the device is working properly and not in flight mode.

Q: What is the range of measurement for the device?

- A: Please ensure that the device is working within the specified range of measurement.

Q: Can I take apart the device by myself?

- A: No, please do not take apart the device by yourself.

Q: Can I put the device into liquid?


- A: No, please do not put the device into liquid.

Appearance Instruction



Note The AC code Activation code is in the back of the device.

Display Instruction




Instructions

To better experience the real-time monitoring (temperature & humidity, location, track routes), and real-time alarm

(SMS, email) of the Frigga wireless temperature recorder, it is recommended to register your business account on Frigga cloud platform's official website (cloud.friggatech.com) and then add the device ID to your account before starting the device.

Start

- Long press the “Start/Stop” button till “REC” has been showing on the LCD interface, and the device is ready to monitor.
- At the same time, the record quantity also will be shown on the LCD interface.
- (Using default thresholds or changing the thresholds via the Frigga cloud platform).




Setting

- Thresholds can be changed via the cloud platform. On the page “Device Setting”, we can:
- Change the temperature thresholds.
- Add alarm notification personnel.
- Share equipment with someone.
- Setting position notification.
- Set up automatic flight mode.



Transport

- Put the device into the goods and begin to transport.



Monitoring

- Whether you set up the device or not, you also can monitor the temperature, humidity, location, and route through the Frigga cloud platform.
- When the temperature is over the limit, the cloud platform will notify the relevant person by mail or SMS.
- Notify the presupposed person when the device reaches the designated location.
- When the device arrives near the designated airport, the device will enter the flight mode automatically.




Stop

Three ways to end the journey:

1. Long press the “Start/Stop” button till “REC” disappears from the LCD interface, and the device has been stopped.

①



2. Connect with the computer through a USB cable and then export the PDF report from the device.



3. Via the cloud platform, inform the device to stop, and the device will respond within one reporting interval in a good signal environment.



Report

1. When recording data, the device will generate a PDF report automatically. Via a USB cable connected to the PC can access it directly.
2. On the Frigga cloud platform, the whole transportation data will be backed up and can be viewed through the device ID.



Cautions

- Please read the following notes carefully before using them:
- When you find that the device doesn't upload the data to the cloud, Please confirm that the device is working properly or whether the device is in flight mode.
- Please confirm that the device is working in the range of measurement.
- Don't use external force to impact the device.
- Don't take apart the device by yourself.
- Please keep the device away from fire.
- Don't put the device into liquid.

Salute Extraordinary

Technical Support: support@dewav.com

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference,
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

Radiation Exposure Statement



To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with a minimum distance of 20cm from your body.

www.friggatech.com

Documents / Resources

	<p>FRIGGA T7 Series Real Time Temperature [pdf] User Manual 2ATWZ-T7X, 2ATWZT7X, T7 Series, T7 Series Real Time Temperature, Real Time Temperature, Time Temperature, Temperature</p>
---	---

References

-  [Frigga lot Platform](#)
-  [Frigga lot Platform](#)

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)