

**FUNLAB
FF04 Luminpad
Wired Switch
Controller**



FUNLAB FF04 Luminpad Wired Switch Controller User Guide

[Home](#) » [Funlab](#) » FUNLAB FF04 Luminpad Wired Switch Controller User Guide 

Contents

- [1 FUNLAB FF04 Luminpad Wired Switch Controller](#)
- [2 Frequently Asked Questions](#)
- [3 PRODUCT IDENTIFICATION](#)
- [4 Product Specification](#)
- [5 Connection Method](#)
- [6 TURBO Function](#)
- [7 Vibration Adjustment Function](#)
- [8 Lighting Control Instruction Light Button](#)
- [9 Macro and Mapping Function](#)
- [10 Support](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)

FUNLAB

FUNLAB FF04 Luminpad Wired Switch Controller



Frequently Asked Questions

Q: How do I adjust the vibration intensity on the controller?

A: Press the Vibration Button on the back of the controller and use the right button to increase vibration strength or the left button to decrease it.


Q: How do I control the LED lights on the controller?

A: Use the Light Control Button to switch between different lighting modes like Always-on Mode or Breathing Light Mode, as well as adjust brightness levels.

Q: How do I set up the Turbo function on the controller?

A: Follow the instructions provided in the manual to adjust turbo speed levels and methods using the TURBO Button.

PRODUCT IDENTIFICATION




Product Specification

Category	Specification
Transmission Medium	Bluetooth 2.1
Carrier Frequency	2.402-2.480GHz
Protocol	Bluetooth BT2.1+EDR
LED	42 LED Beads In total
Working Voltage	3.7V-4.2V
Working Temperature	-10°C~50°C
Storage Temperature	-20°C~70°C

Connection Method

1. From the HOME Menu, select System Settings, then Controllers and Sensors.
2. Set Pro Controller Wired Communication to On.



3. Insert the Switch console into the controller, aligning it with the Type-C port on the controller for connection.

TURBO Function

TURBO Setting

Press TURBO Button + A/B/X/Y/L/R/ZL/ZR/D-pad Button to set the TURBO Function

Take A Button for Example:

- (For the 1st time) Press TURBO Button + A Button to achieve Manual TURBO Function (Press and hold to launch continuously)
 - (For the 2nd time) Press the TURBO Button + A Button to achieve Automatic TURBO Function (Automatically continuous launch)
 - (For the 3rd time) Press the TURBO Button + A Button to clear TURBO Function (Clear)
- Note: Press and hold TURBO Button for 5 seconds (if the Vibration Intensity is not 0%, there will be a vibration cue) to clear all TURBO Functions.

TURBO Speed Adjustment

Speed Levels:

- Continuously launch 5 times per second (Level 1);
- Continuously launch 12 times per second (Level 2);
- Continuously launch 20 times per second (Level 3);



Adjusting Methods:

Press TURBO Button + "+", speed increases;

Press TURBO Button + "-", speed reduces.

Vibration Adjustment Function

- Press Vibration Button on the back of the controller to adjust the motor vibration intensity.

(Press the right button  to increase vibration strength, and the left button  to decrease vibration strength).

- There are 5 intensities: 100%, 75%, 50%, 30% and 0% (the default is 30%).
- After successful adjustment, the motor vibrates for 0.5 seconds at that intensity.
- Upon restarting the console, the controller maintains the vibration intensity set before shutdown.

Lighting Control Instruction Light Button


1. Single click  button: Always-on Mode.


Each click will change its color with the order: Red, purple, turquoise, orange, blue, white, and green.

2. Double-click  button: Breathing Light Mode.

1st time double-click: 7-color breathing light mode;

2nd time double-click: Light Off.

Press and hold  button + D-pad: Adjust the brightness.

Press and hold  button + upward D-pad: Increase the brightness.

Press and hold  button + downward D-pad: Decrease the brightness.

There are 4 levels: 25%, 50%, 75%, 100%.

Macro and Mapping Function

Macro Function-Macro Buttons

Press and hold M Button on the right and don't loosen, inputting the buttons you want to edit (up to 20 steps). The controller will have the vibration cue after loosening M Button on the right, and then press MR Button to trigger Macro Buttons;

Press and hold M Button on the left and don't loosen, inputting the buttons you want to edit (up to 20 steps). The controller will have the vibration cue after loosening M Button on the left, and then press ML Button to trigger Macro Buttons.

Buttons that Macro Function could edit are A/B/X/Y/L/R/ZL/ZR/L3/R3/+/-/D-pad Buttons and two Joysticks (can be used as a combo in the game).

Mapping Function-Programmable Buttons

Press and hold M Button on the right and don't loosen, inputting the single button you want to map. The controller will have the vibration cue after loosening M Button on the right, and then press MR Button to trigger Programmable Buttons;

Press and hold M Button on the left and don't loosen, inputting the single button you want to map. The controller will have the vibration cue after loosening M Button on the left, and then press ML Button to trigger Programmable Buttons;

Buttons that Mapping Function could edit are A/B/X/Y/L/R/ZL/ZR/L3/R3/+/-/D-pad Buttons.

Note:

1. M Button on the left only sets Programmable Buttons of the left controller;

M Button on the right only sets Programmable Buttons of the right controller.

2. With Memory Function;
3. Long-press the M Button on the left/right side of the controller. There will be a vibration cue upon releasing the finger. You can then clear the Macro and Mapping functions of the MR/ML Buttons.

Support

We promise to provide sustainable services for this controller, you can get more operation guidance support from our service channel and official web:

Website: www.funlabswitch.com

Instagram: funlab_official

Service: support@funlabswitch.com


Discord channel: **FUNLAB**



How-To Videos:



Documents / Resources

	FUNLAB FF04 Luminpad Wired Switch Controller [pdf] User Guide YS43, FF, FF04 Luminpad Wired Switch Controller, FF04, Luminpad Wired Switch Controller, W ired Switch Controller, Switch Controller, Controller
---	--

References

-  [FUNLAB Controller Official Store - Firefly Switch Controller&Luminous Joypad](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.