



GL iNet GL-MT3000 Beryl AX AX3000 Wifi 6 Router User Manual

[Home](#) » [GL iNet](#) » GL iNet GL-MT3000 Beryl AX AX3000 Wifi 6 Router User Manual 



Let's get started.
GL-MT3000 / Beryl AX
AX3000 Wifi Router


Contents

- [1 SETTING UP](#)
- [2 SUPPORT](#)
- [3 WARRANTY](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

SETTING UP

1. Power On

When powered up, your router will broadcast both 2.4G and 5G Wi signals with the SSID:
GL-MT3000-00x and GL-MT3000-xxx-56.



2. Connect via Wi-Fi

Scan the QR code printed on the bottom of the router to connect, or manually search and connect to GL-MT3000-xxx, then enter the default password printed on the router to connect.


Wi-Fi	<input type="checkbox"/>
✓ GL-MT3000-xxx	

Search the SSID and connect to it

Password <div> • • • • • • • • </div>

or

Connect via LAN




3. Set Up Router

Visit <http://192.168.8.1> in your browser to set up your router; start by choosing your preferred language.



SUPPORT



Repair / Reset

If you cannot access the web-based setup page or cannot connect to the router, you can press the Reset button

- Press and hold for 3 seconds and then release to repair your network. "The light will turn blue and flash slowly until your network recovers.
- Press and hold for 10 seconds, and then release to reset the router to factory settings. The light will turn blue and flash rapidly. All data will be cleared when the light becomes solid blue.



<https://docs.gl-inet.com/en/4/>

Technical Supports.

For more detailed and updated instructions, please visit our website docs.gl-inet.com

For further questions, you can get help from the following ways:

– Email to support@gh-net.com

Message us on our Facebook: facebook.com/gl.inet.wifi/

Post questions in our forum: forum.ghinet.com

– Ask professionals in other forums e.g. Openr, LEDE or other professional websites

WARRANTY

- We provide one year limited warranty for routers and 3-month limited warranty for accessories.
- Extra warranty may apply according to the local law in which the product purchase took place.
- Highly recommend using the included 5V/3A power adapter.
- Any damage to the router caused by not following the instructions will render this warranty null and void.
- Any damage to the router caused by modifying the PCBA, components or case will render this warranty null and void.
- Issues caused by the use of third-party firmware may not get official support from us.
- Any damage to the router caused by inappropriate use, e.g. inappropriate voltage input, high temperature, dropping in the water or on the ground will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify these materials without further notice.

FCC ID: 2AFIW-MT3000

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not (promoted, approved by the party responsible for compliance could void the user's authority to operate the equipment
3. **Note** This equipment has been tested and found to comply with the requirements for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 70cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The user manual for the LE-1A1N directs shall contain instructions related to the restrictions mentioned in the above sections, namely that the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems. The functions of Wireless Access Systems including Radio Local Area Networks (WLANs) within the band 5150-5350 MHz for this device are restricted to indoor use only within all European Union countries.

	AT	BE	BG	HR	CY	CZ	DK	EE	FI	FR	DE	EL	HU	IS	IE	IT	
	LV	LI	LT	LU	MT	NO	PL	PT	RO	SK	SI	ES	SE	CH	NL	UK(NI)	UK

Hong Kong Office


GL Technologies (Hong Kong) Limited Unit 203, 7th, Building 191-619 Science Park West Avenue, Wong Kenn Science Park, Sha Tin, New Territories, Hong Kong

Shenzhen Office

Shenzhen Guangnengtech Tech Co., Ltd. Room 305 • 306, Sky-math Dural & Odom Station Sheel Station (Nong Shenzhen) China, 516000 4 864) 755.86606176)



Documents / Resources

	<p>GL iNet GL-MT3000 Beryl AX AX3000 Wifi 6 Router [pdf] User Manual</p> <p>GL-MT3000 Beryl AX AX3000 Wifi 6 Router, GL-MT3000, Beryl AX AX3000 Wifi 6 Router, AX3000 Wifi 6 Router, Wifi 6 Router, Router</p>
---	---