

GL iNet GL-MT3000 Beryl AX WiFi 6 Router Instruction Manual

Home » GL iNet GL-MT3000 Beryl AX WiFi 6 Router Instruction Manual

Contents

- 1 GL iNet GL-MT3000 Beryl AX WiFi 6 Router
- 2 Specifications
- **3 Product Usage Instructions**
- 4 FAQ
- **5 SETTING UP**
- **6 SUPPORT**
- **7 Technical Supports**
- **8 WARRANTY**
- 9 FCC Statement
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



GL iNet GL-MT3000 Beryl AX WiFi 6 Router



Specifications

• Model: GL-MT3000 Beryl AX AX3000 WiFi 6 Router

• Wireless Standards: WiFi 6 (802.11ax)

• Frequency Bands: 2.4GHz, 5GHz

• Ports: WAN Ethernet port, LAN Ethernet port, USB3.0 port

• Buttons: Toggle button, Reset button

• Support: http://192.168.8.1

Product Usage Instructions

Setting Up

- 1. Power On: Plug in the power cable to start broadcasting Wi-Fi signals.
- 2. Connect via Wi-Fi: Scan the QR code or manually connect to SSID GL-MT3000-xxx with default password.
- 3. Connect via LAN: Connect your computer to LAN port with a cable.

Set Up Router

Visit http://192.168.8.1 in your browser to set up the router. Choose your preferred language to begin configuration.

Support

If you encounter issues accessing the setup page or connecting to the router:

- Repair: Press and hold the Reset button for 3seconds to repair network connectivity.
- Reset: Press and hold the Reset button for 10 seconds to reset the router to factory settings.

Technical Support

For detailed instructions and technical support, visit docs.gl-inet.com. Contact support via email, Facebook,

forum, or other professional websites.

FAQ

· Where can I find warranty information?

 The FCC ID for this device is 2AFIW-MT3000. Refer to the user manual for compliance details and warranty information.

• How do I ensure FCC compliance?

• Follow FCC guidelines provided in the manual for safe operation and compliance with regulations.

· What should I do in case of harmful interference?

 Reorient or relocate the receiving antenna, increase the separation between devices, and seek professional assistance if needed.


Need help? Scan the QR code for video tutorials and user guide.



SETTING UP


Power On

When powered up, your router will broadcast both 2.4G and 5G Wi-Fi signals with the SSID: GL-MT3000-xxx and GL-MT3000-xxx-5G.




Connect via Wi-Fi

Scan the QR code printed on the bottom of the router to connect, or manually search and connect to GL-MT3000-xxx, then enter the default password printed on the router to connect



Connect via LAN




Set Up Router

Visit http://192.168.8.1 in your browser to set up your router; start by choosing your preferred language.



SUPPORT



Repair / Reset

If you cannot access the web-based setup page or cannot connect to the router, you can press the Reset button:

- Press and hold for 3 seconds and then release to repair your network. The light will turn blue and flash slowly until your network recovers.
- Press and hold for 10 seconds, and then release to reset the router to factory settings. The light will turn blue and flash rapidly. All data will be cleared when the light becomes solid blue.



• https://docs.gl-inet.com/en/4/

Technical Supports

For more detailed and updated instructions, please visit our website docs.gl-inet.com

For further questions, you can get help from the following ways:

- Email to support@gl-inet.com
- Message us on our Facebook: facebook.com/gl.inet.wifi/
- Post questions in our forum: forum.gl-inet.com
- Ask professionals in other forums e.g. OpenWrt, LEDE or other professional websites

WARRANTY

- We provide two-year limited warranty for routers and 3-month limited warranty for accessories.
- Extra warranty may apply according to the local law in which the product purchase took place.
- Highly recommend using the included 5V/3A power adapter.
- Any damage to the router caused by not following the instructions will render this warranty null and void.
- Any damage to the router caused by modifying the PCBA, components or case will render this warranty null and void.
- Issues caused by the use of third-party firmware may not get official support from us.
- Any damage to the router caused by inappropriate use, e.g. inappropriate voltage input, high temperature, dropping in the water or on the ground will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify these materials without further notice.

FCC Statement

FCC ID: 2AFIW-MT3000

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1. This device may not cause harmful interference, and
 - 2. This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 3. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help with important announcements.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction\ with any other antenna or transmitter

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

The user manual for LE-LAN devices shall contain instructions related to the restrictions mentioned in the above sections, namely that: i. the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

The functions of Wireless Access Systems including Radio Local Area Networks(WAS/RLANs) within the band 5150-5350 MHz for this device are restricted to indoor use only within all European Union countries.

| AT | BE | BG | HR | CY | CZ | DK | EE | FI | FR | DE | EL | HU | IS | IE | IT | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|------------|----|
| LV | LI | LT | LU | МТ | NO | PL | PT | RO | SK | SI | ES | SE | СН | NL | UK(NI) | UK |

Hereby, GL TECHNOLOGIES (HONG KONG) LIMITED declares that the radio equipment type [AX3000 WiFi 6 Router, GL-MT3000] is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: https://www.gl-inet.com/products/certificate

- Frequency bands: 2.4G WIFI:2.412-2.472GHz; 5G WIFI:5.15-5.25GHz 5.25-5.35GHz 5.47-5.725GHz 5.725-5.85GHz
- Maximum output power: 2.4GHz WIFI 20dBm 5GHz WIFI 22dBm

Hong Kong Office

GL Technologies (Hong Kong) Limited Unit 601, Building 5W, Hong Kong Science Park, Shatin, N.T., Hong Kong

Shenzhen Office

Shenzhen Guanglianzhitong Tech Co., Ltd. Room 305 – 306, Skyworth Digital Building, Shiyan Street, Baoan District, Shenzhen, China, 518000 (+86-0755-86606126)

Documents / Resources



<u>GL iNet GL-MT3000 Beryl AX WiFi 6 Router</u> [pdf] Instruction Manual GL-MT3000, AX3000, GL-MT3000 Beryl AX WiFi 6 Router, GL-MT3000, Beryl AX WiFi 6 Router, WiFi 6 Router, Router

GL-HTSSS / BeglAX AX3000 WIT & Tooler

References

- **gii** Redirecting
- gli GL.iNet
- 91 Homepage GL.iNet Router Docs 4
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.