

GPX
PCB319B
Bluetooth Cd
Player



GPX PCB319B Bluetooth Cd Player User Manual

[Home](#) » [Support](#) » GPX PCB319B Bluetooth Cd Player User Manual 

Contents

- [1 GPX PCB319B Bluetooth Cd Player](#)
- [2 Important Safety Instructions](#)
- [3 Additional Warnings and Precautions](#)
- [4 Functions & Controls](#)
- [5 Power](#)
- [6 CD](#)
- [7 Bluetooth Transmitter Mode](#)
- [8 FCC Warnings](#)
- [9 International Support](#)
- [10 FAQs](#)
- [11 Video-GPX PCB319B Bluetooth Cd Player](#)
- [12 References](#)
- [13 Related Posts](#)



GPX PCB319B Bluetooth Cd Player





Important Safety Instructions

- Read these Instructions.
- Keep these Instructions.
- Heed all Warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install by the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for the replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



Additional Warnings and Precautions

- **CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH THE WIDE BLADE OF THE PLUG TO THE WIDE SLOT, FULLY INSERT.
- The mains plug is used as a disconnect device and it should remain readily operable during intended use. To disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain, moisture, dripping, or splashing.
- **CAUTION:** Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.
- **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.
- **WARNING:** Use of this unit near fluorescent lighting may cause interference regarding use of the remote. If the unit is displaying erratic behavior move away from any fluorescent lighting, as it may be the cause.
- **WARNING:** Shock hazard – Do Not Open.
- Caution and marking information is located at the rear or bottom of the apparatus.
- Objects filled with liquids, such as vases, shall not be placed on the apparatus.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- **WARNING:** There is a danger of explosion if you attempt to charge standard Alkaline batteries in the unit. Only use rechargeable NiMH batteries.
- Battery shall not be exposed to excessive heat such as sunshine, fire, or the like.
- Do not mix old and new batteries.
- Completely replace all old batteries with new ones.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.
- Batteries should be recycled or disposed of as per state and local guidelines.
-  **WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. This product meets and complies with all Federal regulations.
-  This product utilizes a Class 1 laser to read Compact Discs. This laser Compact Disc Player is equipped with safety switches to avoid exposure when the CD door is open and the safety interlocks are defeated. Invisible laser radiation is present when the CD Player's lid is open and the system's interlock has failed or been defeated. You must avoid direct exposure to the laser beam at all times. Please do not attempt to

defeat or bypass the safety switches.




- **Warning:** To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.
- The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.
- The lightning flash with the arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
- This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user-accessible parts.


WARNING: DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD.

Functions & Controls

Features:



- Bluetooth wireless transmitter
- CD player: CD, CD-R/RW, MP3 CD
- 40 sec. anti-skip protection for CDs
- 100 sec. anti-skip protection for MP3 CDs
- Analog volume control
- LCD
- Low battery indicator
- Stereo headphone jack
- DC battery power: requires 2 AA size batteries (not included)
- DC power input: requires an AC/ DC power adapter or 12V car power adapter (both not included)



- **Play/Pause**

Press to play or pause a loaded CD.

- **Stop/OFF**

- Press to stop a CD during play.
- In stop mode, press to power OFF the CD player.

- **Skip/Search**

Press to skip between tracks on a loaded CD. Press and hold to search an individual track on a loaded CD.

- **P/+10**

- Press to program a CD to play tracks in a specified order.
- Press during play to skip 10 tracks (MP3 CD ONLY).

- **M (Mode)**

Press and hold to switch to Bluetooth Transmitter Mode.

Press to select repeat mode:

- REP 1 – repeat a single track
- ALL – repeat an entire CD
- DIR – repeat a directory on an MP3 CD
- RND – play tracks in a random order
- INTRO – play the CD in Intro mode

- **Open**

Press to open the CD door.


Includes:

- One set of stereo earbuds
- User's Guide
- Warranty


Power

Requires 2 AA batteries (not included).

Note: Please remove batteries if using the USB cable for power.



Using an AC/DC power adapter (not included), connect the DC power input on the unit to a standard power outlet.



CD

Loading a CD

1. Press the OPEN button to open the CD door.
2. Load a CD into the player, and label side up.
3. Close the CD door.

Playing a CD

1. Press the PLAY/PAUSE button to begin playing the loaded CD.

Programming a CD

1. Press the STOP button to stop the CD during play.
2. Press the P button, "P-01" will begin to blink on the display.
3. Press the SKIP/SEARCH buttons to select the track you wish to program.
4. Press the P button to save the selected track to the program.
5. Repeat steps 3 and 4 to program up to 20 tracks to play in the order they are programmed.

6. Press the PLAY/PAUSE button to begin playing the programmed tracks.

Bluetooth Transmitter Mode

Pairing to a Bluetooth Speaker

The CD player can act as a Bluetooth transmitter to a Bluetooth speaker. Follow the below steps to connect to a Bluetooth speaker and play music from a loaded CD.

When using Bluetooth, there is no output from the headphone jack.

When the CD player is stopped for approximately 30 seconds, the power will be automatically turned off. The user will need to repeat below connection steps to play in Bluetooth Mode again.

1. Press and hold the Mode button to switch to Bluetooth Pairing Mode.
2. When the CD player is in Bluetooth Mode, "BT" will be seen flashing on the LCD. The pairing process could take up to 30 seconds. For best results, stay within 3 ft. of the Bluetooth speaker you are pairing to.
3. When the Bluetooth connection is made, the "BT" icon on the LCD will stop flashing and turn solid. Your Bluetooth speaker should indicate when the connection has been made as well. Note: The unit will connect to the closest Bluetooth speaker that is near it.
4. Begin playing music on the CD player to hear it on the connected Bluetooth speaker. If you are connected to a Bluetooth speaker with a play/pause button and do not hear audio, try pressing the play/pause button.
5. When you are finished listening, press the Stop button to stop the player.
6. Press and hold the Mode button to turn off Bluetooth transmitter mode.

FCC Warnings

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

International Support

- To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.gpx.com
- For Warranty Information and the most up-to-date version of this User's Guide, go to www.gpx.com
- **Customer Service:** 1-[888-999-4215](tel:888-999-4215)
- **Email Support:** prodinfo@dpiinc.com
- **Email Parts:** partsinfo@dpiinc.com
- Copyright © 2016 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the

property of their respective owners.

Specifications are subject to change without notice.

FAQs

What types of discs does the GPX PCB319B Bluetooth CD Player support?

The GPX PCB319B Bluetooth CD Player supports CD, CD-R, CD-RW, and MP3 CDs, giving you versatile playback options.

What is the weight and size of the GPX PCB319B Bluetooth CD Player?

The GPX PCB319B Bluetooth CD Player weighs just 8.8 ounces and measures 5.51 x 5.98 x 1.26 inches, making it lightweight and compact.

What playback modes does the GPX PCB319B Bluetooth CD Player offer?

The GPX PCB319B Bluetooth CD Player offers repeat, shuffle, intro, and program playback modes, allowing for a personalized listening experience.

What accessories come with the GPX PCB319B Bluetooth CD Player?

The GPX PCB319B Bluetooth CD Player includes one set of stereo earbuds, a user guide, and a 90-day limited warranty.

How does Bluetooth pairing work on the GPX PCB319B Bluetooth CD Player?

To pair Bluetooth devices with the GPX PCB319B Bluetooth CD Player, enable pairing mode on your headphones or speakers, then activate Bluetooth on the CD player to connect.

What kind of display does the GPX PCB319B Bluetooth CD Player have?

The GPX PCB319B Bluetooth CD Player features an LED display that provides clear information about the playback status and battery level.


Is the GPX PCB319B Bluetooth CD Player suitable for travel?

Absolutely! The lightweight and compact design of the GPX PCB319B Bluetooth CD Player, combined with its battery-powered option, makes it ideal for travel.

What should I do if my GPX PCB319B Bluetooth CD Player skips audio?

If your GPX PCB319B Bluetooth CD Player skips audio, check the disc for scratches or dirt, ensure anti-skip protection is enabled, and make sure the device is stable during use.

Video-GPX PCB319B Bluetooth Cd Player



[Download this Manual](#)
[Download this Manual content/uploads/2025/01/GPX-PCB319B-Bluetooth-Cd-Player.mp4](#)

[GPX PCB319B Bluetooth Cd Player User Manual](#)

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.