



# Haltian Thingsee Gateway LAN Device Installation Guide

[Home](#) » [Haltian](#) » Haltian Thingsee Gateway LAN Device Installation Guide 

## Haltian Thingsee Gateway LAN Device Installation Guide



### Welcome to use Thingsee

Congratulations on choosing Haltian Thingsee as your IoT solution. We at Haltian want to make IoT easy and accessible for everyone, so we have created a solution platform that is easy to use, scalable and secure. I hope our solution will help you achieve your business goals!

Pasi Leipälä  
CEO, Haltian Oy

**Thingsee GATEWAY LAN**



Thingsee GATEWAY LAN is a plug & play IoT gateway device for large scale IoT solutions. The main role of the Thingsee GATEWAY LAN is to ensure that data flows in and out from the sensors to a Thingsee Operations Cloud.

Thingsee GATEWAY LAN connects a mesh of a few to hundreds of wireless sensor devices to Thingsee Operations Cloud. It exchanges data with the mesh network and sends data to cloud backends. It is connected to the internet over an Ethernet connection and therefore works globally.

## Contents

- [1 Sales package content](#)
- [2 Note before installation](#)
- [3 Thingsee installation network structure](#)
  - [3.1 Things to avoid in installation](#)
- [4 Data integration](#)
- [5 Installation](#)
- [6 Network requirements](#)
  - [6.1 Network services](#)
  - [6.2 Port configuration](#)
  - [6.3 Device info](#)
  - [6.4 Device measurements](#)
- [7 CERTIFICATION INFORMATION](#)
  - [7.1 Care and maintenance](#)
  - [7.2 RECYCLING](#)
- [8 Get to know other Thingsee devices](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)


## Sales package content

- Thingsee GATEWAY LAN
- Power supply unit (5C USB-C)


## Note before installation

Install the gateway to a secure location. In public places, install the gateway behind locked doors.

To ensure strong enough signal strength for data delivery, keep the maximum distance between mesh network devices under 20 m.




If the distance between a measuring sensor and the gateway is > 20m or if the sensors are separated by a fire door or other thick building materials, use extra sensors as routers.



## Thingsee installation network structure

Thingsee devices build a network automatically. Devices communicate all the time to adjust the network structure for effective data delivery. Sensors create subnetworks for data delivery by choosing the best possible route based on signal strength. The subnetwork chooses the strongest possible gateway connection for data delivery to the cloud. The customer network is closed and secure. It cannot be harmed by third party connections.

- • • • • Network communication
- • • • • Data flow



The amount sensors per one gateway varies depending on the sensors' reporting time: the longer the reporting time, the more sensor can be connected to one gateway. The usual amount is from 50-100 sensors per gateway to even up to 200 sensors.

To ensure mesh network data flow, a second gateway can be installed on the other side of the installation site.


### Things to avoid in installation

Avoid installing the Thingsee products near the following:


- Escalators




- Electrical transformers or thick electrical wires




- Nearby halogen lamps, fluorescent lamps or similar lamps with hot surface



- Thick concrete structures or thick fire doors



- Nearby radio equipment like WiFi routers or any other similar high power RF transmitters




- Inside metal box or covered with a metal plate



- Inside or underneath a metal cabinet or box



- Near elevator motors or similar targets causing a strong magnetic field



## Data integration


Make sure that data integration has been properly setup prior to the installation process. See link <https://support.haltian.com/howto/aws/> Thingsee data can be pulled (subscribed) from the Thingsee Cloud live data stream, or the data can be pushed to your defined end point (e.g. Azure IoT Hub before you install the sensors.)

## Installation

Please make sure the Thingsee GATEWAY LAN is installed before you install the sensors.

To identify the gateway, read the QR code on the backside of the device with a QR code reader or Thingsee installation application on your mobile device.

Identifying the device is not necessary, but it will help you keep track of your IoT installation and help Haltian support to solve possible issues.




To identify the device over Thingsee API, please check:

<https://support.haltian.com/api/open-services-api/api-sequences/>

Connect the power source to the gateway and plug it into a wall socket with 24/7 power.

**Note:** Always use the power source included in the sales package.

Connect the ethernet cable to the device.



**Note:** The socket-outlet for the power source should be installed near the equipment and should be easily accessible.

Thingsee GATEWAY LAN is always ethernet connected:  
LED indication is used to provide gateway status information.

The LED on top of the device starts to blink:



- RED blink – Searching or cannot find Ethernet connectivity.



- Simultaneous RED and GREEN blink – Ethernet connection working, but no cloud connection.



- GREEN blink – normal operation, connected to LAN network.



- Changing Green and Red blink – Firmware update.



To close the device unplug the device.

## Network requirements

### Network services

Thingsee GATEWAY LAN requires following services from the network.

- IP address allocated by DHCP

### Port configuration


The gateway requires that the following ports are open in the network firewall. The ports must be open for outbound connections. Thingsee GATEWAY LAN doesn't run any services and acts only as a client for the services below. A port-forwarding is not required.

Service	Protocol	Port	Description
DNS	UDP	53	Domain Name Service
HTTP	TCP	80	Non-critical communication
NTP	UDP	123	Network Time Protocol
HTTPS	TCP	443	Secure communication
MQTT	TCP	8883	Secure communication, AWS IoT

#### Device info

- **Recommended operating temperature:** 0 °C ... +40 °C
- **Operating humidity:** 8 % ... 90 % RH non-condensing
- **Storage temperature:** 0°C ... +25 °C
- **Storage humidity:** 5 % ... 95 % RH non-condensing
- **IP rating grade:** IP40
- Indoor office use **only**
- **Certifications:** CE, FCC, ISED, RoHS and RCM compliant
- USB-C powered
- BT with Wirepas mesh network support
- **Radio sensitivity:** -95 dBm BTLE
- Wireless Range 5-25 m indoor, up to 100 m Line of Sight Ethernet cable connection
- LED indication for device status

#### Device measurements



#### CERTIFICATION INFORMATION



## EU DECLARATION OF CONFORMITY

Hereby, Haltian Products Oy declares that the radio equipment type Thingsee GATEWAY LAN is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [www.haltian.com](http://www.haltian.com)

Thingsee GATEWAY LAN operates at Bluetooth® 2.4 GHz frequency band. Maximum radio-frequency power transmitted is +4.0 dBm.

### Manufacturer name and address:

Haltian Products Oy  
Yrttipellontie 1 D  
90230 Oulu  
Finland

## FCC REQUIREMENTS FOR OPERATION IN THE UNITED STATES

### FCC Information for the User

This product does not contain any user serviceable components and is to be used with approved, internal antennas only. Any product changes or modifications will invalidate all applicable regulatory certifications and approvals.

### FCC Guidelines for human Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### FCC Radio Frequency Interference Warnings & Instructions

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

- Increase the separation between the equipment and the receiver.
- Connect the equipment into an electrical outlet on a circuit different from that which the radio receiver is connected
- Consult the dealer or an experienced radio/TV technician for help
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### FCC compliance statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with RSS-247 of the Innovation, Science and Economic Development Canada (ISED) Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **Radiation Exposure Statement:**

This device complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and used with a minimum distance of 20 cm between the radiator and your body.

FCC ID: 2AEU3TSGWLN

IC: 20236-TSGWLN

RCM-approved for Australia and New Zealand.

## **SAFETY GUIDE**

Read these simple guidelines. Not following them may be dangerous or against local laws and regulations. For further information, read the user guide and visit <https://www.haltian.com>

### **Usage**

Do not cover the device as it may prevent the device from operating properly.

### **Safety distance**

Due to radio frequency exposure limits the gateway should be installed and operated with a minimum distance of 20 cm between the device and the body of the user or nearby persons.

### **Care and maintenance**

Handle your device with care. The following suggestions help you keep your device operational.

- Do not open, dismantle or modify the device. Unauthorized modifications may damage the device and violate regulations governing radio devices. If the device is opened by an unauthorized representative, the warranty will be null and void.
- Do not store the device in wet or humid conditions.
- Do not drop, knock, or shake the device. Rough handling can break it.
- Only use a soft, clean, dry cloth to clean the surface of the device. Do not clean the device with solvents, toxic chemicals or strong detergents as they may damage your device and void the warranty.
- Do not paint the device. Paint can prevent proper operation.
- Failure to comply with the instructions may cause damage to the device.

### **Damage**

If the device is damaged contact [support@haltian.com](mailto:support@haltian.com). Only qualified personnel may repair this device.

### **Small children**

Your device is not a toy. It may contain small parts. Keep them out of the reach of small children.

### **Interference with medical devices**

The device may emit radio waves, which could affect the operation of nearby electronics, including cardiac pacemakers, hearing aids and defibrillators. If you have a pacemaker or other implanted medical device, do not use the device without first consulting your doctor or the manufacturer of your medical device. Maintain a safe distance between the device and your medical devices and stop using the device if you observe a persistent interference with your medical device.

## RECYCLING

Check the local regulations for proper disposal of electronic products. The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 13th February 2003, resulted in a major change in the treatment of electrical equipment at end-of-life. The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal.

The crossed-out wheelie-bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collection at the end of their working life. Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.



## Get to know other Thingsee devices

- Thingsee PRESENCE




- Thingsee ENVIRONMENT




- Thingsee DISTANCE




- Thingsee AIR




- Thingsee BEAM



- Thingsee ENVIRONMENT RUGGED




- Thingsee LEAKAGE RUGGED



- Thingsee ANGLE RUGGED




- Thingsee GATEWAY GLOBAL



- Thingsee GATEWAY LAN







- Thingsee GATEWAY






For all devices and more information, visit our website [www.haltian.com](http://www.haltian.com) or contact [sales@haltian.com](mailto:sales@haltian.com)

Documents / Resources

<div> User and Installation Guide v. 1.0.0 </div>	<p><a href="#">Haltian Thingsee Gateway LAN Device</a> [pdf] Installation Guide Thingsee Gateway LAN, Device, Thingsee Gateway LAN Device</p>
<div> User and Installation Guide v. 1.0.0 </div>	<p><a href="#">Haltian Thingsee Gateway Lan</a> [pdf] Installation Guide Thingsee Gateway Lan, Thingsee, Gateway Lan</p>

References

-  [Connected solutions for successful businesses | Haltian](#)
-  [How to connect to AWS API Gateway - Haltian Support](#)
-  [Connected solutions for successful businesses | Haltian](#)