




Home » HOMCOM » HOMCOM 800-063V70-800-075V70 Portable Automatic Ice Maker Instruction

Manual ™

HOMCOM 800-063V70-800-075V70 Portable Automatic Ice Maker



Contents [hide]

- 1 IMPORTANT SAFETY INSTRUCTIONS
- 2 PREPARING YOUR ICE MAKER FOR USE
- 3 GETTING TO KNOW YOUR UNIT
- 4 OPERATING PROCEDURES & MAINTENANCE
- **5 USING YOUR ICE MAKER**
- 6 TROUBLESHOOTING
- 7 TECHNICAL PARAMETERS & CIRCUIT DIAGRAM
- 8 EXPLOSIVE DRAWINGS
- 9 Customer Support
- 10 Documents / Resources
 - 10.1 References

IMPORTANT SAFETY INSTRUCTIONS

Your safety and the safety of others are very important.

We have provided many important safety messages manual and your appliance. Always read and obey all safety messages.

This is the safety alert symbol:



All safety messages will follow the safety alert symbol and the word "DANGER" or "WARNING".





These words mean:

You can be killed or seriously injured if you don't immediate follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

PREPARING YOUR ICE MAKER FOR USE

When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons or property. Read all instructions before using any appliance.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not operate this, or any other appliance with a damaged cord.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This ice-maker must be positioned so that the plug is accessible.
- Connect to properly polarized outlets only. No other appliance should be plugged into the same outlet. Be sure that the plug is fully inserted into the receptacle.
- Do not run the power cord over carpeting or other heat insulators. Do not cover the cord.
 - Keep cord away from traffic areas, and do not submerge in water.
- We do not recommend the use of an extension cord, as it may overheat and become a
 risk of fire. If you must use an extension cord, use No. 0.75mm2 minimum size and
 rated no less than 16A/250V~ with a plug.
- Unplug the ice maker before cleaning or making any repairs or servicing.
- Exercise caution and use reasonable supervision when appliance is used near children.
- Do not use your ice-maker outdoors. Place the ice-maker away from direct sunlight and make sure that there is at least 10cm of space between the back of your unit and wall. Keep a minimum distance of 10cm on each side of your unit free.
- Do not clean your ice maker with flammable fluids. The fumes can create a fire hazard

or explosion.

- Do not tip over.
- If the ice maker is brought in from outside in wintertime, give it a few hours to warm up to room temperature before plugging it in.
- This appliance must be earthed.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended to be used in household and similar applications such as
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.

Warning: Risk of fire/flammable materials used. Please according to local regulations regarding disposal of the appliance for its flammable blowing gas.

- **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WANING: Do not damage the refrigerant circuit.
- WARNING: Do not use mechanical devices or other means to accelerate the
 defrosting process or ice harvesting process, other than those recommended by the
 manufacturer.
- WARNING: Do not use other type of electrical appliances inside the ice-maker.

WARNING: fill with potable water only.

WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

To avoid contamination of food, please respect the following instructions:

• Opening the door for long periods can cause a significant increase of the temperature

in the compartments of the appliance.

 Clean regularly surfaces that can come in contact with food and accessible drainage systems.

• Clean water tanks if they have not been used for 48 h; flush the water system connected to a water supply if water has not been drawn for 5 days.

IMPORTANT

The wires in this mains lead are colored in accordance with the following code:

Green or Green with a strip yellow: Grounding

Blue: Neutral

Brown: Live


To avoid a hazard due to instability of the appliance, it must be placed at an even or flat surface.

GETTING TO KNOW YOUR UNIT

General instruction

- 1. Ice scoop.
- 2. Ice full sensor
- 3. Ice basket
- 4. Top cover with transparent window
- 5. Air exhausting
- 6. Water drain cap: at front bottom side of the unit.
- 7. MAXIMUM WATER LEVEL:——▼——

Remove the ice basket, you can see the water level mark.



OPERATING PROCEDURES & MAINTENANCE

Postion of control panel & function

Control Panel: Easy to use, visible functions touch display setting.

A. Selected ice size displaying: Small and Large.


B. Power indicator

C. Ice-Full indicator

D. Water shortage indicator

E. Button to turn on/off the unit.

F. Button to select ice cube size.



UNPACKING YOUR ICE MAKER

- 1. Remove the exterior and interior packaging. Check if ice basket and ice scoop inside. If any parts are missing, please contact our customer service.
- 2. Remove the tapes for fixing ice shovel, ice basket & ice scoop. Clean the tank & ice basket.
- 3. Put the ice maker on a level & flat counter top without direct sunlight and other

sources of heat (i.e.: stove, furnace, radiator). Make sure that there is at least 4 inches gap between the back & LH/RH sides with the wall.

- 4. Allow one hour for the refrigerant fluid to settle before plugging the ice maker in.
- 5. The appliance must be positioned so that the plug is accessible.

WARNING: fill with potable water only. Only use drinking water.

CONNECTING YOUR ICE MAKER



! DANGER

*Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, please call our customer service.

- 1. This unit should be properly grounded for your safety. The power cord of this appliance is equipped with a three-prong plug which mates with standard three prong wall outlets to minimize the possibility of electric shock.
- 2. Plug your appliance into an exclusive, properly installed, grounded wall outlet. Do not under any circumstances, cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician.
- 3. This appliance requires a standard 220-240 Volt, 50Hz electrical outlet with good grounding means.

CLEANING AND MAINTAINING YOUR ICE MAKER

Before using your ice maker, it is strongly recommended to clean it thoroughly.

- 1. Take out the ice basket.
- 2. Clean the interior with diluted detergent, warm water and a soft cloth.
- 3. Then use the water to rinse the inside parts, and drain out the water by unplugging the drain cap on front bottom side.
- 4. The outside of the ice maker should be cleaned regularly with a mild detergent solution and warm water.
- 5. Dry the interior and exterior with a clean soft cloth.

6. When the machine is not to be used for a long time, drain water completely & dry the interior.

USING YOUR ICE MAKER

- 1. Open the cover, remove the ice basket and pour water into tank. Keep water level below the water level mark.
- 2. Press "ON/OFF" button on the control panel to begin the ice making cycle.
- 3. Select the ice cube size by pressing the "SELECT" button. If the room temperature is lower than 15°C(59°F), it is recommended to select small ice cube in order to avoid ice sticking together.
- 4. The ice making cycle lasts approx. 6 to 13 minutes, depending on selection of ice cube size and the room temperature. The recommended room temperature is 10°C to 38°C (50 °F to 100 °F).
- 5. If water pump can't inject water, the ice maker will stop automatically, and the "ADD WATER" indicator will be on. Press "ON/OFF" button, fill water up to the max. water level mark and press "ON/OFF" button again to turn on the unit again. Allow the refrigerant liquid inside the compressor at least 3 minutes to settle before restarting.
- 6. The ice maker stops when the ice backed is full and the "ICE FULL" indicator will be on.

Warning: Direct sunlight or sunlight reflection may cause infrared sensor malfunction. If the unit doesn't stop even ice cubes obstruct sensor, move the unit where no sunlight.

7. Change water in the water reservoir every 24 hours to ensure a reasonable hygiene level.

If unit isn't to be used, drain all the water and dry the tank.

TROUBLESHOOTING


| PROBLEM | POSSIBLE CAUSE | SOLUTION |
|---------|----------------|----------|
|---------|----------------|----------|

| "ADD WATER" indicator is on. | Lack of Water. | Stop the ice maker, fill wat er, and press "ON/OFF" bu tton again to restart the unit. |
|------------------------------|---|--|
| "ICE FULL" indicator is on. | Ice is full in basket. | Remove ice from ice baske t. Continuous press "Select" button 5 seconds, the unit could make ice 10 cycles e ven "Ice" indicator is on. |
| Ice cubes stick together. | The ice making cycle is too long. | Stop the ice maker, and re start it when the ice blocks melt. Select the small size ice cube selection. |
| | Water temperature in inner tank is too low. | Replace the water. Temperature of water recommended at 8 32°C (46°F-90°F). |
| Ice making cycle is normal | Room temperature or wate r temperature in inner tank is too high. | The room temperature should be 10-38°C(50-100°F), water temperature should be 8-32°C (46°F-90°F). |
| but no ice formed. | Refrigerant in cooling syste m leaks. | Verify by a qualified technician. |
| | Pipe in the cooling system is blocked. | Verify by a qualified technician. |

TECHNICAL PARAMETERS & CIRCUIT DIAGRAM

| Model | HZB-12/B(800-063V70) | HZB-12/SB(800-075V70) | |
|------------------------|----------------------|-----------------------|--|
| Power | 220-240V~/50Hz | 220-240V~/50Hz | |
| Protection Type | I | I | |
| Climate Type | SN/N/ST/T | SN/N/ST/T | |
| Ice Making Current | 0.7A | 0.7A | |
| Ice Harvest Current | 1.0A | 1.0A | |
| Refrigerant | R600a/21g | R600a/21g | |
| Vesicant | C5 H10 | C5 H10 | |
| Net Weight | 6.8 | 6.9 | |
| Dimension (W * D *H) | 222x313x320mm | 222x313x320mm | |
| Enclosure | Plastic | Stainless | |

ELECTRICAL DIAGRAM




EXPLOSIVE DRAWINGS

| S/N | Part description | Qty/ Per |
|-----|--------------------|----------|
| 1 | Power cord | 1 |
| 2 | plastic clip | 1 |
| 3 | Back panel | 1 |
| 4 | Plate back support | 1 |
| 5 | Evaporator | 1 |
| 6 | Control box cover | 1 |
| 7 | Main PCB | 1 |
| 8 | Control box | 1 |
| 9 | Magnetism valve | 1 |

| 10 | Ice making box | 1 |
|----|------------------------|---|
| 11 | Micro switch | 2 |
| 12 | Cam | 1 |
| 13 | Inner tank bracket, LH | 1 |
| 14 | Ice scoop link | 2 |
| 15 | Ice scoop | 1 |
| 16 | Back btm panel | 1 |
| 17 | Back top panel | 1 |
| 18 | Touch pad | 1 |
| 19 | Displaying PCB | 1 |
| 20 | Bracket displaying | 1 |
| 21 | Clear window | 1 |
| 22 | Front top panel | 1 |
| 23 | Front btm panel | 1 |
| 24 | Ice shovel | 1 |
| 25 | Foaming's | 1 |
| 26 | Ice basket | 1 |
| 27 | Stainless wire | 1 |
| 28 | Inner tank bracket, RH | 1 |
| 29 | Water filter | 1 |
| 30 | Synchronous motor | 1 |

| 31 | Condenser | 1 |
|----|----------------------|---|
| 32 | DC Fan motor | 1 |
| 33 | Copper tube filter | 1 |
| 34 | Nylon plug drain | 1 |
| 35 | Water Supply pipe | 1 |
| 36 | Silicon pump sealing | 1 |
| 37 | DC water pump | 1 |
| 38 | Compressor | 1 |
| 39 | Plate bottom | 1 |
| 40 | Rubber foot | 2 |
| 41 | Air grille | 1 |
| 42 | Internal Wire | 1 |



Customer Support

If you have any questions, please contact our customer care center.

Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:

IMPORTER ADDRESS: MH STAR UK LTD

Unit 27, Perivale Park, Horsenden lane South Perivale, UB6 7RH MADE IN CHINA





Documents / Resources



HOMCOM 800-063V70-800-075V70 Portable Automatic Ice Maker [pdf] I

nstruction Manual

800-063V70, 800-075V70, 800-063V70-800-075V70 Portable Automatic I ce Maker, 800-063V70-800-075V70, Portable Automatic Ice Maker, Automatic Ice Maker, Ice Maker

References

- User Manual
- HOMCOM
- 800-063V70, 800-063V70-800-075V70, 800-063V70-800-075V70 Portable Automatic Ice Maker, 800-075V70, Automatic Ice Maker, HOMCOM, Ice Maker, Portable Automatic Ice Maker

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

| Name | | |
|--|--------|--|
| | | |
| Email | | |
| <u> </u> | | |
| | | |
| Website | | |
| | | |
| | | |
| ☐ Save my name, email, and website in this browser for the next time I com | ment. | |
| | | |
| Post Comment | | |
| Search: | | |
| e.g. whirlpool wrf535swhz | Search | |
| | | |

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.