

[Skip to content](#)

## Manuals+

User Manuals Simplified.



## Honeywell H35CFW 3.5 Cubic Feet Chest Freezer User Manual

July 27, 2022 July 28, 2022 [Leave a comment on Honeywell H35CFW 3.5 Cubic Feet Chest Freezer User Manual](#)

[Home](#) » [Honeywell](#) » [Honeywell H35CFW 3.5 Cubic Feet Chest Freezer User Manual](#) 📄

# Honeywell

3.5 Cubic Feet Chest Freezer

User Manual

Read and save these instructions before use  
H35CFW



Contents [hide](#)

[1 SAFETY WARNINGS](#)

[2 PROPER USE OF FREEZER](#)

[3 MAINTENANCE OF FREEZER](#)

[4 TROUBLESHOOTING](#)

[5 Documents / Resources](#)

[5.1 References](#)

[5.2 Related Manuals / Resources](#)

### SAFETY WARNINGS

#### 1.1 Warning



**WARNING:** risk of fire / flammable materials

This appliance is intended to be used in household, non-retail applications.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities unless they have been given permission by a

person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

The appliance has to be unplugged after use and before carrying out user maintenance.

DO NOT store explosive substances such as aerosol cans in this appliance.

DO NOT use extension cords or ungrounded (two prongs) adapters.

WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are the type recommended by the manufacturer.

WARNING: This freezer uses flammable blowing gas and refrigerant. Please dispose of according to local regulators.

WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged, and that it is positioned in accordance with the instructions.

WARNING: Do not locate multiple portable socket outlets or portable power supplies at the rear of the appliance.

DANGER: Risk of child entrapment. Before disposing of your old freezer:

- Take off the doors.
- Leave the shelves in place so that children may not easily climb inside.

The freezer must be disconnected from the source of electrical supply before attempting the installation of the accessory.

Refrigerant and cyclopentane foaming material used for the appliance are flammable. To prevent damage to the environment or any other harm, when the appliance is scrapped, please keep it away from any fire source.

For EN standard: This appliance can be used by children aged 8 years and above and persons with reduced physical sensory or mental capabilities if they have been given instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children aged 3 to 8 are allowed to load and unload refrigerating appliances.

## 1.2 Electricity Related Warnings

- Do not pull the power cord when unplugging the freezer. Please firmly grasp the plug and pull out it from the socket directly.
- Do not damage the power cord under any condition, do not use it when the power cord is damaged or the plug is worn.
- Replace worn or damaged power cords in manufacturer-authorized maintenance stations.
- To prevent a fire, the power plug should be firmly contacted with the socket. Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.
- In case of a gas leak, please turn off the valve of the leaking gas and then open the doors and windows. Do not unplug the freezer and other electrical appliances since that spark may cause a fire.
- To ensure safety, it is not recommended to place regulators, rice cookers, microwave ovens, and other appliances on the top of the freezer, unless recommended by the manufacturer.

## 1.3 Related Warnings for Use

- Do not arbitrarily disassemble or reconstruct the freezer, nor damage the refrigerant circuit. Maintenance of the appliance must be conducted by a specialist.
- The damaged power cord must be replaced by the manufacturer, its maintenance department, or related professionals in order to avoid danger.
- To prevent injury, do not put your hand between the freezer doors and body. Please be gentle when opening the door to avoid falling items.
- To avoid frostbite, do not handle food or containers, especially metal, with wet hands in the freezing chamber when the freezer is running.
- Do not allow children to enter or climb the freezer to prevent entrapment or injury.
- Do not spray, wash, or put the freezer in moist places or places where it can be easily splashed with water to protect the electrical insulation properties.
- Do not place heavy objects on the top of the appliance. Objects may fall when opening the door and may cause accidental injury.
- Please pull out the plug in case of power failure or cleaning. Do not connect the freezer to the power supply within five minutes to prevent damage to the compressor due to successive starts.

## 1.4 Warnings Related to Placing Items

- Do not put flammable, explosive, volatile, and highly corrosive items in the freezer to prevent damage to the product or fires.
- Do not place flammable items near the freezer to avoid fires.
- According to national standards, household freezers should not be used for other purposes, such as the storage of blood, drugs, or biological products.
- Do not place items such as bottled or sealed containers of fluid such as bottled beers and beverages in the freezer.

## 1.5 Warnings for Energy

- The freezer might not operate consistently when sited for an extended period of time below the range of temperatures that it is designed to withstand.
- Do not exceed the storage time recommended by the food manufacturers for any kind of food and commercially quick-frozen food in the freezer.
- A rise in the temperature of the frozen food during maintenance or cleaning could shorten the storage life.

## 1.6 Warnings Related to Disposal

The freezer's refrigerant and cyclopentane foam materials are combustible materials. Discarded freezers should be isolated from fire sources and can not be burned.

Please transfer the freezer to qualified professional recycling companies for processing to avoid damage to the environment or other hazards.

Please remove the door of the freezer and shelves to prevent children from entering and playing in the freezer.


### Correct Disposal of this product:



■ This marking indicates that this product should not be disposed of with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. Contact the retailer as many will take them back for recycling.

## PROPER USE OF FREEZER


### 2.1 Names of Components



The freezing speed of the product is related to the amount and temperature of contents stored in the freezer. The thermostat should be adjusted to maximum gear 24 hours before placing room temperature contents into the freezer. If contents are added to the freezer at room temperature prepare ice for cold storage. The large food should be divided into small pieces for better freezing.

**Note:** It is recommended to grease the hinge of the freezer regularly to extend the life of the hinge.

## 2.2 Temperature Control



Connect the freezer to the power supply and the green power indicator light will shine.

The interior temperature of the freezer is adjusted through the thermostat knob.

Rotate the knob clockwise to adjust.

## 2.3 Placement

- Before using the freezer, remove all packaging materials including bottom cushions, foam pads, and tape inside, and tear off the protective film on the door and the freezer body.
- The freezer should be placed in a well-ventilated indoor place on the ground that is flat and sturdy.
- Keep away from heat and avoid direct sunlight. Do not place the freezer in moist or watery places to prevent rust or reduction of insulation.
- Please leave at least 70 cm of space above the freezer, and 20 cm from both sides and backside to facilitate heat dissipation.

## 2.4 Start to Use

- The freezer must stand for half an hour before connecting power when it is first started.
- Run the freezer for 2 to 3 hours, or 4+ hours in the summer, before loading fresh or frozen food.

## 2.5 Energy Saving Tips

- The appliance should be located in the coolest area of the room, away from heat-producing appliances or heating ducts, and out of direct sunlight.
- Let hot foods cool to room temperature before placing them in the appliance.
- Overloading the appliance forces the compressor to run longer. Food that freezes too slowly may lose quality or spoil.
- Be sure to wrap food properly, and wipe containers dry before placing them in the appliance to cut down frost build-up inside the appliance.
- Do not line the storage bin with aluminum foil, wax paper, or paper towels. Liners interfere with cold air circulation, making the appliance less efficient.
- Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

## MAINTENANCE OF FREEZER

### 3.1 Cleaning

- Clean dust behind the freezer and on the ground to improve the cooling effect and energy saving.
- Check the door gasket regularly to make sure there is no debris. Clean the door gasket with a soft cloth dampened with soapy water or diluted detergent.
- Clean the interior of the freezer regularly to avoid odor.
- Please turn off the power before cleaning the interior, and remove all food, shelves, drawers, etc.
- Use a soft cloth or sponge to clean the inside of the freezer, with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean. After cleaning, open the door, and let it dry naturally before turning on the power.
- For areas that are difficult to clean (such as narrow gaps or corners), it is recommended to wipe them regularly with a soft rag, soft brush, etc. to ensure no contaminants or bacteria accumulate in these areas.
- Do not use soap, detergent, scrub powder, spray cleaner, etc., as these may cause odors in the interior of the freezer or contaminate food.
- Clean the baskets with a soft cloth dampened with soapy water or diluted detergent. Then rinse with water and dry with a soft cloth or naturally.
- Wipe the outer surface of the freezer with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, clean steel balls, wire brushes, abrasives (such as toothpaste), organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items, which may damage the cooler surface and interior. Boiling water and organic solvents such as benzene may deform or damage plastic parts.
- Do not rinse directly with water or other liquids during cleaning to avoid short circuits or damage to the electrical insulation.

 Please unplug the freezer for defrosting and cleaning.

### 3.2 Defrost

- Manually defrost the freezer. Disconnect the plug from the wall socket, open the door and remove all contents and shelving baskets before defrosting. open the outflow hole and drainage hole (and place the water container at the outflow hole); it is recommended to remove the frost with a plastic scraper or let the temperature rise naturally until the frost melts. Then wipe away the remaining ice and water, and plug in the freezer.

**!** Do not use other mechanical devices or other means to accelerate the defrosting process except those recommended by the manufacturer. Do not damage the refrigerant circuit.

### 3.3 Stop Using

Power failure: Food can usually be preserved for a couple of hours in case of power failure. It is recommended to reduce the frequency of opening the door and to not put fresh food into the freezer.

Long-time nonuse: Please unplug the unused freezer for cleaning. Keep the door open to avoid odor.

Moving: Do not turn upside down or shake the freezer, the carrying angle can not be greater than 45°.

Do not hold the door and hinge when moving this unit.

**!** Continuous operation is recommended when the freezer is started. To prevent affecting the freezer's service life, please do not stop the freezer under normal circumstances.

## TROUBLESHOOTING

Inoperation	Ensure the freezer is plugged in and connected to power Check that the voltage is not low The temperature control knob is not set to "OFF"
Odor	Thoroughly clean the interior of the freezer.  Do not overload the freezer Do not put hot contents in the freezer Do not open doors too frequently Note that it is normal that the freezer operates for a longer time in summer when the ambient temperature is higher
Long-term operation of the compressor	Note that it is normal that the freezer operates for a longer time in summer when the ambient temperature is higher
The freezer door can not be properly closed	Check for any items blocking the freezer door or unbalanced placement of items.
Loud noises	Ensure that the freezer is sitting on a flat and stable surface Ensure that the freezer accessories are properly placed
Transient difficulty in door opening	Pressure differences between the inside and outside of the freezer may result in transient difficulty in the door opening.
Freezer Enclosure Heat Condensation	The freezer enclosure may emit heat during operation, especially in summer, caused by the radiation of the condenser; this is normal. Condensation may be detected on the exterior surface and door seals of the freezer when humidity is high; this is normal.
Airflow sound Buzz Clatter	The compressor may cause a buzzing sound when starting up or shutting down. The solenoid valve or electric switch valve may create a clattering sound that is normal and does not affect the operation.

If you want to return or replace the product, please contact the store where it was purchased (remember to bring the purchase invoice). If your product needs repair, please contact us via email or phone.

# Honeywell

BHRS Group, LLC

585 Prospect St.  
Lakewood, NJ 08701

Customer Service Tel: 1-800-604-0295

Customer Service Email: [support@honeywellcoolingappliances.com](mailto:support@honeywellcoolingappliances.com)

Website: [honeywellcoolingappliances.com](http://honeywellcoolingappliances.com)

©2021 BHRS Group, LLC. All Rights Reserved.

The Honeywell Trademark is used under license from Honeywell International Inc. and makes no representations or warranties with respect to this product. This product is manufactured by BHRS Group, LLC.

**MADE IN CHINA**

## Documents / Resources

Honeywell  
3.5 Cubic Feet Chest Freezer  
User Manual  
Read all safety instructions before use



[Honeywell H35CFW 3.5 Cubic Feet Chest Freezer \[pdf\] User Manual](#)

H35CFW, 3.5 Cubic Feet Chest Freezer, Feet Chest Freezer, Chest Freezer, H35CFW, Freezer

## References

- [Honeywell Cooling Appliances](#)

## Related Manuals / Resources

[Galanz Chest Freezer GLF10CWED01 Instruction Manual](#)

Chest Freezer GLF10CWED01



[AMANA AQC0902LW Chest Freezer Instructions](#)

PRODUCT MODEL NUMBERS AQC0902LW AZC5216LW ELECTRICAL REQUIREMENTS WARNING  
Electrical Shock Hazard Plug into a grounded 3 prong outlet....



[Hisense Chest Freezer FC70DWBAA Specifications Manual](#)

Hisense Chest Freezer Convenient Recessed Handles Low-noise Durable Hinges Power Light Wire Basket A  
convenient wire basket helps..



[Honeywell H11MFB 1.1 Cubic Feet Compact Freezer User Manual](#)

Honeywell H11MFB 1.1 Cubic Feet Compact Freezer User Manual SAFETY WARNINGS Warning WARNING:  
risk of fire / flammable...

**Leave a comment**

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

[Manuals+](#)

- [home](#)
- [privacy](#)