

Scan Function On The Mobile iCam365 App User Manual

[Home](#) » [iCam365](#) » Scan Function On The Mobile iCam365 App User Manual



iCam365 quick operation manual
WiFi Camera



<http://icam365.cc/>

Meese be sure to scan the upper OR code to do reload the iCam365" APP

Contents [[hide](#)]

- [1 Connect the device](#)
- [2 Add device](#)
- [3 Function Description](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Connect the device

Download APP


Use the "Scan" function on the mobile phone to scan the QR code to download and install the "iCam365" APP.




<http://icam365.cc/>

Connect power supply

Connect the device to the power supply. Keep it connected for about 1 minute until hearing a prompt sound.




Add device




1. Login to iCam365" APP
2. .Add device
3. Select WWI Camera

The APP will be constantly optimized and updated, and the interface shall be subject to the APP




4. Select Add mode For a quick add demonstration
5. Operate according to the prompt After hearing the prompt. check the box and click Next.
6. Select nearby devices



7. Select the VViFi that needs to be connected. and enter the password.
8. Wait for the device to configure the network
9. The device is added. Name your device

Function Description

Function	Description

Real-time and Playback	Click the screen on the device to enter the device real-time page to view the real-time camera screen. You can also switch to Playback to view the historical video. The recording can be divided into event recording and round-the-clock recording. You can select the recording mode as required.
Alert	The device will push an Alert message when it detects any movement or sound. You can select the type of Alert message to be received on the setting
Pan/tilt head and talk	On the real-time page, you can adjust the orientation of the remote camera through the disk of its pan/tilt head, or push and hold the microphone to send voice to the remote camera.
Sharing	Enter the mobile phone number of your family member on the Sharing page. The shared people shall download the APP and register. Each device can be shared by up to 10 accounts. The shared people can view the live video, talk to the camera and view the video through the pan/tilt head, but he/she cannot make settings
Alarm	It gives the voice and light alarm when detecting a movement event or a manlike shape event (purchase separately). You can also customize the voice
Setting management	Click ' 
Binocular camera	<p>If you are purchasing a binocular camera, the following function are currently supported:</p> <ol style="list-style-type: none"> 1. supports the Picture-in-Picture display. You can click Picture-in-Picture to enable or disable the function. 2. supports the switch between the small picture and the big picture. Click the long shot or close shot or small picture to switch. 3. its Playback function also supports the switch between the small picture and big picture and enables/disabling of the small picture window.

FAQ

What shall I do if the device cannot be added?



Check if the WiFi password is correct, and if the network is connected correctly, reset the camera. Add the device again when the above operation is done.

The video cannot be playback?

The recording is divided into event recording and round-the-clock recording. Event recording: The camera records the triggering event until its end. It keeps recording if the event keeps triggering it.

Round-the-clock recording: The camera records round the clock. The round-the-clock recording will occupy a huge space of the memory card. Please select the recording mode as required. The path setting of the recording mode: Setting-> Memory card -> Recording mode

How should I download the video to my mobile phone?

1. Click the Recording button "  " while viewing the playback video.
2. Click the Stop button  when the playback is finished, and the video will automatically be saved to the album.

What shall I do if it is shown that the device is offline?

First, check if the power supply and the network are normal. If they are normal, power off the camera and restart it. If the device is still offline after restarting, eliminate the camera in the APP and add it again.

What shall I do if the Alert message cannot be received?

- Confirm if the system has disabled the message push permission for iCam365. If it is disabled, enable the 'Message notification' permission in the settings of your mobile phone.
- Check if the message push is disabled in the device setting. The Alert message can be saved for up to 7 days.

Display of no memory card

1. The camera does not support hot-plugging. You need to power off the camera to insert the memory card. Please restart the camera.
2. If the memory card still cannot be identified after the camera is restarted, please replace it with a new card and try again.
3. If the new card still cannot be identified, the card slot may be damaged, or there is a failure in the FFC. Contact the supplier to replace the device.


What shall I do if the memory card is full?

No need to handle it manually. The camera automatically overwrites the earliest video documents when the spare space of its memory card is 500M or less.



<http://icam365.cc/>

Documents / Resources

	<p>iCam365 Scan Function On The Mobile iCam365 App [pdf] User Manual</p> <p>Scan Function On The Mobile iCam365 App</p>
---	---