

ICT BILLET

**551216-
KN40 Knock
Sensor
Relocation
Brackets**



ICT BILLET 551216-KN40 Knock Sensor Relocation Brackets Instructions

[Home](#) » [ICT BILLET](#) » [ICT BILLET 551216-KN40 Knock Sensor Relocation Brackets Instructions](#) 

Contents

- [1 ICT BILLET 551216-KN40 Knock Sensor Relocation Brackets](#)
- [2 Specifications](#)
- [3 Installation Process](#)
- [4 Maintenance Tips](#)
- [5 FAQs](#)
- [6 CONTACT INFORMATION](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

ICT BILLET

ICT BILLET 551216-KN40 Knock Sensor Relocation Brackets




Specifications

- **Product Name:** LS GEN 4 KNOCK SENSOR RELOCATION BRACKETS
- **Model Number:** 551216-KN40 IN

- **Dimensions:** M10 X 30MM
- **Weight:** 1 unit
- **Compatibility:** RKO(ICNEPTLOT#OICOCKSNAEASTNLEIO0N1NSOO) RN BLOCK
- **Placement:** Driver Side – Bank 1, Passenger Side – Bank 2

Installation Process

WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov.



- Locate the knock sensor on the engine block.
- Remove the existing knock sensor brackets carefully.
- Place the LS GEN 4 KNOCK SENSOR RELOCATION BRACKETS in position.
- Secure the brackets using the provided M10 X 30MM bolts.
- Ensure the brackets are firmly attached to the engine block.

WARNING: Proposition 65 – This product can expose you to chemicals including lead, which is known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information go to www.P65Warnings.ca.gov ALUMINUM – Most of the aluminum alloys used today contain some level of lead, usually less than .1%, Lead is known to the state of California to cause cancer and reproductive harm. Most aluminum alloys are physiologically inert in their solid form, and the lead is contained within, however, user-generated dust and/or fumes may pose a hazard if inhaled or ingested. Heating beyond a certain temperature may also provide avenues for exposure. STEEL BOLTS – Steel is an iron alloy with several metals including Nickel and Chromium. Both Nickel and Chromium are known to the State of California to cause cancer and reproductive harm respectfully. This warning applies to stainless steel as well.

Maintenance Tips

- Regularly check the brackets for any signs of damage or corrosion.
- Tighten the bolts periodically to prevent loosening.
- Inspect the knock sensors to ensure they are functioning correctly.

FAQs

- **Q: Can these brackets be used with any vehicle model?**
 - A: These brackets are specifically designed for use with RKO(ICNEPTLOT#OICOCKSNAEASTNLEIO0N1NSOO) RN BLOCK. Compatibility with other models may vary.
- **Q: How do I know if the knock sensors need relocation?**
 - A: If you are experiencing issues with knock sensor placement or need to optimize sensor performance, relocating them using these brackets can be beneficial.

CONTACT INFORMATION


Technical Support

- www.ictbillet.com
- email: sales@ictbillet.com
- Phone: 316-800-695
- Scan to visit our website www.ictbillet.com.



- Made in the USA with USA-made materials, spacers, pulleys, & tensioners

Documents / Resources



[ICT BILLET 551216-KN40 Knock Sensor Relocation Brackets](#) [pdf] Instructions
551216-KN40, 840117205314, 551216-KN40 Knock Sensor Relocation Brackets, 551216-KN40, Knock Sensor Relocation Brackets, Sensor Relocation Brackets, Relocation Brackets, Brackets

References

- [User Manual](#)

[Manuals](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.