



IKEA VIKIS Alarm Clock User Manual

[Home](#) » [Ikea](#) » [IKEA VIKIS Alarm Clock User Manual](#) 

Contents

- [1 IKEA VIKIS Alarm Clock User Manual](#)
- [2 FUNCTION BUTTONS](#)
- [3 HOW TO SET A DATE AND TIME](#)
 - [3.1 HOW TO VIEW CURRENT SETTINGS](#)
- [4 TO SWITCH OFF THE ALARM SIGNAL](#)
- [5 Related Posts](#)



IKEA VIKIS Alarm Clock User Manual



VIKIS alarm clock has a date, time, alarm functions, and background lighting. In addition to the alarm function, you can also activate an optional function that gives a signal every hour (chime) and a snooze function that lets you wake up gradually.

FUNCTION BUTTONS

The SET and MODE buttons are used to set the various functions of the clock. Please see below for a more detailed description and illustrations. The LIGHT button is used to switch on the background lighting.

HOW TO SET A DATE AND TIME

1. Press the SET button 4 times to display MONTH. Use the MODE button to set the correct month.
2. Press the SET button once more to display DAY. Use the MODE button to set the correct day.
3. Press the SET button one more time to display HOURS. Use the MODE button to set the correct hour. Note that A/P or H appears to the right of the display. A = AM. P = PM. H = 24-hour clock. (Choose the desired format by pressing the MODE button.)
4. Press the SET button again to display MINUTES. Use the MODE button to set the correct minute value.
5. To save the settings you have entered, press SET and then MODE.

HOW TO VIEW CURRENT SETTINGS

- Press the MODE button to see the current settings.
- Press 1 time to show the current alarm time.
- Press 2 times to show the current date.
- Press 3 times to show the current seconds
- (Press SET to zero the seconds.)
- Press 4 times to return to the current time.

ALARM AND HOURLY SIGNAL



To set the alarm:

1. Press the SET button once and then Press the MODE button to activate the alarm function. Press SET one more time and use the MODE button to set the hour for the alarm signal.
2. Press SET again and use the MODE button to set the minutes for the alarm signal.
3. Press SET again to save these settings.

TO SWITCH OFF THE ALARM SIGNAL

To switch off the signal when the alarm rings, press the SET button. You can also choose to switch off the alarm signal temporarily with the MODE button. If you use this so-called “snooze” function, the alarm will sound every 5 minutes until you switch it off completely by pressing the SET button.

TO ACTIVATE/DEACTIVATE THE ALARM SIGNAL AND HOURLY SIGNAL:

1. Press the SET button once and then Press the MODE button to activate or deactivate the alarm and hourly signal functions; ALARM ON (), CHIME ON (), ALARM OFF and CHIME OFF
2. Press three more times on the SET button to return to the current time.

Download PDF: [IKEA VIKIS Alarm Clock User Manual](#)