



InfinID Technologies VT100D3 V-TAG RFID Tag and USB Gateway User Guide

[Home](#) » [InfinID Technologies](#) » InfinID Technologies VT100D3 V-TAG RFID Tag and USB Gateway User Guide 

Contents

- [1 InfinID Technologies VT100D3 V-TAG RFID Tag and USB Gateway](#)
- [2 System Overview](#)
- [3 Getting Started](#)
- [4 Viewing Sensor Readings](#)
- [5 Appendix A FCC Compliance Statement](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



InfinID Technologies VT100D3 V-TAG RFID Tag and USB Gateway



System Overview

The V-TAG is a RFID tag with a set of sensors for temperature, acceleration and battery level. In contrast to other systems where each tag is polled by a central gateway, the V-TAG tag relays messages from other V-TAG tags which aids with tag read range and communications reliability. See Figure 1.




Figure 1 V-TAG System Overview

Getting Started

To start using your V-TAG RFID tags, insert batteries into each tag. The LED light on the tag should blink once every 20 seconds indicating normal operation.

To start using your V-TAG USB Gateway, attach the gateway to a USB port on a PC running Windows 10 or Windows 11. Select "OK" when the operating system asks to use the Internet to locate drivers.

Install the InfinID Technologies, Inc. AssetWorx! asset tracking software on your PC by running setup.exe and following the prompts.

Viewing Sensor Readings


To associate a V-TAG tag with an asset, simply enter the V-TAG ID printed on the tag label into the VTAG ID field for the asset as shown:

The screenshot shows the 'Asset A1001' window with the 'General' tab selected. The 'V-TAG ID' field is highlighted with a red rectangle. The 'Location' dropdown is set to 'Missing' and the 'Condition' dropdown is set to 'Good'. The 'Alert if Unseen for' dropdown is set to '- No Alerts -' and the 'Checkin Status' dropdown is set to 'Checked In'. The 'Print Label' button is visible on the right side of the form.

To view sensor readings for the asset, choose the sensors tab for the asset:

The screenshot shows the 'Asset 10001' window with the 'Sensors' tab selected. The 'V-TAG ID' field is highlighted with a red rectangle and contains the value '000001'. The 'Maximum Battery (Volts)' field is highlighted with a red rectangle. The 'Neighbors' field is highlighted with a red rectangle. The 'Active Neighbors' field is highlighted with a red rectangle. The 'Total Exceptions' field is highlighted with a red rectangle. The 'Last Exception' field is highlighted with a red rectangle. The 'Best Neighbor' field is highlighted with a red rectangle. The 'Best Neighbor RSSI (dBm)' field is highlighted with a red rectangle. The 'Minimum Temperature (°C)' field is highlighted with a red rectangle. The 'Maximum Temperature (°C)' field is highlighted with a red rectangle. The 'Minimum Acceleration (Volts)' field is highlighted with a red rectangle. The 'Maximum Acceleration (Volts)' field is highlighted with a red rectangle. The 'Minimum Humidity (%)' field is highlighted with a red rectangle. The 'Maximum Humidity (%)' field is highlighted with a red rectangle. The 'Minimum Battery (Volts)' field is highlighted with a red rectangle.

To view historical sensor readings for the asset, click on the "Plot" button for the asset:



To set thresholds for the asset, click on the thresholds button for the asset:

Parameter	Value	Duration (Seconds)
Temperature Lower (°C)	-10	120
Temperature Upper (°C)	80	120
Acceleration Upper (V)		
Humidity Lower (%)		
Humidity Upper (%)		
Battery Lower (V)		

Appendix A FCC Compliance Statement

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Documents / Resources

	InfinID Technologies VT100D3 V-TAG RFID Tag and USB Gateway [pdf] User Guide VT100D3, Y8FVT100D3, V-TAG RFID Tag and USB Gateway, VT100D3 V-TAG RFID Tag and USB Gateway
---	---