



Inivos QT-8509 BLE Remote Control Instruction Manual

Home » Inivos » Inivos QT-8509 BLE Remote Control Instruction Manual

Contents

- 1 Inivos QT-8509 BLE Remote Control
- 2 Specifications
- 3 Product diagram
- 4 Pairing
- **5 Restore Factory Settings**
- **6 FCC Compliance Statement**
- 7 FAQs
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts




Inivos QT-8509 BLE Remote Control



Specifications

- Red+Green LED
- Stop Function
- BLE Remote Control
- BLE Name: Inivos

Product diagram



Pairing

To pair the remote control with the host device, follow these steps:

- Press and hold the stop button for three seconds, then release it. At this\ time, the red LED light flashes, waiting for pairing
- The host searches for the pairing signal sent by Inivos and will automatically pair
- The remote control is successfully paired with the host, and the green LED stays on for three seconds

Restore Factory Settings

To restore factory settings, follow these steps:

• Press and hold the stop button for fifteen seconds, and the red LED will flash rapidly, indicating that the factory settings have been successfully restored

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, a nd can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FAQs

Q: What should I do if the pairing process fails?

A: Ensure that both devices are within range and try the pairing process again. If issues persist, consult the user manual for troubleshooting steps.

Q: How do I know if the remote control is successfully paired?

A: When successfully paired, the green LED on the remote control will stay on for three seconds.

Documents / Resources



<u>Inivos QT-8509 BLE Remote Control</u> [pdf] Instruction Manual QT-8509, QT-8509 BLE Remote Control, BLE Remote Control, Remote Control

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.