



Instant 917UTX-SL 917mhz PCB Universal Transmitter Instructions

[Home](#) » [Instant](#) » Instant 917UTX-SL 917mhz PCB Universal Transmitter Instructions 

Instant 917UTX-SL 917mhz PCB Universal Transmitter

Contents

- [1 Learning-in the Universal Transmitter \(UTX\)](#)
- [2 Operation](#)
- [3 Battery & Electrical Specifications](#)
- [4 FCC Statement](#)
- [5 FCC Caution](#)
- [6 FCC Section 15.105 Information to the user](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Learning-in the Universal Transmitter (UTX)

Please refer to the instructions provided with the receiver equipment or contact an authorized dealer for installation assistance.

Operation

- **To dial Emergency Line:**

Ensure the UTX PCB is correctly installed to the interface board of the peripheral unit.

Press the “Check In,” or “Help” button on the peripheral and ensure the device is transmitting properly. If you have issues with your device, please contact your authorized dealer for assistance.

- **Sleep Mode:**

- Upon receiving the UTX PCB, please refer to the installation instructions of your peripheral device to ensure the UTX board is installed properly into the interface board.

After installation, ensure the battery tab is removed so the CR123A battery makes contact with the battery terminals. After learning-in the UTX 917, 919, 921mhz device, your system is ready to use.

Battery & Electrical Specifications

- **Frequency:** 917, 919, 921MHz
- **Battery:** CR123A, 3V 1550mAh
- **Battery life:** 3 years
- **Open Field Range:** Approximately 500 ft.
- **Low battery status:** when the battery voltage is below the threshold, the UTX will indicate a low battery by transmitting a low battery status message every 180 minutes.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

To assure continued compliance, any changes or notifications not expressly approved by the party responsible for compliance may void the user's authority to operate his equipment. (Example – use only shielded interface cables when connecting to computer or peripheral device)

FCC Section 15.105 Information to the user

NOTE:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Statement :

This Class [B] digital apparatus complies with Canadian ICES-003.

Statement


This device complies with RSS-210 and ICES-003 of the Industry Canada Rules. Operation is subject to the following two conditions : (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation of this device.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Documents / Resources

	<p>Instant 917UTX-SL 917mhz PCB Universal Transmitter [pdf] Instructions 917UTX-SL, 917UTX-SL 917mhz PCB Universal Transmitter, 917mhz PCB Universal Transmitter, PCB Universal Transmitter, Universal Transmitter, Transmitter</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.