

# iTOMA CKS301 White Noise Machine with Alarm Clock **Instruction Manual**

Home » iTOMA » iTOMA CKS301 White Noise Machine with Alarm Clock Instruction Manual



**iTOMA CKS301 White Noise Machine with Alarm Clock** 




#### **Contents**

- 1 TIME SET
- **2 ALARM SET**
- 3 SNOOZE/ STOP /TURN OFF THE ALARM
- 4 ENJOYING YOUR FAVORITE FANS SOUNDS/NATURE SOUNDS/WHITE NOISE
- **5 POWER SOURCE**
- 6 Documents / Resources
  - **6.1 References**
- **7 Related Posts**


#### **TIME SET**

### Step 1


1. Press TIME SET for 2 seconds to entry time setting."




2. Press ▲ or ▼ to adjust the Hour.



3. Press TIME SET to next, the Minute segment will blink.




4. Press ▲ or ▼ to adjust Minutes.




Step 2

1. Press TIME SET to next, Year segment will blink.




2. Press ▲ or ▼ to adjust the Year.




Step 3


1. Press TIME SET to next, Month segment will blink.




2. Press ▲ or ▼ to adjust the Month.



3. Press TIME SET to next, Date segment will blink.




4. Press ▲ or ▼ to adjust the Date.



# Step 4

1. Press TIME SET to next, 12H / 24H segment will blink.




2. Press ▲ or ▼ to adjust the time format.



Step 5


1. Press TIME SET again to store the time setting, or wait for 40 seconds.



### **ALARM SET**


### Step 1

1. Press and hold the **ALARM SET** for 2 seconds, to entry alarm setting.






2. Press ▲ or ▼ to adjust Hour.






3. Press ALARM SET to next, the Minute segment will blink.







4. Press ▲ or ▼ to adjust Minutes.




# Step 2

1. Press **ALARM SET** again, the current volume level will blink.






2. Press ▲ or ▼ to adjust the Volume.




Step 3

1. Press ALARM SET again, the current day mode will blink.






2. Press ▲ or ▼ to adjust current day mode.




3. Press ALARM SET again to store the alarm setting, or wait for 40 seconds.




### SNOOZE/ STOP /TURN OFF THE ALARM


1. **SNOOZE**: Alarm will pause 9 minutes for each press, 6 times at most.



2. Stop the alarm: Press ALARM SET when the alarm is ringing.




3. Turn on/off the alarm completely: Push the ALARM switch to OFF.




### **ENJOYING YOUR FAVORITE FANS SOUNDS/NATURE SOUNDS/WHITE NOISE**


- 1. There are 5 FANS Sounds,5 White Noise and 10 Nature sounds to help you fall asleep.
- 2. Press the FANS SOUNDS button to turn on Fans sounds, Press ▲ or ▼ to select your favorite Fans sounds.




3. Press the WHITE NOISE button to turn on the White Noise, Press ▲ or ▼ to select your favorite white noise.



4. Press the NATURE SOUNDS button to turn on Nature sounds, Press ▲ or ▼ to select your favorite Nature sounds.




5. Press the TIMER button to choose your desired sleep timer(30.60.90.120 minutes).



#### **POWER SOURCE**

This clock is designed to operate on normal DC 5V 1A USB outlet or 5V 1A Type C outlet.





#### **Documents / Resources**



iTOMA CKS301 White Noise Machine with Alarm Clock [pdf] Instruction Manual CKS301, CKS301 White Noise Machine with Alarm Clock, White Noise Machine with Alarm Clock, Noise Machine with Alarm Clock, Machine with Alarm Clock, Alarm Clock, Clock

### References

### • User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.