



JLL Treadmill Connection Wires Instructions

[Home](#) » [JLL](#) » JLL Treadmill Connection Wires Instructions 



Contents

- [1 Treadmill Connection Wires](#)
- [2 INSTRUCTIONS](#)
- [3 CONTACT DETAILS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Treadmill Connection Wires

COPYRIGHT

The contents of this manual are subject to change without notice to improve quality.

© 2023 JLL Fitness Ltd

JLL Fitness Ltd owns the copyright for this manual.

Use or reproduction of this manual in parts or entirety without the authorization of JLL Fitness Ltd is prohibited.

INSTRUCTIONS

Some issues that may occur where you may need to check your treadmills connection wires are:

- No power to the monitor
- Incline function not working

- Intermittent power to the machine

TOOLS

To perform this check you will need the allen key from your tool pack.



STEP 1

Start by turning off the power supply to the treadmill.




STEP 2

Remove the bolts from the top of the right hand side frame arm.



STEP 3

Lift the monitor up and out of the frame arm and gently pull out the connect wire.




STEP 4

Unclip the wires, check your pins are straight and there is no damage to the wires.

If straight, reconnect everything making sure you hear a click when clipping the wires back together and re-attach your monitor to the frame. Be careful not to trap the wire in the frame.

If not, you may need a replacement connection wire.



CONTACT DETAILS

For any technical queries, product defects or damage or delivery questions please contact us using the details below:



Tel: 0121 328 7507



Email: info@jllfitness.co.uk



Live Chat: WWW.JLLFITNESS.CO.UK



Documents / Resources

	<p>JLL Treadmill Connection Wires [pdf] Instructions Treadmill Connection Wires, Treadmill, Connection Wires</p>
--	--

References

- [Buy Gym & Fitness Equipment Online | Empower Your Fitness | JLL Fitness](#)