



Johnson Controls F4-SNC Supervisory Controller Instructions

[Home](#) » [Johnson Controls](#) » Johnson Controls F4-SNC Supervisory Controller Instructions 

Contents

- [1 Johnson Controls F4-SNC Supervisory Controller](#)
- [2 F4-SNC Supervisory Controller user interface](#)
- [3 About this task:](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

Johnson Controls F4-SNC Supervisory Controller

INSTRUCTION MANUAL

F4-SNC Supervisory Controller user interface

Site Management Portal (SMP) is the user interface (UI) for the F4-SNC series supervisory controllers. The Site Management Portal (SMP) resource files for client access are not provided by the supervisory controllers. After you have installed Launcher, if you need to use SMP to access an F4-SNC supervisory controller that does not include onboard resource files, you must first manually retrieve and copy the necessary resource files to your computer.

Downloading and installing the resource files

About this task:

To download and install the resource files, complete the following steps.

Note: These steps apply to the F4-SNC Supervisory Controllers from Release 13.0.

1. Open Launcher and click the Options icon.
2. Make a note of the path that is selected under Launcher Storage Location. Unless the location was changed, it is one of the following paths:

- C:\ProgramData\Johnson Controls\Launcher for Windows
- /Users/Shared/Johnson Controls/Launcher/ for Mac
- 3. Click Cancel to close the window.
- 4. Open your browser and go to <http://www.johnsoncontrols.com/buildings/specialty-pages/metasys-launcher>.
- 5. Click either the link named Facility Explorer 13.0 Resource Files for Windows (F4SNC.zip) or Facility Explorer 13.0 Resource Files for Mac (F4SNC-macosx.zip) to download the zip file.

Note: The resource files are also located on the License Portal with the FX Engine Images product. Access the License Portal here: <https://software.jci.com/licenseportal/>

- 6. When the download is complete, open the Launcher Storage Location that you recorded in Step 2 and navigate to resources > ui.
- 7. Move the downloaded zip file to the ui folder.
- 8. Open the ui folder and right-click the zip file then choose the option to extract to this location. Depending on the zip program you use, it either creates a new folder named 13.0.0.240 or extracts the files loose in the ui folder. If the program extracts the files loose in the ui folder, create a new folder named 13.0.0.240 and move the extracted files there.
- After the files are extracted, the final path should be, for example:
 - C:\ProgramData\Johnson Controls\Launcher\resources\ui\13.0.0.240 for Windows
 - /Users/Shared/Johnson Controls/Launcher/resources/ui/13.0.0.240 for Mac
- 9. Close and re-open Launcher. Click the ? (Help/About) button to verify that the Installed Resources lists 13.0.0.240.

Result

You can now use Launcher to access the SMP UI of any F4-SNC Supervisory Controller that is updated to Release 13.0.

© 2024 Johnson Controls. All rights reserved. All specifications and other information shown were current as of document revision and are subject to change without notice.

www.johnsoncontrols.com

Documents / Resources

	Johnson Controls F4-SNC Supervisory Controller [pdf] Instructions F4-SNC Supervisory Controller, F4-SNC, Supervisory Controller, Controller
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.