



Keeson Technology MC132 Control Box Instructions

[Home](#) » [Keeson Technology](#) » **Keeson Technology MC132 Control Box Instructions**


Keeson Technology MC132 Control Box Instructions



Contents

- 1 Electrical configuration diagram
- 2 Function Picture
- 3 Process of test
 - 3.1 HEAD port
 - 3.2 FOOT port
 - 3.3 Lumbar port
 - 3.4 Massage
 - 3.5 MULTIFUNCTION port
 - 3.6 Power LED & PAIRING LED
 - 3.7 Power
 - 3.8 Pair Function
 - 3.9 FLAT function
 - 3.10 ZERO G position function
- 4 FCC Warning
- 5 Documents / Resources
- 6 Related Posts

Electrical configuration diagram



Function Picture



Process of test

HEAD port

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released

Click head down button, head actuator moves in, stop when released

This function takes effect only by pressing the corresponding button on the remote.

FOOT port

Connect to foot actuator, control by remote single:

Click foot up button, foot actuator moves out, stop when released

Click foot down button, foot actuator moves in, stop when released

This function takes effect only by pressing the corresponding button on the remote.

Lumbar port

Connect to foot actuator, control by remote single:

Click Lumbar up button, foot actuator moves out, stop when released

Click Lumbar down button, foot actuator moves in, stop when released

This function takes effect only by pressing the corresponding button on the remote.

Massage

Connect to head massage, control by remote:

Click head massage + button, head massage strengthens by one level;

Click head massage – button, head massage weaken by one level;

This function takes effect only by pressing the corresponding button on the remote.

MULTIFUNCTION port

Connect with the same other Control box or Other accessories;

Power LED & PAIRING LED

Power supply for control box, PAIRING LED of control box flashes for 4 times, and then turns off, POWER LED turns on

Power

Connect to the 29V DC;

Pair Function

Power up control box, pairing LED will be flash, the control box enters into mode of code pairing

Press and hold the pairing LED of Remote, the backlight of pairing LED flashes, the backlight of remote flashes, the remote enters into mode of code pairing;

The backlight of pairing LED of remote stops flashing, and the pairing led of control box stop flash, it indicates that the code pairing is successful;

FLAT function

Press and release the FLAT button on remote, the head and foot actuators moves to lower position (when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once) stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

ZERO G position function

Press and release ZERO G button on remote, the head and foot actuator moves to preset memory position, stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

FCC Warning

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Warning:


This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the

device.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Documents / Resources



[Keeson Technology MC132 Control Box](#) [pdf] Instructions
MC132, 2AK23MC132, MC132 Control Box, Control Box