



Keeson Technology MC232F Control Box User Manual

[Home](#) » [Keeson Technology](#) » Keeson Technology MC232F Control Box User Manual 




MC232F Function instruction

Contents

- [1 Electrical configuration diagram](#)
- [2 Remote Picture](#)
- [3 Process of test](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Electrical configuration diagram



Remote Picture



Process of test

1.1. HEAD port

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released

Click head down button head actuator moves in, stop when released

This function takes effect only by pressing the corresponding button on the remote.

1.2. FOOT port

Connect to foot actuator, control by remote single:

Click foot up button foot actuator moves out stop when released

Click foot down button foot actuator moves in stop when released

This function takes effect only by pressing the corresponding button on the remote.

1.3. LUMBAR port

Connect to lumbar actuator, control by remote single:

Click lumbar up button lumbar actuator moves out stop when released

Click lumbar down button lumbar actuator moves in stop when released

This function takes effect only by pressing the corresponding button on the remote.

1.4. FOOT VIBRATION

Connect to foot massage, control by remote:

Click foot massage + button, foot massage strengthens by one level;

Click foot massage – button, foot massage weakens by one level;

This function takes effect only by pressing the corresponding button on the remote.

1.5. HEAD VIBRATION

Connect to head massage, control by remote:

Click head massage + button, head massage strengthens by one level;

Click head massage – button, head massage weakens by one level;

This function takes effect only by pressing the corresponding button on the remote.

1.6. MULTIFUNCTION port

Connect with the same other Control box or Other accessories;

1.7. Power LED & PAIRING LED

Power supply for control box, LED of control box flashes for 10 seconds, and then turns on

1.8. Power

Connect to the 29V DC;

1.9. Pair Function

Power on the control box enters into mode of code pairing

Press and hold the pairing LED of Remote, the backlight of pairing LED flashes, the backlight of remote flashes, the remote enters into mode of code pairing;

The backlight of pairing LED of remote stops flashing, and the pairing LED of control box turns off, it indicates that the code pairing is successful;

If fails, repeat all the processes above;

1.10. Test for underbed light

Click button of underbed light, turns on(or turns off) the underbed light, switch the status once when click once

This function takes effect only by pressing the corresponding button on the remote.

1.11. FLAT function

Press and release the FLAT button on remote the head and foot actuators move to lower position(when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once) stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

1.12. ZERO G position function

Press and release ZERO G button on remote the head and foot actuator move to preset memory position stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

1.13. I position function

Press and release I on remote the head and foot actuator move to preset memory position, stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

1.14. II position function

Press and release II on remote the head and foot actuator move to preset memory position, stop when press any button

This function takes effect only by pressing the corresponding button on the remote.

FCC warning

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC RSS warning

This device complies with Industry Canada licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference,including interference that may cause undesired operation of the device.

ISED RSS Warning:


This device complies with Innovation,Science and Economic Development Canada licenceexempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

	Issue department Bedding Division	Date	5/3/2017
	Product Function instruction	Author	Ben
		No MC232SC	
MC232SC	Version		1.0
	Page 1 of 6		

Documents / Resources

	<p>Keeson Technology MC232F Control Box [pdf] User Manual MC232F, 2AK23MC232F, MC232F Control Box, MC232F, Control Box, Box</p>
---	---