

Kirisun Communication UP305/UP405 DMR Two-Way Radio **User Guide**

Home » Kirisun Communication » Kirisun Communication UP305/UP405 DMR Two-Way Radio User Guide






UP305/ UP405 DMR Two-way Radio **Quick User Guide**

Please read carefully the Safety Information and Warranty Card before using the product. **Caution for Using the Battery**

- The explosion may be incurred by using a battery of a non-supplied model, or by shorting the anode and cathode of the battery.
- Charge the battery using the attached charger, and dispose of it as instructed.
- Do not strike, squeeze, short out or disassemble the battery.
- Do not put the battery at a high temperature or throw it into a fire.
- Stop using the battery if it is seriously bulged or immersed in water.

Installing the Battery


- 1. Press the upper part of the belt clip gently so that it goes up. (Figure ①)
- 2. Align the battery with the battery holder at the back of the radio, and then insert the battery. (Figure 2)
- 3. Push the battery in the direction indicated until the latch is in position. (Figure ③)
- 4. Press the upper part of the battery until it is latched. (Figure 4)



Installing/Uninstalling the Antenna

Insert the threaded end of the antenna into the antenna interface, and rotate the antenna tight clockwise. (Figure 1)

To uninstall the antenna, rotate it counterclockwise. (Figure 2)




Charging the Battery

- 1. Plug the power adapter into a qualified AC power socket.
- 2. Connect the USB cable of the power adapter to the USB port at the back of the desktop charger. The green indicator light is on.
- 3. Insert the battery only or together with the radio into the charger.
- 4. Make sure the battery contacts the charging terminals properly and the red indicator light is on.
- 5. When the indicator light turns from red to green, charging is finished.
- 6. After this, wait for 1 to 2 hours before taking out the battery to achieve the best performance.

Note:


- 1. The radio is delivered uncharged. Before using it for the first time, please charge the battery.
- 2. Always use the supplied lithium battery and desktop charger.
- 3. A new battery or one that has been stored for more than 2 months after charging needs to be charged several times to achieve its normal capacity.



Installing/Uninstalling Belt Clip


Align the two screw holes of the belt clip with the screw holes at the back of the radio, and screw up the screws using a screwdriver.

To uninstall the belt clip, unscrew the screws and take off the belt clip.



Installing an Earphone (Optional)

To use an earphone, open the earphone cover at the upper part of the right side of the radio, and then plug the earphone connector into the jack.



Contents

- 1 Basic Operation
- 2 LED Indicator
- 3 Troubleshooting
- 4 Regulatory
- 5 Disposing of batteries
- 6 Documents /

Resources

7 Related Posts

Basic Operation

1. Powering On/Off

- When the radio is off, hold down the Power/Channel knob for 3 seconds to power on the radio. You will hear the tone "di di".
- When the radio is on, hold down the Power/Channel knob for 3 seconds to power off the radio. You will hear the tone "di di".

2. Selecting a Channel

In the standby state, rotate the Power/Channel knob to select a channel.

3. Adjusting the Volume

In the standby state, press the Volume + key to increase the volume, or the Volume - key to decrease it.

4. Initiating a Call to Default Group

Hold down the PTT key to initiate a call and talk, and release it to guit the call.

5. Receiving a Call

The green indicator light is on when signals are received.

While working on a digital channel, the radio outputs voice when it receives an individual call, group call, or all call.

While working on an analog channel, the radio outputs voice when it receives signals, and the CTCSS code is the preset one for the channel or analog signaling is disabled for the radio.

6. Answering a Call

On a digital channel, you can answer a call by holding down the PTT key within the call duration. After this duration is

up, you need to initiate a new call.

(Note: You may have the call duration set by your dealer.)

On an analog channel, you can answer a call by holding down the PTT key and speaking to the microphone.

7. Digital/Analog Switching

After configuring the mode of each channel as analog or digital, you can switch to either mode by selecting a channel using the Power/Channel knob.

8. **TOT**

TOT (Time-out Timer) is to prevent a user from occupying a channel for too long. If the radio transmits continuously for a duration longer than that set by the dealer, transmission stops and there is an alert tone, and you may cancel the tone by releasing the PTT key. After a period, you may resume transmission by holding down the key. (**Note:** You may have this period set by your dealer.)

If a pre-alarm is enabled, you hear a pre-alarm alert tone before TOT time is up.

9. Scan

The radio scans to search for active channels. After finding an active channel, the radio dwells on it for communication.

To start/stop the scan, press the Function key programmed to scan.

10. Initiating a Call during Scan

During the scan, you can press the PTT key to transmit on a preset channel.

Note: This channel is set by your dealer.

11. Stun/ Revive

The radio receives and decodes Kill and Revive signals from another radio, and performs accordingly.

When the radio is killed, it receives no signals but Revives.

When the radio is revived, it transmits and receives signals normally.

Note: This function is available in digital mode only, and is enabled by your dealer.

12. Emergency Alarm

Under the emergency, you may send an emergency alarm by pressing the Function key programmed to send alarms.

To cancel an alarm, press the Function key programmed to exit the emergency alarm.

You need to set an alarm mode and an alarm type.

Alarm Mode

Emergency Alarm: The radio sends an alarm and then exits the alarm state automatically.

Emergency Alarm + Emergency Call: After the radio sends an emergency alarm, press the PTT key to initiate an emergency call.

Emergency Alarm + Auto Background Tone: The radio sends an emergency alarm and then a background tone.

Alarm Type

None: The alarm is disabled. You cannot send an alarm by pressing the Function key programmed to perform this function.

Siren Only: In alarm state, the siren plays locally and the control center cannot receive alarm signals.

Conventional: In an alarm state, there is a light and sound alert, and the radio can receive a response from other members.

Secret: In an alarm state, there is no light or sound alert, and the radio cannot receive a response from other members.

The secret with Voice: In an alarm state, there is no light or sound alert, but the radio can receive a response from other members.

Note:

An emergency alarm is a non-speech signal the radio sends to trigger another radio to give off an alarm.

You may set the above parameters using the programming software.

To guarantee emergent communication, an emergency call is prior to a common call.

Programmable Keys

You may have the Function key programmed by your dealer to perform a specific function as needed.

Note:

Press: Press down and release quickly.

Hold down: Press down and hold for a period set through the CPS.

NO	Function	Description
1	(Undefined)	Press the key, and the radio does not act.
2	High/Low Power	Switch to the high/low power.
3	Monitoring	If CTCSS is enabled on the current analog channel, press the key to switch to c arrier squelch mode (i.e. cancel CTCSS), and the radio outputs voice if carriers are matched.
4	Emergency Alarm	Send an emergency alarm.
5	Exit Emergency Alarm	Quit emergency alarm state.
6	Squelch On/Off	Enable/disable squelch. You may enable this function to receive weak signals on an analog channel.
7	Battery on Level	Press the key to announce the battery level.
8	Scan	Enable/disable scan. Listen to the communication on other channels.
9	Alert Tone On/Off	Enable/disable alert tones.
10	Zone Selection	Switch to another zone. Zones are programmed using the CPS.
11	Repeater/Talk Around	Enable/disable the repeater function for the channel.
12	Nuisance Delete	Press the key to delete an unwanted channel from the scan list.
13	Broadcast Call	Make a broadcast call.

LED Indicator

Indicator State	Device State
Red Light on	Transmission in progress.
Green Light on	Reception in progress.
Red Light Flashing	Low battery. Charging is required.
Green Light Flashing	Scan in progress.
Yellow Light Flashing	Incall holds state in digital mode. Exit when hold time is up.
Yellow Light on	The channel is not configured. Switch to another channel.

Icons (UP405S only)

lcon	Description
	Current channel. (16 channels in total)
	Volume level. (14 levels in total)
	Mute state.
	Low-battery alarm. (Remaining capacity < 5%)
	Remaining battery capacity. (High, medium, or low)
	The zone of the current channel. (16 zones in total)
	Calling in progress.

Troubleshooting

No.	Problem	Reason and Solution
1	Power-on failure	Battery out Solution: Charge or replace the battery. Faulty volume switch Solution: Get it repaired at the authorized service station .
2	Low voice during the call	 Speak too far from the microphone Solution: Keep a distance of 3~10 cm from the microphone. Wrong volume setting Solution: Rotate the volume knob clockwise to increase the volume.
3	Failed to transmit or receive	 Wrong channel parameters Solution: Set the parameters properly and try again. Wrong group identity for default contact Solution: Select the right group. Beyond communication scope Solution: Reduce the distance.

Kirisun reserves the right to the final interpretation of this document. This document is only for reference, and the actual product prevails.

Notice to user

Regulatory

C Kirisun directive (EU) No 2014/53 of the European Parliament and of the Council of 16 April 2014 on harmonization of the laws of the Member States relating to the making available on the market of radio equipment (RED) and that any applicable Essential Test Suits measurement has been performed.

Restrictions Frequencies are valid for the European country

Country	Frequency Range(MHz)	Max. transmit p ower (W)
Germany(DE)	406.1-430 ,440-470	4
France (FR)	406.1-430,444.5-447, 451.5-460, 461.5-470	4
United Kingdom (UK)	410-430 ,440-470	4
Italy(IT)	440-443,445-470	4
Greece(EL)	406.1-430 ,440-470	4
Spain(ES)	406.1-430 ,440-470	4
Ireland (IE)	410 – 430,440 – 455, 456 – 459,460 – 470	4
Belgium(BE)	406.1-430 ,440-470	4
Croatia (HR)	406.1-430 ,440-470	4
Cyprus (CY)	406.1-430 ,440-470	4
Portugal (PT)	440-470	4

Malta(MT)	406.1-430 ,440-470	4
Luxembourg (LU)	410-430,440- 470	4
Bulgaria(BG)	410 -430,440-470	4
Latvia (LV)	406.1-430,440-450,456 -470	4
Slovenia(SI)	406.1-430 ,440-470	4
Czech Republic(CZ)	448 – 451.3,457.38 – 461.3,467.38 – 470	4
Denmark(DK)	406.1-430,450 – 470	4
Estonia(EE)	406.1 - 410,412.5 - 420, 422.5-430,440 - 442.5, 443 - 450,446 -446.2,450 -453,457.575 - 463,467.575 -470	4
Lithuania(LT)	406.1 - 410 , 413 - 418.6 ,423- 428.6 ,440 - 450, 450 - 452.9875,458.1125 - 462.9875 ,467.4875 - 467.5875	4
Hungary(HU)	417 – 420,442 – 445,456 – 460, 461.3 – 470	4
Netherlands(NL)	410 -430,440-470	4
Austria(AT)	444.9 – 444.900001, 450 – 456, 457.33 – 457.330001, 457.45 – 458.3,460 -470	4
Poland(PL)	448 - 449.5,457 - 460,467 - 470	4

Romania (RO) 408 - 410.8,415 - 420.8,425 - 429.8, 440 - 450.55, 457.5 - 458.2, 460 - 460.55,467.5 - 468.2 Slovakia(SK) 441.025 - 451.31,455.73 - 461.31,465.73-470 4 407.525 -408.55,410.0125			
407.525 -408.55,410.0125 410.8875,417.525 - 417.9, 419.15 - 419.525,419.55625 - 419.71875,420.0125 - 420.8875,426.35 - 27.5,427.525 - 427.9, 429.15 - 429.525,429.55625 - 429.71875,440.0125 - 440.5875, 440.60625 - 440.89375,442.775-443, 443.025 - 444, 444.025 - 444.525,444.55 - 444.975,445 - 446, 447.00625 - 447.29375,447.30625 - 447.70625, 449.025 - 449.525,449.55 - 449.975, 450.325 - 452.475, 452.525 - 452.975,453.0125	Romania (RO)	450.55,	4
410.8875,417.525 - 417.9, 419.15 - 419.525,419.55625 - 419.71875,420.0125 - 420.8875,426.35 - 27.5,427.525 - 427.9, 429.15 - 429.525,429.55625 - 429.71875,440.0125 - 440.5875, 440.60625 - 440.89375,442.775-443, Finland(FI) 443.025 - 444, 444.025 - 444.525,444.55 - 444.975,445 - 446, 447.00625 - 447.29375,447.30625 - 447.70625, 449.025 - 449.525,449.55 - 449.975, 450.325 - 452.475, 452.525 - 452.975,453.0125	Slovakia(SK)	441.025 – 451.31,455.73 – 461.31,465.73- 470	4
	Finland(FI)	410.8875,417.525 - 417.9, 419.15 - 419.525,419.55625 - 419.71875,420.0125 - 420.8875,426.35 - 27.5,427.525- 427.9, 429.15 - 429.525,429.55625- 429.71875,440.0125 - 440.5875, 440.60625 - 440.89375,442.775-443, 443.025 - 444, 444.025 - 444.525,444.55 - 444.975,445 - 446, 447.00625 - 447.29375,447.30625 - 447.70625, 449.025 - 449.525,449.55 - 449.975, 450.325 - 452.475, 452.525 - 452.975,453.0125	4

Sweden(SE) $\begin{vmatrix} 406.1 - 430, 442 - 444, 444.5875 - 452.5, 457.5 - 462.5, 467.5 - 4 \\ 70 \end{vmatrix}$

Restrictions are valid for the European country

Restrictions are valid for the following countries:

 $\label{eq:france} France (FR), United Kingdom (UK), Italy(IT), Ireland (IE), Portugal (PT), Luxembourg (LU), Bulgaria(BG), Latvia (LV), Czech Republic (CZ) , Denmark(DK), Estonia(EE), Lithuania(LT) , Hungary(HU) , Netherlands(NL) , Austria(AT), Poland(PL), Romania (RO) , Slovakia(SK) , Finland(FI) , Sweden(SE)$

Waste Electrical and Electronic Equipment recycling

This symbol on the product or its packaging indicates that this product must not be disposed of as household or commercial waste. Some countries have set up collection and recycling systems for waste electrical and electronic products. By ensuring that this product and its packaging is disposed of correctly, you will help prevent potentially negative consequences for the environment and human health, and help conserve natural resources. Please dispose of your waste product according to your national and local regulations. Contact your service provider or Kirisun for information about disposing of this product in your region of the world.

Disposing of batteries

Your radio is supplied with a rechargeable lithium-ion battery. This symbol on the battery and its packaging indicate that it must not be disposed of with household or commercial waste. Please dispose of your waste batteries according to your national and local regulations. Contact your service provider or Kirisun about recycling batteries in your region of the world.

US Markets

FCC& IC radiation exposure statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This radio is designed for and classified as "Occupational/Controlled Use Only", meaning it must be used only
 during the course of employment by individuals aware of the hazards, and the ways to minimize such hazards;
 NOT intended for use in an General population /uncontrolled environment.
- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio.
- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between the user and the device or its antenna shall be at least 25mm and 0mm from your body.

All qualified end-users of this device must have the knowledge to control their exposure conditions and/or duration to comply with occupational/controlled Exposure limits and requirements. The highest reported SAR values for Face-held and body-worn are 2.653 W/Kg and 6.042 W/Kg.

The information listed above provides the user with the information needed to make him or her aware of an RF exposure, and what to do to assure that this radio operates within the RSS-102 exposure limits of this radio.

Output power listed is rated conducted. This device must be restricted to work-related operations only in an Occupational/Controlled RF exposure environment and must operate with a duty factor not exceeding 50%. This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. The

the device complies with RF specifications when the device is used at 25 mm from your front face and 0 mm from your body.

All qualified end-users of this device must have the knowledge to control their exposure conditions and/or duration to comply with occupational/controlled Exposure limits and requirements. A label, as described in this filing, must be displayed on the device to direct users to specific training information for meeting occupational exposure requirements. This portable radio generates RF electromagnetic energy during transmit mode. This radio is designed for and classified as "Occupational Use Only," meaning it must be used only during the course of employment by individuals aware of the hazards and the ways to minimize such hazards. This radio is NOT intended for use by the "General Population" in an uncontrolled environment.

All qualified end-users of this device must have the knowledge to control their exposure conditions and/or duration

to comply with occupational/controlled Exposure limits and requirements. A label, as described in this filing, must be displayed on the device to direct users to specific training information for meeting occupational exposure requirements. The highest reported SAR values for Face-held and body-worn are 3.529 W/Kg and 6.285 W/Kg.



Documents / Resources



<u>Kirisun Communication UP305/UP405 DMR Two-Way Radio</u> [pdf] User Guide UP305, Q5EUP305, UP405, DMR Two-Way Radio, Two-Way Radio, Radio, DMR Radio

Manuals+,