





## Kmart TR0903 6 Volt Scotter User Manual

[Home](#) » [Kmart](#) » Kmart TR0903 6 Volt Scotter User Manual 

*Kmart TR0903 6 Volt Scotter User Manual*

# 6 Volt Scooter

## Assembly & Instruction Manual



Item No.: 3083  
Mode No.: TR0903

- Maximum user weight is 30kg.
- Continuous adult supervision required when using this product.
- Suitable for 3 years and over.
- Always wear a helmet when riding.
- Adult assembly required.
- Before each use, charge the battery for at least 8 -12 hours .
- Charging of the battery should only be done by an adult.
- Please keep this manual for future reference as it contains important information.

#### **Made In China**

**WARNING: Vehicle must be charged fully before use.**

FOR ANY PRODUCT ENQUIRIES OR ISSUES PLEASE CONTACT HUNTER PRODUCTS AT  
[WWW.ELECTRICRIDEON.COM.AU](http://WWW.ELECTRICRIDEON.COM.AU) OR TOLL FREE HELP LINE 1800 224 094.

#### **Contents**

- 1 1. Specifications
- 2 2. List of Parts
- 3 3. Assembly Picture
- 4 4. Function and Circuit Diagram
- 5 5. Fuse
- 6 6. Charging The Vehicle
- 7 7. Troubleshooting Guide
- 8 8. Maintaining your vehicle
- 9 9. Safety Precautions
- 10 10. Disposal of Battery
- 11 Documents / Resources
- 12 Related Posts

## **1. Specifications**

**Battery:** DC6V 4.5AH X 1 Set Battery

**Size of Car:** 92 x 44 x 46 cm

**Charging Times:** Approx. 300 times

**Fuse:** F 5A

**Suitable Age:** 3 years +








**Capacity:** 30kg

**Speed:** 3 km/h


**Charger:** Input: 100-240V 50/60Hz

Output: DC 8V 500mA

## **2. List of Parts**


<p>Vehicle body</p>  <p><b>1</b></p>	<p>Handle bar with streamer</p>  <p><b>2</b></p>	<p>Front wheel set</p>  <p><b>3</b></p>	<p>Seat</p>  <p><b>4</b></p>
<p>Charger</p>  <p><b>5</b></p>	<p>1pcs 4x16mm screw for assembling seat</p>  <p><b>6</b></p>	<p>1pcs M5X70bolt and 1pcs M5 nut for assembling the handle bar</p>  <p><b>7</b></p>	

### 3. Assembly Picture




1. Vehicle body
2. Front wheel set
3. Handle bar
4. Seat
5. 1 pcs M5X 70 bolt
6. 1 pcs M5 nut
7. 1 pce 4\*16mm screw for assembling seat

1. **Assemble the seat.**





Connect the battery wires (red to red). Insert the back tab on the seat into the slot on the vehicle. Tighten with the screw.

2. **Assemble the front wheel.**



Insert the front wheel into the front of the vehicle body.

3. **Assemble the handle bar.**



Screw off the M5x70 bolt and the M5 nut from the vehicle handle bar. **connect the handle and gauge board middle connector.** Insert the handle bar on top of the front of the vehicle body. Secure by inserting the screw stem nut/bolt.

**Before using the vehicle, confirm the following has been completed:**

- The vehicle has been fully assembled according to the steps layer out in the manual.
- The battery has been inserted correctly and the vehicle has been charged for at least 10 hours.
- Ensure all screws are tight.
- Educate your child on all the appropriate safety rules before allowing them to use the vehicle .
- Charger is disconnected from bike.

**Reduce the risk of injury:**

- Direct adult supervision is required.
- Always wear protective clothing including footwear.
- Do not exceed the maximum user weight of 30kg.
- Keep children within safe user areas.
- Never use on roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other sources of water.

**⚠ WARNING:**

To reduce the risk of injury, adult supervision is required.  
Never use on roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes and never allow more than 1 rider.


**⚠ WARNING:**

Contains small parts, sharp points and sharp edges. Adult assembly required.

**⚠ WARNING:**

**Choking Hazard!** Contains small parts. Not for children under 3 years old!

1. Circuit Diagram



4. Function and Circuit Diagram

2. Introduction of the functions

- (a) Power switch
- (b) Forward and Reverse switch
- (c) Pedal switch
- (d) Horn and engine switch

**TO MOVE FORWARD**

1. Turn the power switch to the 'ON' position.
2. Press the 'Forward and Reverse' switch to the 'Forward' position.
3. Press the pedal with your foot.
4. The vehicle will move forward.

**TO STOP**

To stop, remove your foot from the accelerator pedal.


**TO REVERSE**

1. Turn the power switch to the 'ON' position.
2. Press the 'Forward and Reverse' switch to the 'Reverse' position.

3. Press the pedal with your foot.
4. The vehicle will move backwards.

### Sound


You can enjoy sound by push any sound button.



### PLEASE NOTE:

Make sure the vehicle comes to a complete stop before changing directions from forward to reverse. Not doing so will cause damage to the gearbox/motor.

**WARNING:** Disconnect charger from bike before operation. It will not work while charging.



The drive battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery should operate for one to three years.



Follow these steps to replace and dispose the battery:

1. Remove the seat.
2. Disconnect the battery connectors.
3. Remove the battery bracket.
4. Carefully lift the battery.
  - Depending on the condition of the battery (i.e.: leakage) you may want to wear protective rubber gloves before removal.
  - Do not lift the battery by its connectors or cables.
5. Place the dead battery in a plastic bag.


**Important!**

- The sealed lead-acid battery must be recycled or disposed of in an environment-tally sound manner.
  - Do not dispose of battery in a fire. The battery may explode or leak acid.
  - Do not dispose of the battery in household trash. The incineration, land filling or mixing of sealed lead-acid batteries with household trash is prohibited by law.
6. Install replacement battery and reconnect the connectors.
  7. Replace the battery bracket.
  8. Replace the seat.

## 5. Fuse

The vehicle is equipped with a self-resetting fuse. When the vehicle is overloaded or operated incorrectly; the self-resetting fuse will be cut off for 15-20 seconds before becoming operational again.

The self-resetting fuse is under the seat (Refer to the picture).




**To avoid electric shock, follow these guidelines:**

- DO NOT** overload the vehicle. The maximum user weight is 30kg.
- DO NOT** tow any thing behind the vehicle.
- DO NOT** drive up steep slopes.
- DO NOT** drive into fixed objects, which may cause the wheels to spin, causing the motor to overheat.
- DO NOT** drive in very hot weather, components may overheat.
- DO NOT** allow water or other liquids to come in contact with the battery or other electric components.
- DO NOT** tamper with the electric system. Doing so may create a short circuit causing the fuse to trip.



## 6. Charging The Vehicle

- The charging socket is at the back right of the vehicle body.
- Press the power switch to the 'OFF' position to turn the power off.
- Plug charger pin into bike next to seat.  
Plug the charger into a 240V mains power wall outlet.
- The battery should be charged for 8-12 hours before the first use. Do not recharge the battery for more than 16 hours to avoid damage to the battery and charger.
- Never drain battery completely or to a crawling speed, recharge the battery when a decrease in speed and power is noticed.  
Warranty will be voided if misuse has occurred.
- After each use (or a minimum of once a month), recharge for ideally 8-12 hours, but no longer than 16 hours.



- Battery charging must be done by adults only. Never allow children to charge the battery.
- Do not short circuit the battery.
- The charger and the battery are not toys.
- Do not allow children to play with the charger and the battery.
- Only use the battery and charger specified by the manufacturer.
- Do not attempt to open the battery or charger.
- Always secure the battery with the bracket.
- The battery must be handled by adults only. Dropping the battery could result in serious injury.
- Do not allow the battery to drain completely. Recharge after each use or at least once a month.
- Before charging the battery, check for wear or damage to the battery, charger, connectors and other parts. If any damage is found, charger should be repaired or replaced immediately.
- Do not use a damaged charger.  
It is normal for the adaptor to feel warm during charging, but if the charger feels very hot, stop charging and check the battery and adaptor .
- Non-rechargeable batteries are not to be recharged rechargeable batteries are to be removed from the toy before being charged different types of batteries or new and used batteries are not to be mixed batteries are to be inserted with the correct polarity exhausted batteries are to be removed from the toy

## 7. Troubleshooting Guide

PROBLEM	POSSIBLE CAUSE
The 6 Volt battery will not recharge	<ul style="list-style-type: none"><li>• Battery connector is loose. Make sure the battery connector is firmly plugged in.</li><li>• The 6-Volt battery will not recharge. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on.</li><li>• Charger is not plugged in. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on.</li><li>• Check and replace fuse if necessary.</li></ul>
The vehicle does not run	<ul style="list-style-type: none"><li>• The battery is dead. Have you properly maintained the battery according to the directions? Is the battery old? Your battery may need to be replaced. Contact Hunter Products Customer Service for assistance on 1800 224 094.</li><li>• Electrical system is damaged. Water may have corroded the system or loose dirt, gravel or sand may have jammed the switch.</li><li>• Motor is damaged. Contact Hunter Products Customer Service for assistance on 1800 224 094.</li><li>• Battery connector is loose. Make sure the battery connector is firmly plugged in.</li><li>• The 6-Volt battery will not recharge. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on.</li><li>• Charger is not plugged in. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on.</li><li>• Check and replace fuse if necessary.</li></ul>

The vehicle does not run for very long	<ul style="list-style-type: none"> <li>The battery may be undercharged. You may not be charging the battery for long enough. After each use, or at a minimum of once a month, charge the battery for a full 10 hours. <b>DO NOT</b> leave the the battery on the charger for more than 16 hours.</li> <li>The battery is old. The 6 Volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions , the battery should operate for one to three years. Replace the battery with a new 6 Volt battery.</li> <li>Available through Hunter Products Customer Sevice</li> </ul>
Battery buzes or gurgles when charging	<ul style="list-style-type: none"> <li>This is normal and not a cause for concern. It may also be silent when charging, which is also normal.</li> </ul>
The vehicle runs sluggishly	<ul style="list-style-type: none"> <li>The battery needs recharging. After each use, or at a minimum of once a month, charge the battery for a full 10 hours. <b>DO NOT</b> leave the battery on the charger for more than 16 hours.</li> <li>The battery is old. The 6 Volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery should operate for one to three years. Replace the battery with a new 6 Volt battery.</li> <li>The vehicle is overloaded. Maximum weight is 30kg. <b>DO NOT</b> overload the vehicle. <b>DO NOT</b> tow anything behind the vehicle.</li> </ul>

## 8. Maintaining your vehicle

- It is a parents responsibility to check main parts of the vehicle before use. Regularly examine the vehicle for potential hazards, such as the battery, charge cable, cord and plug. Ensure screws are tightened. If there are any damages, the vehicle must not be used until these damages have been properly repaired or replaced.
- Occasionally use a lightweight oil to lubricate moving parts such as the wheels and steering linkages.
- Keep the vehicle in an upturned position, do not overturn or incline it. It is recommended to store the vehicle indoors when not in use.
- This toy should be kept away from fire. Keep the vehicle away from sources of heat, such as stoves and heaters. Plastic parts may melt. While charging ensure all flammable liquids are well away from the vehicle.
- ADULTS ONLY** to recharge the battery after each use. Recharge the battery at least once a month when the vehicle is not being used.
- Use a soft, dry cloth to clean vehicle.
- DO NOT** use any chemical liquids to clean the plastic surface of the vehicle.
- DO NOT** wash the vehicle with soap and water.
- DO NOT** drive the vehicle in rainy or snowy weather. Water will damage the motor, electric system and battery.
- When not in use all electrical sources should be turned off. Press the power switch to the 'OFF' position to turn the power off. Also disconnect the battery connection under the seat.
- Please do not change the structure of this product and circuit system.
- DO NOT** use the vehicle for other purposes except riding.

## 9. Safety Precautions

1. While riding, adult supervision is required at all times.
2. Always wear a helmet when riding.
3. Do not ride near roads or on the footpath.
4. It is not recommended to drive the vehicle on wet surfaces or on slopes greater than 15 degrees.
5. It is recommended to ride this vehicle on smooth surfaces only.
6. Do not use this vehicle outdoors when it is raining.
7. Make sure you come to a complete stop before changing directions from forward to reverse.
8. Don't allow children to operate the charger or play with the battery.
9. Clean the vehicle with a dry cloth only.
10. Please follow the correct weight and age limits allowed to drive this vehicle.
11. It is prohibited to change the circuit or add other electric parts.
12. Adults must teach their children about safe driving procedures.
13. Please turn the power off when not in use.
14. Check the seat ensure it has been fitted and secured with a bolt before driving.
15. Inspect all wires and connections of the vehicle periodically.
16. Charging the battery should only be done by adults.
17. In order to avoid accidents, please ensure the vehicle is safe before driving.
18. Do not let any child touch the wheels or be near them when the car is moving.
19. This toy contains batteries that are non-replaceable
20. Warning. Not to be used in traffic.
21. WARNING: it has the potential hazards of using the ride-on electric toy in areas other than private grounds.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Where a failure does not amount to a major failure, we are entitled to choose between providing you with a repair, replacement or refund. To obtain compensation, you would need to provide documentary evidence of the loss or damage suffered, and documentary evidence that such loss or damage was a reasonably foreseeable consequence of a failure by us to comply with a consumer guarantee under the Australian Consumer Law. Such evidence may include photographs, statutory declarations, receipts or reports (e.g. from your doctor), depending on the loss or damage.

In addition to all rights and remedies to which you may be entitled under the Competition and Consumer Act 2010 (Commonwealth) and any other relevant legislation, the manufacturer warrants this product to be free from defects in materials or workmanship for a period as stated on the packaging from the date of purchase.

In order to claim under this warranty, you will need to bring the product to the store of purchase, along with proof of purchase (typically this will be a receipt). Any cost incurred by you in bringing the product to the service desk will be borne by you. We will then, at our option, either repair or replace the product, or refund your money and take back the product.

Our liability under this manufacturer's warranty is subject to us being satisfied that a defect was caused by defective workmanship or materials, and was not caused by or substantially contributed to by other factors, or circumstances beyond our control, including (but not limited to) defective installation, maintenance or repair,

alteration or modification of the product in any manner not recommended by the manufacturer or any neglect, misuse or excessive use.

The benefits conferred by this manufacturer's warranty are in addition to all rights and remedies conveyed by the Competition and Consumer Act 2010 (Commonwealth), and any other statutory rights to which you may already be entitled, and this warranty does not exclude, restrict or modify any such rights or remedies that are implied by law.


## HUNTER PRODUCTS

Level 2, 424 Warringal Road Moorabbin 3189

Ph: 1800 224 094

Email: [enquiries@hunterproducts.com.au](mailto:enquiries@hunterproducts.com.au)

## 10. Disposal of Battery




- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Do not dispose of your lead-acid battery in a fire. The battery may explode or leak.

**PLEASE NOTE:  
IN CASE OF PRODUCT FAULT,  
PLEASE CONTACT:  
HUNTER PRODUCTS CUSTOMER SERVICE  
TOLL FREE NUMBER:  
1800 224 094**

For customer service or product enquiries please contact:  
Hunter Products Customer Service  
Toll Free – 1800 224 094

**MADE IN CHINA**

## Documents / Resources

	<p><a href="#">Kmart TR0903 6 Volt Scooter</a> [pdf] User Manual TR0903, 6 Volt Scooter</p>
---	---